

IDX

Firmware Specification



TABLE OF CONTENTS

1	ABOUT	7
1.1	About this Document	7
1.2	About the Devices.	11
1.3	About the Safety Precautions	11
2	SYSTEM OVERVIEW	13
2.1	Device Architecture.	13
2.2	Device Control	14
2.3	System Units.	17
2.4	USB Bus Powering	18
3	OPERATING MODES	19
3.1	Operating Mode Selection Guide	19
3.2	Overview.	20
3.3	Profile Position Mode (PPM).	21
3.4	Profile Velocity Mode (PVM).	25
3.5	Homing Mode (HMM)	28
3.6	Cyclic Synchronous Position Mode (CSP)	37
3.7	Cyclic Synchronous Velocity Mode (CSV)	41
3.8	Cyclic Synchronous Torque Mode (CST)	44
3.9	Position Control Function	47
3.10	Velocity Control Function	49
3.11	Current Control Function	51
4	INPUTS AND OUTPUTS	53
4.1	Digital Inputs.	53
4.2	Digital Outputs	54
4.3	Analog Inputs	55

READ THIS FIRST

These instructions are intended for qualified technical personnel. Prior commencing with any activities...

- *you must carefully read and understand this manual and*
- *you must follow the instructions given therein.*

IDX drives are considered as partly completed machinery according to EU Directive 2006/42/EC, Article 2, Clause (g) and are intended to be incorporated into or assembled with other machinery or other partly completed machinery or equipment.

Therefore, you must not put the device into service,...

- *unless you have made completely sure that the other machinery fully complies with the EU directive's requirements!*
- *unless the other machinery fulfills all relevant health and safety aspects!*
- *unless all respective interfaces have been established and fulfill the herein stated requirements!*

5	COMMUNICATION	57
5.1	USB Communication	57
5.2	CAN Communication	57
5.3	EtherCAT Communication	57
5.4	Gateway Communication (USB to CAN)	57
6	OBJECT DICTIONARY	59
6.1	Overview	59
6.1.1	Object Data Types	59
6.1.2	Object Codes	59
6.1.3	Object Access Types	59
6.1.4	Object Flags	60
6.1.5	Entries Overview	60
6.2	Objects	64
6.2.1	Device type	64
6.2.2	Error register	64
6.2.3	Error history	65
6.2.4	COB-ID SYNC	66
6.2.5	Manufacturer device name	67
6.2.6	Store parameters	67
6.2.7	Restore default parameters	68
6.2.8	COB-ID EMCY	68
6.2.9	Consumer heartbeat time	69
6.2.10	Producer heartbeat time	70
6.2.11	Identity object	70
6.2.12	Error behavior	72
6.2.13	Diagnosis History	73
6.2.14	SDO server parameter	77
6.2.15	Receive PDO 1 parameter	78
6.2.16	Receive PDO 2 parameter	80
6.2.17	Receive PDO 3 parameter	81
6.2.18	Receive PDO 4 parameter	82
6.2.19	Receive PDO 1 mapping	83
6.2.20	Receive PDO 2 mapping	85
6.2.21	Receive PDO 3 mapping	86
6.2.22	Receive PDO 4 mapping	88
6.2.23	Transmit PDO 1 parameter	89
6.2.24	Transmit PDO 2 parameter	91
6.2.25	Transmit PDO 3 parameter	93
6.2.26	Transmit PDO 4 parameter	94
6.2.27	Transmit PDO 1 mapping	96
6.2.28	Transmit PDO 2 mapping	98
6.2.29	Transmit PDO 3 mapping	99
6.2.30	Transmit PDO 4 mapping	101
6.2.31	SYNC manager communication type	102

6.2.32 SYNC manager 2 PDO assignment	104
6.2.33 SYNC manager 3 PDO assignment	105
6.2.34 SYNC manager 2 parameter	106
6.2.35 SYNC manager 3 parameter	110
6.2.36 Program data	113
6.2.37 Program control	114
6.2.38 Program software identification.	115
6.2.39 Flash status identification	116
6.2.40 Node-ID.	118
6.2.41 CAN bit rate	119
6.2.42 USB frame timeout	119
6.2.43 CAN bit rate display	120
6.2.44 Active fieldbus.	120
6.2.45 Active controller type.	121
6.2.46 Additional identity	121
6.2.47 Extension 1 identity.	122
6.2.48 Custom persistent memory.	124
6.2.49 Power supply	125
6.2.50 Power supply supervision	126
6.2.51 Axis configuration	128
6.2.52 Motor data	133
6.2.53 Electrical system parameters	135
6.2.54 Gear configuration	136
6.2.55 SSI absolute encoder	138
6.2.56 Current control parameter set.	146
6.2.57 Position control parameter set	147
6.2.58 Velocity control parameter set	150
6.2.59 Velocity observer parameter set.	152
6.2.60 Home position.	154
6.2.61 Home offset move distance	154
6.2.62 Current threshold for homing mode	155
6.2.63 Current demand value	155
6.2.64 Current actual values	156
6.2.65 Torque actual values.	157
6.2.66 Velocity actual values	158
6.2.67 Standstill window configuration.	159
6.2.68 Digital input properties	161
6.2.69 Configuration of digital inputs	162
6.2.70 Digital output properties	164
6.2.71 Configuration of digital outputs	165
6.2.72 Holding brake parameters.	166
6.2.73 Analog input properties.	168
6.2.74 Configuration of analog inputs	169
6.2.75 Analog input general purpose.	170
6.2.76 Analog input adjustment	171
6.2.77 Analog input current set value properties	172
6.2.78 Analog input velocity set value properties.	175

6.2.79 Power limitation	177
6.2.80 Thermal overload protection	178
6.2.81 Motor control	180
6.2.82 Abort connection option code	180
6.2.83 Error code	181
6.2.84 Controlword	182
6.2.85 Statusword	183
6.2.86 Quick stop option code	184
6.2.87 Shutdown option code	185
6.2.88 Disable operation option code	185
6.2.89 Halt option code	186
6.2.90 Fault reaction option code	186
6.2.91 Modes of operation	187
6.2.92 Modes of operation display	187
6.2.93 Position demand value	188
6.2.94 Position actual value	188
6.2.95 Following error window	188
6.2.96 Following error time out	189
6.2.97 Position window	190
6.2.98 Position window time	191
6.2.99 Velocity demand value	191
6.2.100 Velocity actual value	191
6.2.101 Target torque	192
6.2.102 Motor rated torque	192
6.2.103 Torque actual value	192
6.2.104 Target position	193
6.2.105 Position range limit	194
6.2.106 Home offset	195
6.2.107 Software position limit	195
6.2.108 Max profile velocity	196
6.2.109 Max motor speed	197
6.2.110 Profile velocity	197
6.2.111 Profile acceleration	198
6.2.112 Profile deceleration	198
6.2.113 Quick stop deceleration	198
6.2.114 Motion profile type	199
6.2.115 Homing method	200
6.2.116 Homing speeds	201
6.2.117 Homing acceleration	202
6.2.118 SI unit position	202
6.2.119 SI unit velocity	203
6.2.120 SI unit acceleration	204
6.2.121 Position offset	204
6.2.122 Velocity offset	205
6.2.123 Torque offset	205
6.2.124 Touch probe function	206
6.2.125 Touch probe status	207

6.2.126	Touch probe 1 positive edge	207
6.2.127	Touch probe 1 negative edge	208
6.2.128	Interpolation time period	209
6.2.129	Max acceleration	210
6.2.130	Touch probe source	211
6.2.131	Touch probe 1 positive edge counter	212
6.2.132	Touch probe 1 negative edge counter	212
6.2.133	Supported homing methods	213
6.2.134	Following error actual value	218
6.2.135	Digital inputs	219
6.2.136	Digital outputs	220
6.2.137	Target velocity	221
6.2.138	Motor type	221
6.2.139	Supported drive modes	222
6.2.140	Modular device profile	223
6.2.141	Configured module ident list	224
6.2.142	Detected module ident list	225
6.3	Modular Device Profile Module	226
6.3.1	MDP Module PPM	226
6.3.2	MDP Module PVM	227
6.3.3	MDP Module CSP	228
6.3.4	MDP Module CSV	229
6.3.5	MDP Module CST	230
7	ERROR HANDLING	231
7.1	Emergency Message Frame	231
7.2	Device Errors	231
7.3	CANopen Communication Errors (Abort Codes)	248
7.4	EtherCAT FoE Error Codes	249
8	FIRMWARE VERSION HISTORY	251
8.1	Version Overview	251
8.2	Version History	251
	LIST OF FIGURES	253
	LIST OF TABLES	255
	INDEX	259

1 ABOUT

1.1 About this Document

1.1.1 Intended Purpose

The purpose of the present document is to familiarize you with the described equipment and the tasks on safe and adequate installation and/or commissioning. Follow the described instructions ...

- to avoid dangerous situations,
- to keep installation and/or commissioning time at a minimum,
- to increase reliability and service life of the described equipment.

The present document is part of a documentation set and provides IDX firmware details and contains descriptions on architecture, device states, operation modes, error handling, and object dictionary. The below overview shows the documentation hierarchy and the interrelationship of its individual parts:




Figure 1-1 Documentation structure

Find the latest edition of the present document as well as additional documentation and software for IDX positioning controllers also on the Internet: ➔ <http://idx.maxongroup.com>

1.1.2 Target Audience

This document is meant for trained and skilled personnel working with the equipment described. It conveys information on how to understand and fulfill the respective work and duties.

This document is a reference book. It does require particular knowledge and expertise specific to the equipment described.

1.1.3 How to use

Take note of the following notations and codes which will be used throughout the document.

Notation	Explanation
EPOS4	stands for “EPOS4 positioning controller”
IDX	stands for “IDX drive”
«Abcd»	indicating a title or a name (such as of document, product, mode, etc.)
(n)	referring to an item (such as order number, list item, etc.)
*	referring to an internal value
➔	denotes “see”, “see also”, “take note of”, or “go to”

Table 1-1 Notations used

In the later course of the present document, the following abbreviations and acronyms will be used:

Short	Description
CCW	Counterclockwise
CiA	CAN in Automation
CSP	Cyclic Synchronous Position Mode
CST	Cyclic Synchronous Torque Mode
CSV	Cyclic Synchronous Velocity Mode
CW	Clockwise
GPIO	General purpose input/output
HMM	Homing Mode
NMT	Network Management
OBD	Object Dictionary
PDO	Process Data Object
PPM	Profile Position Mode
PVM	Profile Velocity Mode
SDO	Service Data Object

Table 1-2 Abbreviations & acronyms used

1.1.4 Symbols and Signs



Requirement / Note / Remark
Indicates an action you must perform prior continuing or refers to information on a particular item.



Best Practice
Gives advice on the easiest and best way to proceed.



Material Damage
Points out information particular to potential damage of equipment.

1.1.5 Trademarks and Brand Names

For easier legibility, registered brand names are listed below and will not be further tagged with their respective trademark. It must be understood that the brands (the below list is not necessarily concluding) are protected by copyright and/or other intellectual property rights even if their legal trademarks are omitted in the later course of this document.

Brand name	Trademark owner
Adobe® Reader®	© Adobe Systems Incorporated, USA-San Jose, CA
CANopen® CiA®	© CiA CAN in Automation e.V, DE-Nuremberg
EtherCAT®	© EtherCAT Technology Group, DE-Nuremberg, licensed by Beckhoff Automation GmbH, DE-Verl

Table 1-3 Brand names and trademark owners

1.1.6 Sources for additional Information

For further details and additional information, please refer to below listed sources:

#	Reference
[1]	USB Implementers Forum: Universal Serial Bus Revision 2.0 Specification www.usb.org/developers/docs
[2]	CiA 301 CANopen application layer and communication profile www.can-cia.org
[3]	CiA 305 Layer Setting Services (LSS) and protocols www.can-cia.org
[4]	CiA 306 CANopen electronic data sheet specification www.can-cia.org
[5]	CiA 402 CANopen device profile for drives and motion control www.can-cia.org
[6]	Bosch's CAN Specification 2.0 www.can-cia.org
[7]	Konrad Etschberger: Controller Area Network ISBN 3-446-21776-2
[8]	maxon: IDX Communication Guide www.maxongroup.com
[9]	maxon: IDX Application Notes www.maxongroup.com
[10]	IEC 61158-x-12: Industrial communication networks – Fieldbus specifications (CPF 12)
[11]	IEC 61800-7: Adjustable speed electrical power drives systems (Profile type 1)
[12]	ETG.1000 EtherCAT Specification www.ethercat.org
[13]	ETG.1020 EtherCAT Protocol Enhancements Specification www.ethercat.org
[14]	ETG.2000 EtherCAT Slave Information (ESI) Specification www.ethercat.org
[15]	EN 5325-4 Industrial communications subsystem based on ISO 11898 (CAN) for controller device interfaces Part4: CANopen

Table 1-4 Sources for additional information

1.1.7 Copyright

© 2021 maxon. All rights reserved. Any use, in particular reproduction, editing, translation, and copying, without prior written approval is not permitted (contact: maxon international ltd., Brünigstrasse 220, CH-6072 Sachseln, +41 41 666 15 00, www.maxongroup.com). Infringements will be prosecuted under civil and criminal law. The mentioned trademarks belong to their respective owners and are protected under trademark laws. Subject to change without prior notice.

CCMC | IDX Firmware Specification | Edition 2025-05 | DocID rel12948

1.2 About the Devices

maxon's «IDX» are compact, high-performance, IP 65-protected, brushless DC drives with either integrated positioning controller or speed controller particularly suitable for the use in harsh environmental conditions. They deliver up to 0.7 Nm of continuous torque and come in a wide range of configurable options that allow full adaption to suit specific needs.

The IDX firmware is based on maxon's EPOS4 platform.

1.3 About the Safety Precautions

IMPORTANT NOTICE: PREREQUISITES FOR PERMISSION TO COMMENCE INSTALLATION

IDX drives are considered as partly completed machinery according to EU Directive 2006/42/EC, Article 2, Clause (g) and **are intended to be incorporated into or assembled with other machinery or other partly completed machinery or equipment.**



WARNING

Risk of Injury

Operating the device without the full compliance of the surrounding system with the EU directive 2006/42/EC may cause serious injuries!

- *Do not operate the device, unless you have made sure that the other machinery fulfills the requirements stated in EU directive!*
- *Do not operate the device, unless the surrounding system fulfills all relevant health and safety aspects!*
- *Do not operate the device, unless all respective interfaces have been established and fulfill the stated requirements!*

••page intentionally left blank••

2 SYSTEM OVERVIEW

2.1 Device Architecture

The IDX's communication interface follows these specifications (numbers in brackets refer to respective items listed on →Page 1-10):

- CiA 301 V4.2; CANopen application layer and communication profile (→[2]), corresponds with the international standard EN 5325-4; Industrial communications subsystem based on ISO 11898 (CAN) (→[15])
- CiA 306 V1.3; CANopen electronic data sheet specification (→[4])
- CiA 402 V4.0; CANopen device profile for drives and motion control (→[5]), corresponds with international standard IEC 61800-7 Ed 2.0; Generic interface and use of profiles for power drive systems – profile type 1 (→[11])
- ETG.1000 V1.0.4; EtherCAT Specification (→[12]), corresponds with the international standard IEC 61158-x-12; Industrial communication networks – Fieldbus specifications (CPF 12: EtherCAT) (→[10])
- ETG.1020 V1.2.0; EtherCAT Protocol Enhancements Specification (→[13])
- ETG.2000 V1.0.9; EtherCAT Slave Information (ESI) Specification (→[14])




Figure 2-2 Communication architecture

DEVICE CONTROL

Starting and stopping of the drive and several mode-specific commands are executed by the state machine.

MODES OF OPERATION

The operating mode defines the behavior of the drive.

2.2 Device Control

The state machine describes the axis state and the possible control sequence of the axis. An axis state represents a special internal or external behavior. The state of the axis also determines the commands that will be accepted.

States may be changed using the →Controlword and/or according to internal events. The actual state can be read using the →Statusword. A new state transition must not be initiated before the previous one is completed and the →Statusword is changed accordingly.




Figure 2-3 Device State Machine

2.2.1 State of the Drive

The following → Statusword bits indicate the actual state of the drive.

State	Statusword [binary]	Description
Not ready to switch on	xxxx xxxx x00x 0000	Drive function is disabled
Switch on disabled	xxxx xxxx x10x 0000	Drive initialization is complete. Drive parameters may be changed. Drive function is disabled.
Ready to switch on	xxxx xxxx x01x 0001	Drive parameters may be changed. Drive function is disabled.
Switched on	xxxx xxxx x01x 0011	Drive function is disabled. Current offset calibration done.
Operation enabled	xxxx xxxx x01x 0111	No faults have been detected. Drive function is enabled and power is applied to the motor.
Quick stop active	xxxx xxxx x00x 0111	«Quick stop» function is being executed. Drive function is enabled and power is applied to the motor.
Fault reaction active	xxxx xxxx x00x 1111	A fault has occurred in the drive. Selected fault reaction is being executed.
Fault	xxxx xxxx x00x 1000	A fault has occurred in the drive. Drive parameters may have changed. Drive function is disabled.

Table 2-5 Device state bits

2.2.2 State Transitions

State transitions are caused by internal events in the drive or by commands from the host via the → Controlword.



State transition during change of state

If a command is received which causes a change of state, this command will be processed completely and the new state attained before the next command can be processed.

Transition	Event	Action
0	Reset	Initialize drive
1	Drive has initialized successfully	Activate communication
2	«Shutdown» command received	
3	«Switched on» command received	Initialize current sensor. Current offset calibration.
4	«Enable operation» command received	Enable drive function (enable current controller and, if needed, position or velocity controller)
5	«Disable operation» command received	Stop movement according to «Disable operation option code». Disable drive function.
6	«Shutdown» command received	Disable power section
7	«Quick stop» or «Disable voltage» command received	
8	«Shutdown» command received	Stop movement according to «Shutdown option code». Disable drive function and power section.

Continued on next page.

Transition	Event	Action
9	«Disable voltage» command received	Stop movement according to «Shutdown option code». Disable drive function and power section.
10	«Quick stop» or «Disable voltage» command received	
11	«Quick stop» command received	Stop movement according to «Quick stop option code»
12	«Disable voltage» command received	Disable drive function and power section
13	A fault has occurred	Start fault reaction
14	The fault reaction is completed	Disable drive function and power section
15	«Fault reset» command received	Reset fault condition if no fault is present
16	«Enable operation» command received	

Table 2-6 Device state transitions

2.2.3 Device Control Commands

Axis control commands are triggered by the following bit patterns in the →Controlword.

Command	Controlword LowByte [binary]	State transition
Shutdown	0xxx x110	2, 6, 8
Switch on	0xxx x111	3
Switch on & Enable operation	0xxx 1111	3, 4 (*1)
Disable voltage	0xxx xx0x	7, 9, 10, 12
Quick stop	0xxx x01x	11
Disable operation	0xxx 0111	5
Enable operation	0xxx 1111	4, 16
Fault reset	0xxx xxxx → 1xxx xxxx	14, 15

(*1) Automatic transition to state «Operation enabled» after execution of command «Switch on»

Table 2-7 Axis control commands

2.3 System Units

The user-defined units for this device are as follows:

- Position Units (→“SI unit position” auf Seite 6-202)
- Velocity Units (→“SI unit velocity” auf Seite 6-203)
- Acceleration Units (→“SI unit acceleration” auf Seite 6-204)

The units are used for all objects that support user-defined units. They are specified by the SI unit objects. Objects with factor group-independent values have fixed units specified by the object.

Coding of user-defined units and prefixes takes place as to →Table 2-8.

Bit 31...24	Bit 23...16	Bit 15...8	Bit 7...0
Prefix	Numerator	Denominator	reserved (0)

Table 2-8 User-defined units – Parameter structure

2.3.1 SI Units

Description	Name	Symbol	Notation index
Dimensionless	–	–	0x00
Length	Meter	m	0x01
Mass	Kilogram	kg	0x02
Time	Second	s	0x03
Electric current	Ampere	A	0x04
Time	Minute	min	0x47
Square second	Square second	s ²	0x57

Table 2-9 SI units – Notation index

2.3.2 CiA 402 Application Profile-specific Units

Description	Name	Symbol	Notation index
Revolutions	revolutions	rev	0xB4
Increments	increments	inc	0xB5
Steps	steps	steps	0xAC
Velocity (manufacturer-specific)	revolutions/minute	rpm	0xC0

Table 2-10 CiA 402 Application profile-specific units – Notation index

2.3.3 Unit Prefixes

Prefix	Factor	Symbol	Notation index
Mega	10^6	M	0x06
Kilo	10^3	k	0x03
Hecta	10^2	h	0x02
Deca	10^1	da	0x01
—	10^0	—	0x00
Deci	10^{-1}	d	0xFF
Centi	10^{-2}	c	0xFE
Milli	10^{-3}	m	0xFD
—	10^{-4}	—	0xFC
—	10^{-5}	—	0xFB
Micro	10^{-6}	μ	0xFA

Table 2-11 Unit prefixes – Notation index

2.4 USB Bus Powering

Powering the controller for configuration via USB only is not possible. To use a communication interface, either the power supply or the logic supply must be connected.

3 OPERATING MODES

3.1 Operating Mode Selection Guide

The device behavior depends on the currently activated mode of operation.

- Choose desired mode (→ “Overview” on page 3-20).
- Select mode using (→ “Modes of operation” on page 6-187).
- Read currently active mode from → “Modes of operation display” on page 6-187.




Figure 3-4 Functional architecture

3.2 Overview

PROFILE POSITION MODE (PPM)

Defines the drive's positioning. Speed, position, and acceleration can be limited, profiled moves can be executed using a Trajectory Generator. For details see →Page 3-21.

PROFILE VELOCITY MODE (PVM)

Controls the drive's velocity without particular focus on the position. It supplies limit functions and Trajectory Generation. For details see →Page 3-25.

HOMING MODE (HMM)

Provides various methods to find the home position (also called reference point or zero point). For details see →Page 3-28.

CYCLIC SYNCHRONOUS POSITION MODE (CSP)

The trajectory generator is located in the control device (not in the drive device). In cyclic synchronous manner, it provides a target position to the drive device, which then performs position control, velocity control, and torque control. For details see →Page 3-37

CYCLIC SYNCHRONOUS VELOCITY MODE (CSV)

The trajectory generator is located in the control device (not in the drive device). In cyclic synchronous manner, it provides a target velocity to the drive device, which then performs velocity control and torque control. For details see →Page 3-41

CYCLIC SYNCHRONOUS TORQUE MODE (CST)

The trajectory generator is located in the control device (not in the drive device). In cyclic synchronous manner, it provides a target torque to the drive device, which then performs torque control. For details see →Page 3-44.

3.3 Profile Position Mode (PPM)

The operating mode is only available for «IDX CANopen» and «IDX EtherCAT».

A target position is applied to the trajectory generator. It will generate a position demand value for the position control function.



Annotation

Items marked with an asterisk (*) refer to internal values.




Figure 3-5 Profile Position Mode – Block diagram

3.3.1 Profile Position Trajectory Generator

The trajectory generator supports the following motion profiles.




Figure 3-6 Profile position trajectory – Linear ramp (trapezoidal profile)

3.3.2 How to use «PPM»

CONFIGURATION PARAMETERS

Parameter	Index	Description
→ Software position limit	0x607D	Contains the sub-parameters “Min position limit” and “Max position limit” that define the absolute position limits of the position demand value and position actual value. A new target position will be checked against these limits.
→ Max profile velocity	0x607F	Defines the maximal permitted speed
→ Max motor speed	0x6080	Indicates the configured maximal permitted speed for the motor. It serves as protection of the motor and is taken from the motor data sheet.
→ Max gear input speed	0x3003	Indicates the configured maximal permitted input speed of the gear. It serves as protection of the gear and is taken from the gear data sheet. Together with “Max motor speed”, it limits the speed of the system.
→ Quick stop deceleration	0x6085	Defines the deceleration ramp during a «Quick stop»
→ Max acceleration	0x60C5	Defines the maximal allowed acceleration and deceleration

Table 3-12 Profile Position Mode – Configuration parameters

COMMANDING PARAMETERS

Parameter	Index	Description
➔Controlword	0x6040	The mode will be controlled by a write access to the controlword's mode-dependent bits
➔Target position	0x607A	The position to which the drive is supposed to move using the motion control parameters, such as velocity, acceleration, motion profile type, etc. It will be interpreted as absolute or relative depending on the controlword "abs / rel" flag.
➔Profile velocity	0x6081	The velocity normally attained at the end of the acceleration ramp during a profiled move
➔Profile acceleration	0x6083	Defines the acceleration ramp during a movement
➔Profile deceleration	0x6084	Defines the deceleration ramp during a movement
➔Motion profile type	0x6086	Selects the type of motion profile used for the movement: 0 = linear ramp (trapezoidal profile)

Table 3-13 Profile Position Mode – Commanding parameters

CONTROLWORD (PROFILE POSITION MODE-SPECIFIC BITS)

To perform system endless movements, the "endless movement" bit can be set. Speed is given by ➔"Profile velocity" on page 6-197 while direction is given by the sign of ➔"Target position" on page 6-193.

Bit 15	Bit 14...9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3...0
Endless movement	➔Table 6-1 27	Halt	➔Table 6-1 27	Abs / rel	Change set immediately	New setpoint	➔Table 6-1 27

Table 3-14 Profile Position Mode – Controlword

Name	Value	Description
New setpoint	0	Does not assume ➔Target position
	0→1	Assume ➔Target position
Change set immediately	0	Finish actual positioning, then start next positioning. The actual positioning is considered as completed as soon as the position demand value reaches the target position.
	1	Abort actual positioning and start next positioning
Abs / rel	0	➔Target position is an absolute value
	1	➔Target position is a relative value
Halt	0	Execute or continue positioning
	1	Stop axis with ➔Profile deceleration
Endless movement	0	Normal operation mode
	1	System will perform endless movement

Table 3-15 Profile Position Mode – Controlword bits

OUTPUT PARAMETERS

Parameter	Index	Description
➔Statusword	0x6041	Mode state can be observed by the statusword bits
➔Position demand value	0x6062	The output of the trajectory generator. It is used as input for the position control function.

Table 3-16 Profile Position Mode – Output parameters

STATUSWORD (PROFILE POSITION MODE-SPECIFIC BITS)

Bit 15, 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9...0
→ Table 6-128	Following error	Setpoint acknowledge	→ Table 6-128	Target reached	→ Table 6-128

Table 3-17 Profile Position Mode – Statusword

Name	Value	Description
Target reached	0	Halt = 0: → Target position not reached Halt = 1: Axis decelerates
	1	Halt = 0: → Target position reached Halt = 1: Velocity of axis is “0” (zero)
Setpoint acknowledge	0	Positioning to the previous setpoint is ongoing and a new setpoint may be accepted
	1	The previous setpoint has been assumed and no additional setpoint may be accepted
Following error	0	Not following error
	1	Following error

Table 3-18 Profile Position Mode – Statusword bits




Figure 3-7 Profile Position Mode – Setpoint (example)

3.4 Profile Velocity Mode (PVM)

The operating mode is only available for «IDX CANopen» and «IDX EtherCAT».

The profile velocity mode includes a velocity trajectory generator and a velocity control function.



Annotation

Items marked with an asterisk (*) refer to internal values.




Figure 3-8 Profile Velocity Mode – Block diagram

3.4.1 Profile Velocity Trajectory Generator

The trajectory generator supports the following motion profiles.




Figure 3-9 Profile velocity trajectory – Linear ramp (trapezoidal profile)

3.4.2 How to use «PVM»

CONFIGURATION PARAMETERS

Parameter	Index	Description
→ Software position limit	0x607D	Contains the sub-parameters “Min position limit” and “Max position limit” that define the absolute position limits of the position demand value and position actual value. A new target position will be checked against these limits.
→ Max profile velocity	0x607F	Defines the maximal permitted speed
→ Max motor speed	0x6080	Indicates the configured maximal permitted speed for the motor. It serves as protection of the motor and is taken from the motor data sheet.
→ Max gear input speed	0x3003	Indicates the configured maximal permitted input speed of the gear. It serves as protection of the gear and is taken from the gear data sheet. Together with “Max motor speed”, it limits the speed of the system.
→ Quick stop deceleration	0x6085	Defines the deceleration ramp during a «Quick stop»
→ Max acceleration	0x60C5	Defines the maximal allowed acceleration and deceleration

Table 3-19 Profile Velocity Mode – Configuration parameters

COMMANDING PARAMETERS

Parameter	Index	Description
→ Controlword	0x6040	The mode will be controlled by a write access to the controlword's mode-dependent bits. A new target velocity is not assumed before the controlword is written.
→ Target velocity	0x60FF	The speed that the drive is supposed to reach
→ Profile acceleration	0x6083	Defines the acceleration ramp during a movement
→ Profile deceleration	0x6084	Defines the deceleration ramp during a movement
→ Motion profile type	0x6086	Selects the type of motion profile used for the movement: 0 = linear ramp (trapezoidal profile)

Table 3-20 Profile Velocity Mode – Commanding parameters

CONTROLWORD (PROFILE VELOCITY MODE-SPECIFIC BITS)

Bit 15...9	Bit 8	Bit 7	Bit 6...4	Bit 3...0
→ Table 6-127	Halt	→ Table 6-127	reserved	→ Table 6-127

Table 3-21 Profile Velocity Mode – Controlword

Name	Value	Description
Halt	0	Execute or continue motion
	1	Stop axis

Table 3-22 Profile Velocity Mode – Controlword bits

OUTPUT PARAMETERS

Parameter	Index	Description
→ Statusword	0x6041	Mode state can be observed by the statusword bits
→ Velocity demand value	0x606B	The output of the trajectory generator. It is used as input for the velocity control function.

Table 3-23 Profile Velocity Mode – Output parameters

STATUSWORD (PROFILE VELOCITY MODE-SPECIFIC BITS)

Bit 15, 14	Bit 13	Bit 12	Bit 11 (*2)	Bit 10	Bit 9...0
→ Table 6-128	Not used	Speed	Speed is limited	Target reached	→ Table 6-128

(*2) Bit 11 is shared with I2t current limitation feature

Table 3-24 Profile Velocity Mode – Statusword

Name	Value	Description
Target reached	0	Halt = 0: Target velocity not (yet) reached Halt = 1: Axis decelerates
	1	Halt = 0: Target velocity reached Halt = 1: Axis has velocity “0” (zero)
Speed	0	Speed is not equal “0” (zero)
	1	Speed is equal “0” (zero)
Speed is limited	0	Speed is not limited
	1	Speed is limited to → Max profile velocity

Table 3-25 Profile Velocity Mode – Statusword bits




Figure 3-10 Profile velocity trajectory – Setpoint and acceleration behavior (example)

3.5

Homing Mode (HMM)
The operating mode is only available for «IDX CANopen» and «IDX EtherCAT».

«Homing» describes the procedure according to which the drive seeks the home position (also called reference point or zero point). There are various methods to achieve this using limit switches at both ends of travel.



Annotation
Items marked with an asterisk (*) refer to internal values.




Figure 3-11 Homing Mode – Block diagram

3.5.1

Homing Trajectory Generator

The trajectory generator supports the following motion profiles. The movements are mode-dependent, the end positions will be calculated internally.




Figure 3-12 Homing trajectory – Linear ramp (trapezoidal profile)

3.5.2 How to use «HMM»

CONFIGURATION PARAMETERS

Parameter	Index	Description
➔ Digital input properties	0x3141	Input polarity and logic state
➔ Configuration of digital inputs	0x3142	Permits the configuration of digital inputs to digital input functionalities. Necessary for limit and homing switches that are used for «Homing».
➔ Digital inputs	0x3141	Input functionality state (after polarity correction)
➔ Motion profile type	0x6086	Selects the type of motion profile used for the movement: 0 = linear ramp (trapezoidal profile)

Table 3-26 Homing Mode – Configuration parameters

COMMANDING PARAMETERS

Parameter	Index	Description
➔ Controlword	0x6040	The mode will be controlled by a write access to the controlword's mode-dependent bits
➔ Homing method	0x6098	Defines the type of homing procedure. The object 0x60E3 provides the supported homing methods.
➔ Homing speeds	0x6099	Specifies the two speeds used for Homing: In a typical cycle, the faster speed is used to find the home switch and for the offset move, the slower speed is used to find the index pulse.
➔ Homing acceleration	0x609A	Specifies the acceleration during Homing
➔ Home offset move distance	0x30B1	The distance to move away from a detected position upon end of the homing sequence
➔ Home position	0x30B0	Allows to displace zero in the user's coordinate system
➔ Current threshold for homing mode	0x30B2	The current threshold for current index homing methods

Table 3-27 Homing Mode – Commanding parameters

CONTROLWORD (HOMING MODE-SPECIFIC BITS)

Bit 15...9	Bit 8	Bit 7	Bit 6, 5	Bit 4	Bit 3...0
➔ Table 6-127	Halt	➔ Table 6-127	reserved	Homing operation start	➔ Table 6-127

Table 3-28 Homing Mode – Controlword

Name	Value	Description
Homing operation start	0	Do not start homing procedure
	0→1	Start or continue homing procedure
Halt	0	Execute instruction of bit 4
	1	Stop axis with ➔ Homing acceleration

Table 3-29 Homing Mode – Controlword bits

OUTPUT PARAMETERS

Parameter	Index	Description
→ Statusword	0x6041	Mode state can be observed by the statusword bits

Table 3-30 Homing Mode – Output parameters

STATUSWORD (HOMING MODE-SPECIFIC BITS)

Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9...0
Position referenced to home position	→ Table 6-128	Homing error	Homing attained	→ Table 6-128	Target reached	→ Table 6-128

Table 3-31 Homing Mode – Statusword

Name	Value	Description
Bit 15 Position referenced to home position	0	The position is not referenced to the home position (for example homing not yet attained or position overflow)
	1	Homing was attained and the position is referenced to the home position

Table 3-32 Homing Mode – Statusword bit 15

Bit 13 Homing error	Bit 12 Homing attained	Bit 10 Target reached	Description
0	0	0	Homing procedure is in progress
0	0	1	Homing procedure is interrupted or not started
0	1	X	Homing procedure is completed successfully
1	0	X	Homing error occurred

Table 3-33 Homing Mode – Statusword bits 10, 12, and 13

3.5.3 Homing Methods

The index used for homing can be either a hardware index impulse (incremental encoder) or a virtual index (SSI sensor).

3.5.3.1 Homing Method 1 (Negative Limit Switch & Index)

The initial direction of the movement is negative (here to the left) if the negative limit switch is inactive (here shown as low).

- The axis moves with →Speed for switch search to the positive edge of the limit switch (1).
- The axis moves with →Speed for zero search to the negative edge of the limit switch and further to the first encoder index pulse after the negative edge of the limit switch (2).
- The axis moves the →Home offset move distance (3) in positive direction with →Speed for switch search. This point will be used as reference for all further moves and is set to →Home position (4).




Figure 3-13 Homing method 1

3.5.3.2 Homing Method 2 (Positive Limit Switch & Index)

The initial direction of the movement is positive (here to the right) if the positive limit switch is inactive (here shown as low).

- The axis moves with →Speed for switch search to the positive edge of the limit switch (1).
- The axis moves with →Speed for zero search to the negative edge of the limit switch and further to the first encoder index pulse after the negative edge of the limit switch (2).
- The axis moves the →Home offset move distance (3) in negative direction with →Speed for switch search. This point will be used as reference for all further moves and is set to →Home position (4).




Figure 3-14 Homing method 2

3.5.3.3 Homing Method 7 (Home Switch Positive Speed & Index)

The method uses a home switch, which is active only during part of the movement. In effect, the switch acts as the position of the axis sweeps past the switch. The initial direction of the movement is positive (here to the right) except when the home switch is already active upon start of the movement.

- The axis moves with →Speed for switch search to the positive edge of the limit switch (1).
- The axis moves with →Speed for zero search to the encoder index pulse (2).
- The axis moves the →Home offset move distance (3) with →Speed for switch search. This point will be used as reference for all further moves and is set to →Home position (4).




Figure 3-15 Homing method 7

3.5.3.4 Homing Method 11 (Home Switch Negative Speed & Index)

The method uses a home switch, which is active only during part of the movement. In effect, the switch acts as the position of the axis sweeps past the switch. The initial direction of the movement is negative (here to the left) except when the home switch is already active upon start of the movement.

- The axis moves with →Speed for switch search to the positive edge of the limit switch (1).
- The axis moves with →Speed for zero search to the encoder index pulse (2).
- The axis moves the →Home offset move distance (3) with →Speed for switch search. This point will be used as reference for all further moves and is set to →Home position (4).




Figure 3-16 Homing method 11

3.5.3.5 Homing Method 17 (Negative Limit Switch)

The principle is similar to homing method 1 except that the →Home position is not dependent on the index pulse but only on the negative edge of the negative limit switch.




Figure 3-17 Homing method 17

3.5.3.6 Homing Method 18 (Positive Limit Switch)

The principle is similar to homing method 2 except that the →Home position is not dependent on the index pulse but only on the negative edge of the positive limit switch.



Figure 3-18 Homing method 18

3.5.3.7 Homing Method 23 (Home Switch Positive Speed)

The principle is similar to homing method 7 except that the →Home position is not dependent on the index pulse but only on the rising edge of the home switch.




Figure 3-19 Homing method 23

3.5.3.8 Homing Method 27 (Home Switch Negative Speed)

The principle is similar to homing method 11 except that the →Home position is not dependent on the index pulse but only on the falling edge of the home switch.




Figure 3-20 Homing method 27

3.5.3.9 Homing Method 33 (Index Negative Speed)

The direction for homing is negative (here to the left).

- The axis moves with →Speed for switch search to the next encoder index pulse (33).
- The axis moves the →Home offset move distance (2) with →Speed for switch search. This point will be used as reference for all further moves and is set to →Home position (4).




Figure 3-21 Homing method 33

3.5.3.10 Homing Method 34 (Index Positive Speed)

The direction for homing is positive (here to the right).

- The axis moves with →Speed for switch search to the next encoder index pulse (34).
- The axis moves the →Home offset move distance (2) with →Speed for switch search. This point will be used as reference for all further moves and is set to →Home position (4).




Figure 3-22 Homing method 34

3.5.3.11 Homing Method 37 (Actual Position)

The actual position is changed and considered as the future →Home position.

If the operation is disabled, the →Home position (1) will be taken immediately as reference for further moves.




Figure 3-23 Homing method 37 (disabled)

If the operation is enabled, the axis will move first with the defined →Home offset move distance (1) and consider then this point as reference for further moves and is set to →Home position (2).




Figure 3-24 Homing method 37 (enabled)

3.5.3.12 Homing Method -1 (Current Threshold Positive Speed & Index)

The method uses a mechanical end stop on the right (positive) side. The edge is detected when the averaged output current rises above →Current threshold for homing mode.

- The axis moves with →Speed for switch search to the mechanical end stop (1).
- The axis moves with →Speed for zero search to the next encoder index pulse (2).
- The axis moves the →Home offset move distance (3) with →Speed for switch search. This point will be used as reference for all further moves and is set to →Home position (4).




Figure 3-25 Homing method -1

3.5.3.13 Homing Method -2 (Current Threshold Negative Speed & Index)

The method uses a mechanical end stop on the left (negative) side. The edge is detected when the averaged output current rises above →Current threshold for homing mode.

- The axis moves with →Speed for switch search to the mechanical end stop (1).
- The axis moves with →Speed for zero search to the next encoder index pulse (2).
- The axis moves the →Home offset move distance (3) with →Speed for switch search. This point will be used as reference for all further moves and is set to →Home position (4).




Figure 3-26 Homing method -2

3.5.3.14 Homing Method -3 (Current Threshold Positive Speed)

The principle is similar to homing method -1 except that the →Home position is not dependent on the index pulse but only on the mechanical end stop.




Figure 3-27 Homing method -3

3.5.3.15 Homing Method -4 (Current Threshold Negative Speed)

The principle is similar to homing method -2 except that the →Home position is not dependent on the index pulse but only on the mechanical end stop.




Figure 3-28 Homing method -4

3.6 Cyclic Synchronous Position Mode (CSP)

The operating mode is only available for «IDX CANopen» and «IDX EtherCAT».

With Cyclic Synchronous Position Mode, the trajectory generator is located in the control device (not in the drive device). It provides a target position to the drive device in cyclic synchronous manner, thus the drive performing position control and torque control.




Figure 3-29 Cyclic Synchronous Position Mode – Overview

Cyclic Synchronous Position Mode is based on a position control function. The inputs are →Target position and (optionally) →Position offset. A linear interpolation based on the →Interpolation time period is executed between two position values. This interpolation is active for PDO communication only. The →Velocity offset is not taken into account.

Furthermore, an optional torque offset is being used for feed forward control. The input →Motor data is used to define limitations for the current value (torque). Other features specified in this mode are the function →Software position limit (used to restrict the range of values to avoid unintended positions) as well as →Max motor speed and →Max gear input speed (to limit and monitor the following error). Actual values for position, velocity, and torque are used as output to the control device.

Continued on next page.




Figure 3-30 Cyclic Synchronous Position Mode – Block diagram

3.6.1 How to use «CSP»

CONFIGURATION PARAMETERS

Parameter	Index	Description
Nominal current (→Motor data)	0x3001	The maximal permissible continuous current of the motor
Motor torque constant (→Motor data)	0x3001	The torque constant of the motor
→Current control parameter set	0x30A0	Configuration of the current controller gains
→Position control parameter set	0x30A1	Configuration of the position controller.
→Quick stop deceleration	0x6085	Defines the deceleration for the quick stop ramp (*3)
→Profile deceleration	0x6084	Defines the deceleration for the slowdown ramp (*3)
→Following error window	0x6065	The maximal allowed difference of position actual value to position demand value. If exceeded, following error is generated.
→Software position limit	0x607D	Used to restrict the absolute position range. If the target position or the actual position exceeds the range, a software position limit error is generated.
→Motor rated torque	0x6076	Holds the value to which all torque objects are related to
→Max motor speed	0x6080	Indicates the configured maximal permitted speed for the motor. It serves as protection of the motor and is taken from the motor data sheet (active during PDO communication only).
→Max gear input speed	0x3003	Indicates the configured maximal permitted input speed of the gear. It serves as protection of the gear and is taken from the gear data sheet. Together with "Max motor speed", it limits the speed of the system (active during PDO communication only).
→Interpolation time period	0x60C2	Defines the time interval

(*3) Deceleration values are used for stopping only (and not for normal operation).

Table 3-34 Cyclic Synchronous Position Mode – Configuration parameters

COMMANDING PARAMETERS

Parameter	Index	Description
→Target position	0x607A	Position input value for the position controller (linear interpolation between PDO values)
→Position offset	0x60B0	Optional additive position value which is added to the target position (linear interpolation between PDO values)
→Torque offset	0x60B2	Optional torque feed forward input

Table 3-35 Cyclic Synchronous Position Mode – Commanding parameters

CONTROLWORD

Cyclic Synchronous Position Mode does not use mode-specific controlword bits.

OUTPUT PARAMETERS

Parameter	Index	Description
→ Torque actual value	0x6077	Actual motor torque value
→ Velocity actual value	0x606C	Actual velocity value [velocity units]
→ Position actual value	0x6064	Actual position is absolute and referenced to system zero position

Table 3-36 Cyclic Synchronous Position Mode – Output parameters

STATUSWORD (CYCLIC SYNCHRONOUS POSITION MODE-SPECIFIC BITS)

Bit 15, 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9...0
→ Table 6-128	following error	drive follows command value	→ Table 6-128	reserved	→ Table 6-128

Table 3-37 Cyclic Synchronous Position Mode – Statusword

Name	Value	Description
drive follows command value	0	Drive does not follow the target value
	1	Drive is in state operation enables and follows the target and setpoint values of the control device
following error	0	No following error
	1	Difference of position demand value and position actual value exceeds the defined maximal following error

Table 3-38 Cyclic Synchronous Position Mode – Statusword bits

3.7 Cyclic Synchronous Velocity Mode (CSV)

With Cyclic Synchronous Velocity Mode, the trajectory generator is located in the control device (not in the drive device). It provides a target velocity to the drive device in cyclic synchronous manner, thus the drive velocity control and torque control.




Figure 3-31 Cyclic Synchronous Velocity Mode – Overview

Cyclic Synchronous Velocity Mode is based on velocity control function. The input is →Target velocity. Optionally, additive velocity values may be provided by the control system in order to allow a second source for velocity feed forward control. A linear interpolation based on the →Interpolation time period is executed between two velocity values. This interpolation is active for PDO communication only.

The input →Motor data is used to define limitations for velocity and current values. Actual values for position, velocity, and torque are used as output to the control device.




Figure 3-32 Cyclic Synchronous Velocity Mode – Block diagram

3.7.1 How to use «CSV»

CONFIGURATION PARAMETERS

Parameter	Index	Description
Nominal current (→Motor data)	0x3001	The maximal permissible continuous current of the motor
Motor torque constant (→Motor data)	0x3001	The torque constant of the motor
→Current control parameter set	0x30A0	Configuration of the current controller gains
→Velocity control parameter set	0x30A2	Configuration of the velocity controller
→Quick stop deceleration	0x6085	Defines the deceleration for the quick stop ramp (*3)
→Profile deceleration	0x6084	Defines the deceleration for the slowdown ramp (*3)
→Software position limit	0x607D	Used to restrict the absolute position range. If the actual position exceeds the range, a software position limit error is generated.
→Motor rated torque	0x6076	Holds the value to which all torque objects are related to
→Max motor speed	0x6080	Indicates the configured maximal permitted speed for the motor. It serves as protection of the motor and is taken from the motor data sheet (active during PDO communication only).
→Max gear input speed	0x3003	Indicates the configured maximal permitted input speed of the gear. It serves as protection of the gear and is taken from the gear data sheet. Together with "Max motor speed", it limits the speed of the system (active during PDO communication only).
→Interpolation time period	0x60C2	Defines the time interval

(*3) Deceleration values are used for stopping only (and not for normal operation).

Table 3-39 Cyclic Synchronous Velocity Mode – Configuration parameters

COMMANDING PARAMETERS

Parameter	Index	Description
→Target velocity	0x60FF	Velocity input value for the velocity controller
→Velocity offset	0x60B1	Optional velocity feed forward input
→Torque offset	0x60B2	Optional torque feed forward input

Table 3-40 Cyclic Synchronous Velocity Mode – Commanding parameters

CONTROLWORD

Cyclic Synchronous Velocity Mode does not use mode-specific controlword bits.

OUTPUT PARAMETERS

Parameter	Index	Description
→Torque actual value	0x6077	Actual motor torque value
→Velocity actual value	0x606C	Actual velocity value [velocity units]
→Position actual value	0x6064	Actual position is absolute and referenced to system zero position

Table 3-41 Cyclic Synchronous Velocity Mode – Output parameters

STATUSWORD (CYCLIC SYNCHRONOUS VELOCITY MODE-SPECIFIC BITS)

Bit 15, 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9...0
→ Table 6-128	reserved	drive follows command value	→ Table 6-128	reserved	→ Table 6-128

Table 3-42 Cyclic Synchronous Velocity Mode – Statusword

Name	Value	Description
drive follows command value	0	Drive does not follow the target value
	1	Drive is in state operation enables and follows the target and setpoint values of the control device

Table 3-43 Cyclic Synchronous Velocity Mode – Statusword bits

3.8 Cyclic Synchronous Torque Mode (CST)

With Cyclic Synchronous Torque Mode, the trajectory generator is located in the control device (not in the drive device). It provides a target torque to the drive device in cyclic synchronous manner, thus the drive performing torque control.




Figure 3-33 Cyclic Synchronous Torque Mode – Overview

Cyclic Synchronous Torque Mode is based on the current control function. The inputs are →Target torque and (optionally) →Torque offset. The input →Motor data is used to define limitations for velocity and current values. Actual values for position, velocity, and torque are used as output to the control device.




Figure 3-34 Cyclic Synchronous Torque Mode – Block diagram

3.8.1 How to use «CST»

CONFIGURATION PARAMETERS

Parameter	Index	Description
Nominal current (→Motor data)	0x3001	The maximal permissible continuous current of the motor
Motor torque constant (→Motor data)	0x3001	The torque constant of the motor
→Max motor speed	0x6080	Indicates the configured maximal allowed speed for the motor. It serves as protection of the motor and is taken from the motor data sheet.
→Max gear input speed	0x3003	Indicates the configured maximal permitted input speed of the gear. It serves as protection of the gear and is taken from the gear data sheet. Together with "Max motor speed", it limits the speed of the system.
→Current control parameter set	0x30A0	Configuration of the current controller gains
→Quick stop deceleration	0x6085	Defines the deceleration for the quick stop ramp (*4)
→Profile deceleration	0x6084	Defines the deceleration for the slowdown ramp (*4)
→Motor rated torque	0x6076	Holds the value to which all torque objects are related to
→Software position limit	0x607D	Contains the sub-parameters "Min position limit" and "Max position limit" that define the absolute position limits of the position demand value and position actual value. A new target position will be checked against these limits.

(*4) Deceleration values are used for stopping only (and not for normal operation).

Table 3-44 Cyclic Synchronous Torque Mode – Configuration parameters

COMMANDING PARAMETERS

Parameter	Index	Description
→Target torque	0x6071	Torque input value for the torque controller
→Torque offset	0x60B2	Optional additive torque which is added to the target torque value

Table 3-45 Cyclic Synchronous Torque Mode – Commanding parameters

CONTROLWORD

Cyclic Synchronous Torque Mode does not use mode-specific controlword bits.

OUTPUT PARAMETERS

Parameter	Index	Description
→Torque actual value	0x6077	Actual motor torque value
→Velocity actual value	0x606C	Actual velocity value
→Position actual value	0x6064	Actual position is absolute and referenced to system zero position

Table 3-46 Cyclic Synchronous Torque Mode – Output parameters

STATUSWORD (CYCLIC SYNCHRONOUS TORQUE MODE-SPECIFIC BITS)

Bit 15, 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9...0
→Table 6-128	reserved	drive follows command value	→Table 6-128	reserved	→Table 6-128

Table 3-47 Cyclic Synchronous Torque Mode – Statusword

Name	Value	Description
drive follows command value	0	Drive does not follow the target value
	1	Drive is in state operation enables and follows the target and setpoint values of the control device

Table 3-48 Cyclic Synchronous Torque Mode – Statusword bits

3.9 Position Control Function

Used for position-based modes, such as «Profile Position Mode» and «Homing Mode».

The control loop is fed with the «Position demand value» and «Position actual value» (the output of the position detection unit) like an encoder as input parameter. The behavior of the control may be influenced by externally applicable control parameters (Position Control Parameter Set). The output of the controller is a current demand value, which serves as input for the current controller.



Annotation

Items marked with an asterisk (*) refer to internal values.




Figure 3-35 Position Control Function – Block diagram

3.9.1 How to use «Position Control Function»

CONFIGURATION PARAMETERS

Parameter	Index	Description
➔ Following error window	0x6065	Defines the following error window. If the difference between Position Actual Value and Position Demand Value is larger than the following error window, a following error will occur.
➔ Position control parameter set	0x30A1	Configuration of the position controller. The parameters are defined by the controller properties bandwidth, reset time, and damping factor.

Table 3-49 Position Control Function – Configuration parameters

COMMANDING PARAMETERS

There are no commanding parameters. The Position Control Function is directly commanded by position-based operating modes (such as Profile Position Mode, Homing Mode).

OUTPUT PARAMETERS

Parameter	Index	Description
➔Position demand value	0x6062	The operation mode's output. It is used as input for the position control function. Generally, the value is the trajectory generator output.
➔Position actual value	0x6064	The actual position is absolute and referenced to system zero position in position units.

Table 3-50 Position Control Function – Output parameters

3.10 Velocity Control Function

Used for velocity-based modes, such as «Profile Velocity Mode».

The control loop is fed with the «Velocity demand value» and «Position actual value» (the output of the position detection unit) like an encoder as input parameter. The behavior of the control may be influenced by externally applicable control parameters. The output of the controller is a current demand value, which serves as input for the current controller.



Annotation

Items marked with an asterisk (*) refer to internal values.




Figure 3-36 Velocity Control Function – Block diagram

3.10.1 How to use «Velocity Control Function»

CONFIGURATION PARAMETERS

Parameter	Index	Description
→ Velocity control parameter set	0x30A2	Configuration of the velocity controller gains

Table 3-51 Velocity Control Function – Configuration parameters

COMMANDING PARAMETERS

There are no commanding parameters. The Velocity Control Function is directly commanded by velocity-based operating modes (such as Profile Velocity Mode).

OUTPUT PARAMETERS

Parameter	Index	Description
➔Velocity demand value	0x606B	The operation mode's output. It is used as input for the velocity control function. Generally, the value is the output of the trajectory generator.
➔Velocity actual value	0x606C	The actual velocity value
➔Velocity actual value averaged	0x30D3	The averaged actual velocity value

Table 3-52 Velocity Control Function – Output Parameters

3.11 Current Control Function

All operating modes are based on the current control function. The «Current demand value» is received from a super-ordinate position or the velocity controller.



Annotation
Items marked with an asterisk (*) refer to internal values.




Figure 3-37 Current Control Function – Block diagram

3.11.1 How to use «Current Control Function»

CONFIGURATION PARAMETERS

Parameter	Index	Description
➔Current control parameter set	0x30A0	Configuration of the current controller gains
➔Motor data	0x3001	Used for configuration of motor-dependent parameters
➔Motor type	0x6402	Used to define the type of motor

Table 3-53 Current Control Function – Configuration parameters

COMMANDING PARAMETERS

There are no commanding parameters. The Current Control Function is commanded by the control loops «Position control function» or «Velocity control function», or directly by operating mode «Cyclic Synchronous Torque Mode».

OUTPUT PARAMETERS

Parameter	Index	Description
➔Current demand value	0x30D0	Set value for current controller
➔Current actual values	0x30D1	The averaged and actual current value

Table 3-54 Current Control Function – Output parameters

4 INPUTS AND OUTPUTS

4.1 Digital Inputs

Available are predefined functions and general purpose inputs for process control.

Configuration of the digital input functions is done with →“Configuration of digital inputs” on page 6-162, the polarity is set with →“Digital input properties” on page 6-161.

The input logic state is read with →“Digital input properties” on page 6-161 while the functionality state is read with →“Digital inputs” on page 6-219.

With «IDX I/O», the functionality of Bit 26, 25, 24, and 2 are not available.




Figure 4-38 Digital input functionality

DIGITAL INPUT TIMING BEHAVIOR

- **Hardware**For details on voltage levels and switching delays see separate document →«Hardware Reference» of respective controller.
- **Software filter**The digital inputs are filtered to suppress spikes. For digital inputs, the filter has a length of 1 ms. Therefore, to detect a state change (edge), the input level must be stable for more than 1 ms.
- **Update rates**The digital input functionality states (→Digital inputs) and the →Digital input properties are updated with 1 kHz.

4.2 Digital Outputs

Available are predefined functions and general purpose outputs for process control.

Configuration of the digital output functions is done with → “Configuration of digital outputs” on page 6-165, the polarity is set with → “Digital output properties” on page 6-164.

The functionality state can be set with → “Digital outputs” on page 6-220, the logic state of the corresponding pin can be read with → “Digital output properties” on page 6-164.

With factory-equipped internal brake, the functionality of Bit 24 is not available.




Figure 4-39 Digital output functionality

DIGITAL OUTPUT TIMING BEHAVIOR

- **Hardware** For details on voltage levels and switching delays see separate document → «Hardware Reference» of respective controller.
- **Update rates** Digital outputs (→ Digital outputs) are updated when the object is written, no update rate applies. The same applies for the logic state (→ Digital output properties).

4.3 Analog Inputs

The analog inputs may be used for general purpose process values, such as temperature, pressure, torque from an external sensor, etc. The values are given in →“Analog input properties” on page 6-168.




Figure 4-40 Analog input functionality

••page intentionally left blank••

5 COMMUNICATION

The device supports communication profiles for USB, CANopen, and EtherCAT. You can find detailed information on the subject in the separate document → «IDX Communication Guide». For sources of supply see → Chapter “1.1.6 Sources for additional Information” on page 1-10.

5.1 USB Communication

The device's USB interface follows the «Universal Serial Bus Specification Revision 2.0».

The device always communicates as a slave and uses the «maxon Serial V2» protocol.

5.2 CAN Communication

The «IDX CANopen» communication follows the CiA CANopen specifications:

- CiA 301 V4.2; CANopen application layer and communication profile
- CiA 306 V1.3; CANopen electronic data sheet specification
- CiA 402 V4.0; CANopen drives and motion control device profile



Find details here:

→ «IDX Communication Guide», chapter “3 CAN Communication”

5.3 EtherCAT Communication

The «IDX EtherCAT» communication follows the EtherCAT Technology Group's and CiA CANopen specifications:

- ETG.1000 V1.0.4; EtherCAT Specification
- ETG.1020 V1.2.0; EtherCAT Protocol Enhancements Specification
- ETG.2000 V1.0.9; EtherCAT Slave Information (ESI) Specification
- CiA 402 V4.0; CANopen drives and motion control device profile



Find details here:

→ «IDX Communication Guide», chapter “4 EtherCAT Communication”

5.4 Gateway Communication (USB to CAN)

The «IDX CANopen» provides a USB-to-CAN gateway that permits the master to access all other «IDX CANopen» connected to the CAN bus via USB port. In addition, other CANopen devices (I/O modules) that support the CANopen standard CiA 301 may also be accessed.

••page intentionally left blank••

6 OBJECT DICTIONARY

6.1 Overview

6.1.1 Object Data Types

Index	Name	Base type	Description	Size [Bits]	Range
0x0001	BOOLEAN	BOOL	False/True	1	0.1
0x0002	INTEGER8	SINT	Short Integer	8	$-2^7 \dots 2^7 - 1$
0x0003	INTEGER16	INT	Integer	16	$-2^{15} \dots 2^{15} - 1$
0x0004	INTEGER32	DINT	Double Integer	32	$-2^{31} \dots 2^{31} - 1$
0x0015	INTEGER64	LINT	Long Integer	64	$-2^{63} \dots 2^{63} - 1$
0x0005	UNSIGNED8	USINT	Unsigned Short Integer	8	$0 \dots 2^8 - 1$
0x0006	UNSIGNED16	UINT	Unsigned Integer	16	$0 \dots 2^{16} - 1$
0x0007	UNSIGNED32	UDINT	Unsigned Double Integer	32	$0 \dots 2^{32} - 1$
0x001B	UNSIGNED64	ULINT	Unsigned Long Integer	64	$0 \dots 2^{64} - 1$
0x0009	VISIBLE_STRING	STRING(n)	Visible String (1 octet per character)	8*n	–
0x000A	OCTET_STRING	ARRAY[0...n] of USINT	Sequence of octets (data type USINT)	8*(n+1)	–
0x0021	PDO_MAPPING	–	PDO mapping Parameter Record	–	–
0x0023	IDENTITY	–	Identity Parameter Record	–	–

Table 6-55 Object data types

6.1.2 Object Codes

Object code	Object name
0x0007	VAR
0x0008	ARRAY
0x0009	RECORD

Table 6-56 Object codes

6.1.3 Object Access Types

Access type	Description
RW	read and write access
RO	read only access
WO	write only access
CONST	read only access value is constant

Table 6-57 Object access types

6.1.4 Object Flags

Flag	Code	Description
PDO mapping	TXPDO, RXPDO	Entry can be mapped as TxPdo or as RxPdo
Backup	YES/NO	Entry can be stored/not stored in non-volatile memory

Table 6-58 Object flags

6.1.5 Entries Overview

Index	Name	Object code	CANopen	EtherCAT	I/O
0x1000	→Device type	VAR	X	X	X
0x1001	→Error register	VAR	X	X	X
0x1003	→Error history	ARRAY	X		X
0x1005	→COB-ID SYNC	VAR	X		
0x1008	→Manufacturer device name	VAR	X	X	X
0x1010	→Store parameters	ARRAY	X	X	X
0x1011	→Restore default parameters	ARRAY	X	X	X
0x1014	→COB-ID EMCY	VAR	X		
0x1016	→Consumer heartbeat time	ARRAY	X		
0x1017	→Producer heartbeat time	VAR	X		
0x1018	→Identity object	RECORD	X	X	X
0x1029	→Error behavior	ARRAY	X		
0x10F3	→Diagnosis History	RECORD		X	
0x1200	→SDO server parameter	RECORD	X		
0x1400	→Receive PDO 1 parameter	RECORD	X		
0x1401	→Receive PDO 2 parameter	RECORD	X		
0x1402	→Receive PDO 3 parameter	RECORD	X		
0x1403	→Receive PDO 4 parameter	RECORD	X		
0x1600	→Receive PDO 1 mapping	RECORD	X	X	
0x1601	→Receive PDO 2 mapping	RECORD	X	X	
0x1602	→Receive PDO 3 mapping	RECORD	X	X	
0x1603	→Receive PDO 4 mapping	RECORD	X	X	
0x1800	→Transmit PDO 1 parameter	RECORD	X		
0x1801	→Transmit PDO 2 parameter	RECORD	X		
0x1802	→Transmit PDO 3 parameter	RECORD	X		
0x1803	→Transmit PDO 4 parameter	RECORD	X		
0x1A00	→Transmit PDO 1 mapping	RECORD	X	X	
0x1A01	→Transmit PDO 2 mapping	RECORD	X	X	
0x1A02	→Transmit PDO 3 mapping	RECORD	X	X	
0x1A03	→Transmit PDO 4 mapping	RECORD	X	X	
0x1C00	→SYNC manager communication type	ARRAY		X	
0x1C12	→SYNC manager 2 PDO assignment	ARRAY		X	

Continued on next page.

Index	Name	Object code	CANopen	EtherCAT	I/O
0x1C13	→SYNC manager 3 PDO assignment	ARRAY		X	
0x1C32	→SYNC manager 2 parameter	RECORD		X	
0x1C33	→SYNC manager 3 parameter	RECORD		X	
0x1F50	→Program data	ARRAY	X	X	X
0x1F51	→Program control	ARRAY	X	X	X
0x1F56	→Program software identification	ARRAY	X	X	X
0x1F57	→Flash status identification	ARRAY	X	X	X
0x2000	→Node-ID	VAR	X	X	X
0x2001	→CAN bit rate	VAR	X		
0x2006	→USB frame timeout	VAR	X	X	X
0x200A	→CAN bit rate display	VAR	X		
0x2010	→Active fieldbus	VAR	X	X	X
0x2011	→Active controller type	VAR	X	X	X
0x2100	→Additional identity	RECORD	X	X	X
0x2101	→Extension 1 identity	RECORD		X	
0x210C	→Custom persistent memory	ARRAY	X	X	
0x2200	→Power supply	RECORD	X	X	X
0x2201	→Power supply supervision	RECORD	X	X	X
0x3000	→Axis configuration	RECORD	X	X	X
0x3001	→Motor data	RECORD	X	X	X
0x3002	→Electrical system parameters	RECORD	X	X	X
0x3003	→Gear configuration	RECORD	X	X	X
0x3012	→SSI absolute encoder	RECORD	X	X	X
0x30A0	→Current control parameter set	RECORD	X	X	X
0x30A1	→Position control parameter set	RECORD	X	X	
0x30A2	→Velocity control parameter set	RECORD	X	X	X
0x30A3	→Velocity observer parameter set	RECORD	X	X	X
0x30B0	→Home position	VAR	X	X	X
0x30B1	→Home offset move distance	VAR	X	X	
0x30B2	→Current threshold for homing mode	VAR	X	X	
0x30D0	→Current demand value	VAR	X	X	X
0x30D1	→Current actual values	ARRAY	X	X	X
0x30D2	→Torque actual values	ARRAY	X	X	X
0x30D3	→Velocity actual values	ARRAY	X	X	X
0x30E0	→Standstill window configuration	RECORD	X	X	X
0x3141	→Digital input properties	ARRAY	X	X	X
0x3142	→Configuration of digital inputs	ARRAY	X	X	X
0x3150	→Digital output properties	ARRAY	X	X	X
0x3151	→Configuration of digital outputs	ARRAY	X	X	X
0x3158	→Holding brake parameters	RECORD	X	X	X
0x3160	→Analog input properties	ARRAY	X	X	X

Continued on next page.

Index	Name	Object code	CANopen	EtherCAT	I/O
0x3161	→ Configuration of analog inputs	ARRAY	X	X	X
0x3162	→ Analog input general purpose	ARRAY	X	X	X
0x3163	→ Analog input adjustment	RECORD	X	X	X
0x3170	→ Analog input current set value properties	ARRAY	X	X	X
0x3171	→ Analog input velocity set value properties	ARRAY	X	X	X
0x3200	→ Power limitation	RECORD	X	X	X
0x3201	→ Thermal overload protection	RECORD	X	X	X
0x3203	→ Motor control	RECORD	X	X	X
0x6007	→ Abort connection option code	VAR	X	X	X
0x603F	→ Error code	VAR	X	X	X
0x6040	→ Controlword	VAR	X	X	X
0x6041	→ Statusword	VAR	X	X	X
0x605A	→ Quick stop option code	VAR	X	X	X
0x605B	→ Shutdown option code	VAR	X	X	X
0x605C	→ Disable operation option code	VAR	X	X	X
0x605D	→ Halt option code	VAR	X	X	X
0x605E	→ Fault reaction option code	VAR	X	X	X
0x6060	→ Modes of operation	VAR	X	X	X
0x6061	→ Modes of operation display	VAR	X	X	X
0x6062	→ Position demand value	VAR	X	X	
0x6064	→ Position actual value	VAR	X	X	X
0x6065	→ Following error window	VAR	X	X	
0x6066	→ Following error time out	VAR	X	X	
0x6067	→ Position window	VAR	X	X	
0x6068	→ Position window time	VAR	X	X	
0x606B	→ Velocity demand value	VAR	X	X	X
0x606C	→ Velocity actual value	VAR	X	X	X
0x6071	→ Target torque	VAR	X	X	X
0x6076	→ Motor rated torque	VAR	X	X	X
0x6077	→ Torque actual value	VAR	X	X	X
0x607A	→ Target position	VAR	X	X	
0x607B	→ Position range limit	ARRAY	X	X	
0x607C	→ Home offset	VAR	X	X	
0x607D	→ Software position limit	ARRAY	X	X	
0x607F	→ Max profile velocity	VAR	X	X	X
0x6080	→ Max motor speed	VAR	X	X	X
0x6081	→ Profile velocity	VAR	X	X	
0x6083	→ Profile acceleration	VAR	X	X	X
0x6084	→ Profile deceleration	VAR	X	X	X
0x6085	→ Quick stop deceleration	VAR	X	X	X
0x6086	→ Motion profile type	VAR	X	X	

Continued on next page.

Index	Name	Object code	CANopen	EtherCAT	I/O
0x6098	→Homing method	VAR	X	X	
0x6099	→Homing speeds	ARRAY	X	X	
0x609A	→Homing acceleration	VAR	X	X	
0x60A8	→SI unit position	VAR	X	X	X
0x60A9	→SI unit velocity	VAR	X	X	X
0x60AA	→SI unit acceleration	VAR	X	X	X
0x60B0	→Position offset	VAR	X	X	
0x60B1	→Velocity offset	VAR	X	X	X
0x60B2	→Torque offset	VAR	X	X	X
0x60B8	→Touch probe function	VAR	X	X	
0x60B9	→Touch probe status	VAR	X	X	
0x60BA	→Touch probe 1 positive edge	VAR	X	X	
0x60BB	→Touch probe 1 negative edge	VAR	X	X	
0x60C2	→Interpolation time period	RECORD	X	X	
0x60C5	→Max acceleration	VAR	X	X	X
0x60D0	→Touch probe source	ARRAY	X	X	
0x60D5	→Touch probe 1 positive edge counter	VAR	X	X	
0x60D6	→Touch probe 1 negative edge counter	VAR	X	X	
0x60E3	→Supported homing methods	ARRAY	X	X	
0x60F4	→Following error actual value	VAR	X	X	
0x60FD	→Digital inputs	VAR	X	X	X
0x60FE	→Digital outputs	ARRAY	X	X	X
0x60FF	→Target velocity	VAR	X	X	X
0x6402	→Motor type	VAR	X	X	X
0x6502	→Supported drive modes	VAR	X	X	X
0xF000	→Modular device profile	RECORD		X	
0xF030	→Configured module ident list	ARRAY		X	
0xF050	→Detected module ident list	ARRAY		X	

Table 6-59 Object Dictionary (overview)

6.2 Objects



Annotation
Items marked with an asterisk () refer to internal values.*

6.2.1 Device type

Describes the device type. The lower word stands for the supported device profile number. The value 0x0192 (402) means that the device follows CiA 402 “CANopen device profile for drives and motion control”. The higher word holds information on the drive type. The value 0x0002 means that the drive is a servo drive.

Name	Device type	
Index	0x1000	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RO	
Default value	0x00020192	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.2 Error register

The error register for the device. The device maps internal errors in this byte.

Name	Error register	
Index	0x1001	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RO	
Default value	0	
Value range	–	–
PDO mapping	NO	
Backup	NO	

Bit	Description
7	Motion error
6	reserved (always 0)
5	Device profile-specific
4	Communication error
3	Temperature error
2	Voltage error
1	Current error
0	Generic error

Table 6-60 Error register bits

6.2.3 Error history

The object is only available for «IDX CANopen» and «IDX I/O».

Holds errors that have occurred on the device and have been signaled via the emergency object.

Name	Error history
Index	0x1003
Object code	ARRAY
Highest subindex supported	5

6.2.3.1 Number of errors

Contains the number of actual errors that are recorded in the array starting at subindex 1. Writing a “0” (zero) deletes the error history (empties the array). Values higher than “0” (zero) are not allowed to write.

Name	Number of errors	
Index	0x1003	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	0	
Value range	0	5
PDO mapping	NO	
Backup	NO	

6.2.3.2 Error history

Every new error code is stored at subindex 1, the older ones move down the list. The error numbers compose of a 16-bit error code and 16-bit additional error information on higher word.

Errors without a device state change are marked with 0x8000 (bit31) in additional error information.

Names	Error history 1 Error history 2 Error history 3 Error history 4 Error history 5	
Index	0x1003	
Subindex	0x01...0x05	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

BYTE	Value	Description
31	0	Error
	1	Warning only (without effect on device states)
30...16	0	Reserved
15...0	Error code	Device error code

Table 6-61 Error history structure

6.2.4 COB-ID SYNC

The object is only available for «IDX CANopen».

The Communication Object Identifier of the synchronization object.

Name	COB-ID SYNC	
Index	0x1005	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	0x00000080	
Value range	0x00000080	0x00000080
PDO mapping	NO	
Backup	NO	

6.2.5 *Manufacturer device name*

Holds the manufacturer device name.

Name	Manufacturer device name		
Index	0x1008		
Subindex	0x00		
Data type	VISIBLE_STRING		
Access type	RO		
Default value	IDX		
Value range	–		–
PDO mapping	NO		
Backup	NO		

6.2.6 *Store parameters*

Controls saving of configuration parameters in a non-volatile memory.

Name	Store parameters		
Index	0x1010		
Object code	ARRAY		
Highest subindex supported	1		

In order to avoid storage of parameters by mistake, storage should only be executed when a specific signature is written to the respective subindex.

On read access, the device will always return the value 0x00000001.

BYTE	MSB			LSB
Character	'e'	'v'	'a'	's'
Hex value	0x65	0x76	0x61	0x73

Table 6-62 Store parameters signature

6.2.6.1 *Save all parameters*

All parameters of the controller will be stored in a non-volatile memory if the code “save” is written to the object.

Name	Save all parameters		
Index	0x1010		
Subindex	0x01		
Data type	UNSIGNED32		
Access type	RW		
Default value	0x00000001		
Value range	→ Table 6-62		
PDO mapping	NO		
Backup	NO		

6.2.7 Restore default parameters

Configuration parameters are restored to the default values.

Restoring the default parameters is permitted in NMT state «Pre-Operational» and device state «Power Disable», only. The default values are only set valid after the device is reset or power cycled.

Name	Restore default parameters
Index	0x1011
Object code	ARRAY
Highest subindex supported	4

In order to avoid restoring of default parameters by mistake, restoring should only be executed when a specific signature is written to the respective subindex.

On read access, the device will always return the value 0x00000001.

BYTE	MSB			LSB
Character	'd'	'a'	'o'	'l'
Hex value	0x64	0x61	0x6F	0x6C

Table 6-63 Restore default parameters signature

6.2.7.1 Restore all default parameters

All parameters of the controller will be stored in a non-volatile memory, if the code "load" is written to the object. Only permitted if all axes of the controller are in device state «Power Disable».

Name	Restore all default parameters
Index	0x1011
Subindex	0x01
Data type	UNSIGNED32
Access type	RW
Default value	0x00000001
Value range	→ Table 6-63
PDO mapping	NO
Backup	NO

6.2.8 COB-ID EMCY

The object is only available for «IDX CANopen».

The Communication Object Identifier of the emergency object.

Name	COB-ID EMCY		
Index	0x1014		
Subindex	0x00		
Data type	UNSIGNED32		
Access type	RO		
Default value	0x00000080 + Node-ID		
Value range	–		–
PDO mapping	NO		
Backup	NO		

6.2.9 Consumer heartbeat time

The object is only available for «IDX CANopen».

Defines the expected cycle time of the heartbeat. The heartbeat times are higher than the corresponding producer heartbeat times configured on the CANopen device that produces this heartbeat.

Monitoring starts after reception of the first heartbeat. The time is given as multiple of 1 ms.

If the heartbeat time is “0” (zero), the Node-ID can also be set to “0” (zero). The object entry will not be used.

We recommend to set the consumer heartbeat time value at least 20 ms higher than the time value of the producer.

Typically, the master (or another slave) produces the heartbeat. Therefore, it does not make sense nor even may work properly if the producer Node-ID configured in this object is equal to the Node-ID in use by this device.

In case of a CAN heartbeat error, the device behavior can be defined with → “Communication error” on page 6-72.

Related object: → “Producer heartbeat time” on page 6-70

Name	Consumer heartbeat time
Index	0x1016
Object code	ARRAY
Highest subindex supported	2

6.2.9.1 Consumer n heartbeat time

Names	Consumer 1 heartbeat time Consumer 2 heartbeat time
Index	0x1016
Subindex	0x01...0x02
Data type	UNSIGNED32
Access type	RW
Default value	0
Value range	→ Table 6-64
PDO mapping	NO
Backup	YES

Bit 31...24	Bit 23...16	Bit 15...0
reserved (0)	Node-ID	heartbeat time

Table 6-64 Consumer heartbeat time – Structure

6.2.10 *Producer heartbeat time*

The object is only available for «IDX CANopen».

Defines the cycle time of the heartbeat. The producer heartbeat time "0" (zero) will not be used. The time must be a multiple of 1 ms.

Name	Producer heartbeat time	
Index	0x1017	
Subindex	0x00	
Data type	UNSIGNED16	
Access type	RW	
Default value	0	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.11 *Identity object*

Provides general identification information on the device.

Name	Identity object	
Index	0x1018	
Object code	RECORD	
Highest subindex supported	4	

6.2.11.1 *Vendor ID*

Unique "maxon motor ag" vendor identification defined by CiA.

Name	Vendor ID	
Index	0x1018	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RO	
Default value	0x000000FB	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.11.2 Product code

The high word contains the hardware version. The low word contains the application number.

Name	Product code	
Index	0x1018	
Subindex	0x02	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

Hardware version	Hardware
0x6751	IDX 56
0x6650	IDX 70

Table 6-65 Definition of hardware version

6.2.11.3 Revision number

The high word contains the software version. The low word contains the application version.

Name	Revision number	
Index	0x1018	
Subindex	0x03	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.11.4 Serial number

Contains the last 8 digits of the device serial number.

Related object: →“Serial number complete” on page 6-121

Name	Serial number	
Index	0x1018	
Subindex	0x04	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.12 Error behavior

The object is only available if the active fieldbus is CANopen.

Allows to define the device behavior in case of a certain error.

Name	Error behavior
Index	0x1029
Object code	ARRAY
Highest subindex supported	1

6.2.12.1 Communication error

Defines the device behavior in case of a CAN heartbeat error.

Name	Communication error	
Index	0x1029	
Subindex	0x01	
Data type	UNSIGNED8	
Access type	RW	
Default value	0x00	
Value range	0x00	0x01
PDO mapping	NO	
Backup	YES	

Value	Description
0x00	Change to NMT state Pre-operational (only if currently in NMT state Operational)
0x01	No change of NMT state

Table 6-66 Error behavior in case of CAN heartbeat error

6.2.13 Diagnosis History

The object is only available for «IDX EtherCAT».

Allows the EtherCAT master to access the latest diagnosis messages. Up to maximal five diagnosis messages can be accessed.

In case of an error, the corresponding message will be displayed in «TwinCAT» (tab “Diag History”) and in «EPOS Studio». The error may be cleared by writing the value 0x80 to the → “Controlword” on page 6-182.

Name	Diagnosis History
Index	0x10F3
Object code	RECORD
Highest subindex supported	10

6.2.13.1 Maximum messages

Represents the number of diagnosis messages that can be stored in the diagnosis history (subindex 6 onwards).

Name	Maximum messages	
Index	0x10F3	
Subindex	0x01	
Data type	UNSIGNED8	
Access type	RO	
Default value	5	
Value range	5	5
PDO mapping	NO	
Backup	NO	

6.2.13.2 Newest message

The subindex of the latest diagnosis message (6...255).

Name	Newest message		
Index	0x10F3		
Subindex	0x02		
Data type	UNSIGNED8		
Access type	RO		
Default value	0		
Value range	0, 6	10	
PDO mapping	NO		
Backup	NO		

6.2.13.3 Newest acknowledged message

Name	Newest acknowledged message	
Index	0x10F3	
Subindex	0x03	
Data type	UNSIGNED8	
Access type	RW	
Default value	0	
Value range	0	255
PDO mapping	NO	
Backup	NO	

Bit	RW	Description
>[SI0]...255	W	SDO abort with codes 0x06090030 (value range of parameter exceeded)
6...[SI0]	W	Messages are acknowledged
5...1	W	The Slave returns SDO abort with codes 0x06090030 (value range of parameter exceeded)
0	R	When the message queue will be overwritten, the Slave sets SI3 to "0" (zero)
	W	The Slave will clear all messages

Table 6-67 Newest acknowledged message – Read/Write bits

6.2.13.4 New messages available

Name	New messages available	
Index	0x10F3	
Subindex	0x04	
Data type	BOOLEAN	
Access type	RO	
Default value	0	
Value range	0: no unacknowledged message	1: diagnosis messages are available that can be acknowledged (SI2 <> SI3)
PDO mapping	YES	
Backup	NO	

6.2.13.5 Flags

Flags to control the diagnosis messages for sending/storing. The device supports the functionality for bit2 warning messages only.

Name	Flags	
Index	0x10F3	
Subindex	0x05	
Data type	UNSIGNED16	
Access type	RW	
Default value	0	
Value range	0	15
PDO mapping	NO	
Backup	NO	

Bit		RW	Description
15...6	–	–	reserved
5	1	RO	- In Overwrite Mode: Unacknowledged messages have been overwritten; SI3 is set to "0" (zero) - In Acknowledge Mode: Buffer is full with unacknowledged messages, new messages are discarded
4	0	(W)	Overwrite Mode – old messages are overwritten if buffer is full
	1		Acknowledge Mode – new messages only overwrites older ones if before acknowledged
3	0	(W)	Error messages are stored in the diagnosis message queue
	1		Error messages will not be stored in the diagnosis message queue
2	0	W	Warning messages are stored in the diagnosis message queue
	1		Warning messages will not be stored in the diagnosis message queue
1	0	W	Info messages are stored in the diagnosis message queue
	1		Info messages will not be stored in the diagnosis message queue
0	0	(W)	Default if device does not support Emergency Sending
	1		New diagnosis messages are sent as Emergency Message

Table 6-68 Flags – Read/Write bits

6.2.13.6 *Diagnosis message*

The buffer can store up to 5 diagnosis messages. The first message is stored in subindex 6, the next in subindex 7, and so on. Once the diagnosis message queue is full, the Slave overwrites subindex 6, then subindex 7, and so on, thus enabling the Master to access the most recent messages).

The Diagnosis message contains the parameters shown in ➔Table 6-69.

Nomew	Diagnosis message 1 Diagnosis message 2 Diagnosis message 3 Diagnosis message 4 Diagnosis message 5		
Index	0x10F3		
Subindex	0x06...0x0A		
Data type	OCTET_STRING		
Access type	RO		
Default value	–		
Value range	–		–
PDO mapping	NO		
Backup	NO		

Parameter	Data type	Description	
Diag Code	UNSIGNED32	Bit 0...15 = 0xE000	Bit 16...31: Emergency Error Code
Flags	UNSIGNED16	Bit 0...3	Diag type:
			1 Warning message
			2 Error message
		Bit 4...15	0x00
Text ID	UNSIGNED16	Text ID as reference to Diagnosis text as defined in the ESI file	
		0	No Text ID
		1...65535	Text ID reference to ESI file
Time Stamp	UNSIGNED64	Time Stamp in ns	
		0	No time stamp

Table 6-69 Diagnosis messages

6.2.14 SDO server parameter

The object is only available for «IDX CANopen».

Name	SDO server parameter
Index	0x1200
Object code	RECORD
Highest subindex supported	2

6.2.14.1 COB-ID SDO client to server

Shows the Communication Object Identifier for service data objects from master to device.

Related object: → "Producer heartbeat time" on page 6-70

Name	COB-ID SDO client to server	
Index	0x1200	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RO	
Default value	0x00000600 + Node-ID	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.14.2 COB-ID SDO server to client

Shows the Communication Object Identifier for service data objects from device to master.

Related object: → "Node-ID" on page 6-118

Name	COB-ID SDO server to client	
Index	0x1200	
Subindex	0x02	
Data type	UNSIGNED32	
Access type	RO	
Default value	0x00000580 + Node-ID	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.15 Receive PDO 1 parameter

The object is only available for «IDX CANopen».

Name	Receive PDO 1 parameter
Index	0x1400
Object code	RECORD
Highest subindex supported	2

6.2.15.1 COB-ID used by RxPDO 1

The Communication Object Identifier of receive process data object.

Name	COB-ID used by RxPDO 1
Index	0x1400
Subindex	0x01
Data type	UNSIGNED32
Access type	RW
Default value	0x00000200 + Node-ID
Value range	→Table 6-70 and Table 6-71
PDO mapping	NO
Backup	YES

Bit 31	Bit 30	Bit 29...11	Bit 10...0
valid	RTR	0 (CAN base frame)	11-bit CAN ID

Table 6-70 COB-ID used by RxPDO – Structure

Bit		Description
valid	0b	PDO exists / PDO is valid
	1b	PDO does not exist / PDO is not valid
RTR	0b	RTR allowed on this PDO
	1b	no RTR allowed on this PDO
11-bit Can ID		Value range 0x181...0x57F 0x000 (if valid = 1)

Table 6-71 COB-ID used by RxPDO – Description

6.2.15.2 *Transmission type RxPDO 1*

Describes the PDO's communication principle.

Name	Transmission type RxPDO 1	
Index	0x1400	
Subindex	0x02	
Data type	UNSIGNED8	
Access type	RW	
Default value	255	
Value range	1:synchronous 255:asynchronous	–
PDO mapping	NO	
Backup	YES	

6.2.16 Receive PDO 2 parameter

The object is only available for «IDX CANopen».

Name	Receive PDO 2 parameter
Index	0x1401
Object code	RECORD
Highest subindex supported	2

6.2.16.1 COB-ID used by RxPDO 2

The Communication Object Identifier of receive process data object.

Name	COB-ID used by RxPDO 2
Index	0x1401
Subindex	0x01
Data type	UNSIGNED32
Access type	RW
Default value	0x00000300 + Node-ID
Value range	→ Table 6-70 and Table 6-71
PDO mapping	NO
Backup	YES

6.2.16.2 Transmission type RxPDO 2

Describes the PDO's communication principle.

Name	Transmission type RxPDO 2	
Index	0x1401	
Subindex	0x02	
Data type	UNSIGNED8	
Access type	RW	
Default value	255	
Value range	1:synchronous 255:asynchronous	—
PDO mapping	NO	
Backup	YES	

6.2.17 Receive PDO 3 parameter

The object is only available for «IDX CANopen».

Name	Receive PDO 3 parameter
Index	0x1402
Object code	RECORD
Highest subindex supported	2

6.2.17.1 COB-ID used by RxPDO 3

The Communication Object Identifier of receive process data object.

Name	COB-ID used by RxPDO 3
Index	0x1402
Subindex	0x01
Data type	UNSIGNED32
Access type	RW
Default value	0x00000400 + Node-ID
Value range	→ Table 6-70 and Table 6-71
PDO mapping	NO
Backup	YES

6.2.17.2 Transmission type RxPDO 3

Describes the PDO's communication principle.

Name	Transmission type RxPDO 3		
Index	0x1402		
Subindex	0x02		
Data type	UNSIGNED8		
Access type	RW		
Default value	255		
Value range	1:synchronous 255:asynchronous	—	
PDO mapping	NO		
Backup	YES		

6.2.18 Receive PDO 4 parameter

The object is only available for «IDX CANopen».

Name	Receive PDO 4 parameter
Index	0x1403
Object code	RECORD
Highest subindex supported	2

6.2.18.1 COB-ID used by RxPDO 4

The Communication Object Identifier of receive process data object.

Name	COB-ID used by RxPDO 4
Index	0x1403
Subindex	0x01
Data type	UNSIGNED32
Access type	RW
Default value	0x00000500 + Node-ID
Value range	→ Table 6-70 and Table 6-71
PDO mapping	NO
Backup	YES

6.2.18.2 Transmission type RxPDO 4

Describes the PDO's communication principle.

Name	Transmission type RxPDO 4	
Index	0x1403	
Subindex	0x02	
Data type	UNSIGNED8	
Access type	RW	
Default value	255	
Value range	1:synchronous 255:asynchronous	—
PDO mapping	NO	
Backup	YES	

6.2.19 Receive PDO 1 mapping

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Contains the process data mapping parameters of RxPDO1. Mapping of objects is required to enable PDO processing. Subindex 0 represents the number of mapped objects. Subindex 0x01...0x0C represent the mapped objects whereby the value describes the corresponding index, subindex, and length. The value for the length (in bits) is used to calculate the total mapping length. The maximal allowed length for all mapped objects is as follows:

- CANopen 8 Byte
- EtherCAT 40 Byte

Write access is only permitted in NMT state «Pre-Operational».

The structure for the mapped object in subindex 0x01...0x0C is as follows:

Bit 31...16	Bit 15...8	Bit 7...0
Index	Subindex	Length

Table 6-72 Receive PDO mapping – Structure of mapped object

To be able to change the PDO mapping, the following procedure must be performed:

- Write the value "0" (zero) to subindex 0x00 (disable PDO).
- Modify the desired objects in subindex 0x01...0x0n.
- Write the desired number of mapped objects to subindex 0x00.

Name	Receive PDO 1 mapping
Index	0x1600
Object code	RECORD
Highest subindex supported	12

6.2.19.1 Number of mapped objects in RxPDO 1

Name	Number of mapped objects in RxPDO 1	
Index	0x1600	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	1	
Value range	0 (PDO disabled)	1...12 (1...12 objects are mapped)
PDO mapping	NO	
Backup	YES	

6.2.19.2 1st mapped object in RxPDO 1

Objects with subindex 0x02...0x0C follow the same description as the object with subindex 1.

Name	1st mapped object in RxPDO 1		
Index	0x1600		
Subindex	0x01		
Data type	UNSIGNED32		
Access type	RW		
Default value	0x60400010		
Value range	–		–
PDO mapping	NO		
Backup	YES		

DEFAULT VALUES FOR MAPPED OBJECTS IN RXPDO1

Mapped object	Subindex	Default value	
1 st	0x01	0x60400010	→ Controlword
2 nd	0x02	0x00000000	no object mapped
3 rd	0x03	0x00000000	no object mapped
4 th	0x04	0x00000000	no object mapped
5 th	0x05	0x00000000	no object mapped
6 th	0x06	0x00000000	no object mapped
7 th	0x07	0x00000000	no object mapped
8 th	0x08	0x00000000	no object mapped
9 th	0x09	0x00000000	no object mapped
10 th	0x0A	0x00000000	no object mapped
11 th	0x0B	0x00000000	no object mapped
12 th	0x0C	0x00000000	no object mapped

Table 6-73 Receive PDO 1 mapping

6.2.20 Receive PDO 2 mapping

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Contains the process data mapping parameters of RxPDO2. For a detailed description applicable by analogy → “Receive PDO 1 mapping” on page 6-83.

Name	Receive PDO 2 mapping
Index	0x1601
Object code	RECORD
Highest subindex supported	12

6.2.20.1 Number of mapped objects in RxPDO 2

Name	Number of mapped objects in RxPDO 2	
Index	0x1601	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	2	
Value range	0 (PDO disabled)	1...12 (1...12 objects are mapped)
PDO mapping	NO	
Backup	YES	

6.2.20.2 1st mapped object in RxPDO 2

Objects with subindex 0x02...0x12 follow the same description as the object with subindex 1.

Name	1st mapped object in RxPDO 2	
Index	0x1601	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	0x60400010	
Value range	–	–
PDO mapping	NO	
Backup	YES	

Continued on next page.

DEFAULT VALUES FOR MAPPED OBJECTS IN RXPDO2

Mapped object	Subindex	Default value	
1 st	0x01	0x60400010	➔Controlword
2 nd	0x02	0x60600008	➔Modes of operation
3 rd	0x03	0x00000000	no object mapped
4 th	0x04	0x00000000	no object mapped
5 th	0x05	0x00000000	no object mapped
6 th	0x06	0x00000000	no object mapped
7 th	0x07	0x00000000	no object mapped
8 th	0x08	0x00000000	no object mapped
9 th	0x09	0x00000000	no object mapped
10 th	0x0A	0x00000000	no object mapped
11 th	0x0B	0x00000000	no object mapped
12 th	0x0C	0x00000000	no object mapped

Table 6-74 Receive PDO 2 mapping

6.2.21 Receive PDO 3 mapping

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Contains the process data mapping parameters of RxPDO3. For a detailed description applicable by analogy

➔“Receive PDO 1 mapping” on page 6-83.

Name	Receive PDO 3 mapping		
Index	0x1602		
Object code	RECORD		
Highest subindex supported	12		

6.2.21.1 Number of mapped objects in RxPDO 3

Name	Number of mapped objects in RxPDO 3		
Index	0x1602		
Subindex	0x00		
Data type	UNSIGNED8		
Access type	RW		
Default value	2		
Value range	0 (PDO disabled)	1...12 (1...12 objects are mapped)	
PDO mapping	NO		
Backup	YES		

6.2.21.2 1st mapped object in RxPDO 3

Objects with subindex 0x02...0x12 follow the same description as the object with subindex 1.

Name	1st mapped object in RxPDO 3		
Index	0x1602		
Subindex	0x01		
Data type	UNSIGNED32		
Access type	RW		
Default value	0x60400010		
Value range	–		–
PDO mapping	NO		
Backup	YES		

DEFAULT VALUES FOR MAPPED OBJECTS IN RXPDO3

Mapped object	Subindex	Default value	
1 st	0x01	0x60400010	➔Controlword
2 nd	0x02	0x607A0020	➔Target position
3 rd	0x03	0x00000000	no object mapped
4 th	0x04	0x00000000	no object mapped
5 th	0x05	0x00000000	no object mapped
6 th	0x06	0x00000000	no object mapped
7 th	0x07	0x00000000	no object mapped
8 th	0x08	0x00000000	no object mapped
9 th	0x09	0x00000000	no object mapped
10 th	0x0A	0x00000000	no object mapped
11 th	0x0B	0x00000000	no object mapped
12 th	0x0C	0x00000000	no object mapped

Table 6-75 Receive PDO 3 mapping

6.2.22 Receive PDO 4 mapping

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Contains the process data mapping parameters of RxPDO4. For a detailed description applicable by analogy

→ "Receive PDO 1 mapping" on page 6-83.

Name	Receive PDO 4 mapping
Index	0x1603
Object code	RECORD
Highest subindex supported	12

6.2.22.1 Number of mapped objects in RxPDO 4

Name	Number of mapped objects in RxPDO 4	
Index	0x1603	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	2	
Value range	0 (PDO disabled)	1...12 (1...12 objects are mapped)
PDO mapping	NO	
Backup	YES	

6.2.22.2 1st mapped object in RxPDO 4

Objects with subindex 0x02...0x12 follow the same description as the object with subindex 1.

Name	1st mapped object in RxPDO 4	
Index	0x1603	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	0x60400010	
Value range	–	–
PDO mapping	NO	
Backup	YES	

Continued on next page.

DEFAULT VALUES FOR MAPPED OBJECTS IN RXPDO4

Mapped object	Subindex	Default value	
1 st	0x01	0x60400010	→Controlword
2 nd	0x02	0x60FF0020	→Target velocity
3 rd	0x03	0x00000000	no object mapped
4 th	0x04	0x00000000	no object mapped
5 th	0x05	0x00000000	no object mapped
6 th	0x06	0x00000000	no object mapped
7 th	0x07	0x00000000	no object mapped
8 th	0x08	0x00000000	no object mapped
9 th	0x09	0x00000000	no object mapped
10 th	0x0A	0x00000000	no object mapped
11 th	0x0B	0x00000000	no object mapped
12 th	0x0C	0x00000000	no object mapped

Table 6-76 Receive PDO 4 mapping

6.2.23 Transmit PDO 1 parameter

The object is only available for «IDX CANopen».

Name	Transmit PDO 1 parameter
Index	0x1800
Object code	RECORD
Highest subindex supported	3

6.2.23.1 COB-ID used by TxPDO 1

The Communication Object Identifier of transmit process data object.

Name	COB-ID used by TxPDO 1
Index	0x1800
Subindex	0x01
Data type	UNSIGNED32
Access type	RW
Default value	0x40000180 + Node-ID
Value range	→Table 6-77 and Table 6-78
PDO mapping	NO
Backup	YES

Continued on next page.

Bit 31	Bit 30	Bit 29...11	Bit 10...0
valid	RTR	0 (CAN base frame)	11-bit CAN ID

Table 6-77 COB-ID used by TxPDO – Structure

Bit		Description
valid	0b	PDO exists / PDO is valid
	1b	PDO does not exist / PDO is not valid
RTR	0b	RTR allowed on this PDO
	1b	no RTR allowed on this PDO
11-bit Can ID		11-bit CAN ID of the CAN base frame
		Value range 0x181...0x57F 0x000 (if valid = 1)

Table 6-78 COB-ID used by TxPDO – Description

6.2.23.2 Transmission type TxPDO 1

Describes the PDO's communication principle.

With transmission type 253, the PDO is only transmitted on remote transmission request (RTR). With transmission type 255, the PDO is transmitted if the data changes its value. Therefore, the inhibit time defines a minimum interval.

Name	Transmission type TxPDO 1	
Index	0x1800	
Subindex	0x02	
Data type	UNSIGNED8	
Access type	RW	
Default value	255	
Value range	1: synchronous 253: asynchronous on RTR only 255: asynchronous	–
PDO mapping	NO	
Backup	YES	

6.2.23.3 Inhibit time TxPDO 1

Represents the minimum interval for event-triggered PDO transmission. The value is defined as multiple of 100 μ s.

Event-triggered PDOs can generate immense loads on both CAN bus and device especially if the inhibit time of different PDOs is set to a small value.

Name	Inhibit time TxPDO 1	
Index	0x1800	
Subindex	0x03	
Data type	UNSIGNED16	
Access type	RW	
Default value	10	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.24 Transmit PDO 2 parameter

The object is only available for «IDX CANopen».

Name	Transmit PDO 2 parameter	
Index	0x1801	
Object code	RECORD	
Highest subindex supported	3	

6.2.24.1 COB-ID used by TxPDO 2

The Communication Object Identifier of transmit process data object.

Name	COB-ID used by TxPDO 2	
Index	0x1801	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	0xC0000280 + Node-ID	
Value range	➔ Table 6-77 and Table 6-78	
PDO mapping	NO	
Backup	YES	

6.2.24.2 Transmission type TxPDO 2

Describes the PDO's communication principle.

With transmission type 253, the PDO is only transmitted on remote transmission request (RTR). With transmission type 255, the PDO is transmitted if the data changes its value. Therefore, the inhibit time defines a minimum interval.

Name	Transmission type TxPDO 2	
Index	0x1801	
Subindex	0x02	
Data type	UNSIGNED8	
Access type	RW	
Default value	255	
Value range	1: synchronous 253: asynchronous on RTR only 255: asynchronous	–
PDO mapping	NO	
Backup	YES	

6.2.24.3 Inhibit time TxPDO 2

Represents the minimum interval for event-triggered PDO transmission. The value is defined as multiple of 100 µs.

Event-triggered PDOs can generate immense loads on both CAN bus and device especially if the inhibit time of different PDOs is set to a small value.

Name	Inhibit time TxPDO 2	
Index	0x1801	
Subindex	0x03	
Data type	UNSIGNED16	
Access type	RW	
Default value	10	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.25 Transmit PDO 3 parameter

The object is only available for «IDX CANopen».

Name	Transmit PDO 3 parameter
Index	0x1802
Object code	RECORD
Highest subindex supported	3

6.2.25.1 COB-ID used by TxPDO 3

The Communication Object Identifier of transmit process data object.

Name	COB-ID used by TxPDO 3
Index	0x1802
Subindex	0x01
Data type	UNSIGNED32
Access type	RW
Default value	0xC0000380 + Node-ID
Value range	→ Table 6-77 and Table 6-78
PDO mapping	NO
Backup	YES

6.2.25.2 Transmission type TxPDO 3

Describes the PDO's communication principle.

With transmission type 253, the PDO is only transmitted on remote transmission request (RTR). With transmission type 255, the PDO is transmitted if the data changes its value. Therefore, the inhibit time defines a minimum interval.

Name	Transmission type TxPDO 3		
Index	0x1802		
Subindex	0x02		
Data type	UNSIGNED8		
Access type	RW		
Default value	255		
Value range	1: synchronous 253: asynchronous on RTR only 255: asynchronous	–	
PDO mapping	NO		
Backup	YES		

6.2.25.3 Inhibit time TxPDO 3

Represents the minimum interval for event-triggered PDO transmission. The value is defined as multiple of 100 µs.

Event-triggered PDOs can generate immense loads on both CAN bus and device especially if the inhibit time of different PDOs is set to a small value.

Name	Inhibit time TxPDO 3	
Index	0x1802	
Subindex	0x03	
Data type	UNSIGNED16	
Access type	RW	
Default value	10	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.26 Transmit PDO 4 parameter

The object is only available for «IDX CANopen».

Name	Transmit PDO 4 parameter
Index	0x1803
Object code	RECORD
Highest subindex supported	3

6.2.26.1 COB-ID used by TxPDO 4

The Communication Object Identifier of transmit process data object.

Name	COB-ID used by TxPDO 4
Index	0x1803
Subindex	0x01
Data type	UNSIGNED32
Access type	RW
Default value	0xC0000480 + Node-ID
Value range	→ Table 6-77 and Table 6-78
PDO mapping	NO
Backup	YES

6.2.26.2 Transmission type TxPDO 4

Describes the PDO's communication principle.

With transmission type 253, the PDO is only transmitted on remote transmission request (RTR). With transmission type 255, the PDO is transmitted if the data changes its value. Therefore, the inhibit time defines a minimum interval.

Name	Transmission type TxPDO 4	
Index	0x1803	
Subindex	0x02	
Data type	UNSIGNED8	
Access type	RW	
Default value	255	
Value range	1: synchronous 253: asynchronous on RTR only 255: asynchronous	–
PDO mapping	NO	
Backup	YES	

6.2.26.3 Inhibit time TxPDO 4

Represents the minimum interval for event-triggered PDO transmission. The value is defined as multiple of 100 µs.

Event-triggered PDOs can generate immense loads on both CAN bus and device especially if the inhibit time of different PDOs is set to a small value.

Name	Inhibit time TxPDO 4	
Index	0x1803	
Subindex	0x03	
Data type	UNSIGNED16	
Access type	RW	
Default value	10	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.27 Transmit PDO 1 mapping

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Contains the process data mapping parameters of TxPDO1. Mapping of objects is required to enable PDO processing. Subindex 0 represents the number of mapped objects. Subindex 0x01...0x0C represent the mapped objects whereby the value describes the corresponding index, subindex, and length. The value for the length (in bits) is used to calculate the total mapping length.

The maximal allowed length for all mapped objects is as follows:

- CANopen 8 Byte
- EtherCAT 40 Byte

Write access is only permitted in NMT state «Pre-Operational».

The structure for the mapped object in subindex 0x01...0x0C is as follows:

Bit 31...16	Bit 15...8	Bit 7...0
Index	Subindex	Length

Table 6-79 Transmit PDO mapping – Structure of mapped object

To be able to change the PDO mapping, the following procedure must be performed:

- a) Write the value “0” (zero) to subindex 0x00 (disable PDO).
- b) Modify the desired objects in subindex 0x01...0x0n.
- c) Write the desired number of mapped objects to subindex 0x00.

Name	Transmit PDO 1 mapping
Index	0x1A00
Object code	RECORD
Highest subindex supported	12

6.2.27.1 Number of mapped objects in TxPDO 1

Name	Number of mapped objects in TxPDO 1	
Index	0x1A00	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	1	
Value range	0 (PDO disabled)	1...12 (1...12 objects are mapped)
PDO mapping	NO	
Backup	YES	

6.2.27.2 1st mapped object in TxPDO 1

Objects with subindex 0x02...0x0C follow the same description as the object with subindex 1.

Name	1st mapped object in TxPDO 1		
Index	0x1A00		
Subindex	0x01		
Data type	UNSIGNED32		
Access type	RW		
Default value	0x60410010		
Value range	–		–
PDO mapping	NO		
Backup	YES		

DEFAULT VALUES FOR MAPPED OBJECTS IN TXPDO1

Mapped object	Subindex	Default value	
1 st	0x01	0x60410010	➔ Statusword
2 nd	0x02	0x00000000	no object mapped
3 rd	0x03	0x00000000	no object mapped
4 th	0x04	0x00000000	no object mapped
5 th	0x05	0x00000000	no object mapped
6 th	0x06	0x00000000	no object mapped
7 th	0x07	0x00000000	no object mapped
8 th	0x08	0x00000000	no object mapped
9 th	0x09	0x00000000	no object mapped
10 th	0x0A	0x00000000	no object mapped
11 th	0x0B	0x00000000	no object mapped
12 th	0x0C	0x00000000	no object mapped

Table 6-80 Transmit PDO 1 mapping

6.2.28 Transmit PDO 2 mapping

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Contains the process data mapping parameters of TxPDO2. For a detailed description applicable by analogy
→ “Transmit PDO 1 mapping” on page 6-96.

Name	Transmit PDO 2 mapping
Index	0x1A01
Object code	RECORD
Highest subindex supported	12

6.2.28.1 Number of mapped objects in TxPDO 2

Name	Number of mapped objects in TxPDO 2	
Index	0x1A01	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	2	
Value range	0 (PDO disabled)	1...12 (1...12 objects are mapped)
PDO mapping	NO	
Backup	YES	

6.2.28.2 1st mapped object in TxPDO 2

Objects with subindex 0x02...0x0C follow the same description as the object with subindex 1.

Name	1st mapped object in TxPDO 2	
Index	0x1A01	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	0x60410010	
Value range	–	–
PDO mapping	NO	
Backup	YES	

Continued on next page.

DEFAULT VALUES FOR MAPPED OBJECTS IN TXPDO2

Mapped object	Subindex	Default value	
1 st	0x01	0x60410010	→ Statusword
2 nd	0x02	0x60610008	→ Modes of operation display
3 rd	0x03	0x00000000	no object mapped
4 th	0x04	0x00000000	no object mapped
5 th	0x05	0x00000000	no object mapped
6 th	0x06	0x00000000	no object mapped
7 th	0x07	0x00000000	no object mapped
8 th	0x08	0x00000000	no object mapped
9 th	0x09	0x00000000	no object mapped
10 th	0x0A	0x00000000	no object mapped
11 th	0x0B	0x00000000	no object mapped
12 th	0x0C	0x00000000	no object mapped

Table 6-81 Transmit PDO 2 mapping

6.2.29 Transmit PDO 3 mapping

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Contains the process data mapping parameters of TxPDO3. For a detailed description applicable by analogy → “Transmit PDO 1 mapping” on page 6-96.

Name	Transmit PDO 3 mapping
Index	0x1A02
Object code	RECORD
Highest subindex supported	12

6.2.29.1 Number of mapped objects in TxPDO 3

Name	Number of mapped objects in TxPDO 3	
Index	0x1A02	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	2	
Value range	0 (PDO disabled)	1...12 (1...12 objects are mapped)
PDO mapping	NO	
Backup	YES	

6.2.29.2 1st mapped object in TxPDO 3

Objects with subindex 0x02...0x0C follow the same description as the object with subindex 1.

Name	1st mapped object in TxPDO 3		
Index	0x1A02		
Subindex	0x01		
Data type	UNSIGNED32		
Access type	RW		
Default value	0x60410010		
Value range	–		–
PDO mapping	NO		
Backup	YES		

DEFAULT VALUES FOR MAPPED OBJECTS IN TXPDO3

Mapped object	Subindex	Default value	
1 st	0x01	0x60410010	→ Statusword
2 nd	0x02	0x60640020	→ Position actual value
3 rd	0x03	0x00000000	no object mapped
4 th	0x04	0x00000000	no object mapped
5 th	0x05	0x00000000	no object mapped
6 th	0x06	0x00000000	no object mapped
7 th	0x07	0x00000000	no object mapped
8 th	0x08	0x00000000	no object mapped
9 th	0x09	0x00000000	no object mapped
10 th	0x0A	0x00000000	no object mapped
11 th	0x0B	0x00000000	no object mapped
12 th	0x0C	0x00000000	no object mapped

Table 6-82 Transmit PDO 3 mapping

6.2.30 Transmit PDO 4 mapping

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Contains the process data mapping parameters of TxPDO4. For a detailed description applicable by analogy → “Transmit PDO 1 mapping” on page 6-96.

Name	Transmit PDO 4 mapping
Index	0x1A03
Object code	RECORD
Highest subindex supported	12

6.2.30.1 Number of mapped objects in TxPDO 4

Name	Number of mapped objects in TxPDO 4	
Index	0x1A03	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	2	
Value range	0 (PDO disabled)	1...12 (1...12 objects are mapped)
PDO mapping	NO	
Backup	YES	

6.2.30.2 1st mapped object in TxPDO 4

Objects with subindex 0x02...0x0C follow the same description as the object with subindex 1.

Name	1st mapped object in TxPDO 4	
Index	0x1A03	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	0x60410010	
Value range	–	–
PDO mapping	NO	
Backup	YES	

Continued on next page.

DEFAULT VALUES FOR MAPPED OBJECTS IN TXPDO4

Mapped object	Subindex	Default value	
1 st	0x01	0x60410010	➔ Statusword
2 nd	0x02	0x606C0020	➔ Velocity actual value
3 rd	0x03	0x00000000	no object mapped
4 th	0x04	0x00000000	no object mapped
5 th	0x05	0x00000000	no object mapped
6 th	0x06	0x00000000	no object mapped
7 th	0x07	0x00000000	no object mapped
8 th	0x08	0x00000000	no object mapped
9 th	0x09	0x00000000	no object mapped
10 th	0x0A	0x00000000	no object mapped
11 th	0x0B	0x00000000	no object mapped
12 th	0x0C	0x00000000	no object mapped

Table 6-83 Transmit PDO 4 mapping

6.2.31 SYNC manager communication type

The object is only available for «IDX EtherCAT».

The preconfigured read only object is used to read out the transfer mode of the EtherCAT Sync Manager's channels.

Name	SYNC manager communication type	
Index	0x1C00	
Object code	ARRAY	
Highest subindex supported	4	

6.2.31.1 Number of used SYNC manager channels

Name	Number of used SYNC manager channels	
Index	0x1C00	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RO	
Default value	4	
Value range	4	4
PDO mapping	NO	
Backup	NO	

6.2.31.2 Communication type SYNC channel 0

Name	Communication type SYNC channel 0	
Index	0x1C00	
Subindex	0x01	
Data type	UNSIGNED8	
Access type	RO	
Default value	1: Mailbox Receive (Master → Slave)	
Value range	1	1
PDO mapping	NO	
Backup	NO	

6.2.31.3 Communication type SYNC channel 1

Name	Communication type SYNC channel 1	
Index	0x1C00	
Subindex	0x02	
Data type	UNSIGNED8	
Access type	RO	
Default value	2: Mailbox Receive (Master ← Slave)	
Value range	2	2
PDO mapping	NO	
Backup	NO	

6.2.31.4 Communication type SYNC channel 2

Name	Communication type SYNC channel 2	
Index	0x1C00	
Subindex	0x03	
Data type	UNSIGNED8	
Access type	RO	
Default value	3: Process Data Output (Master → Slave)	
Value range	3	3
PDO mapping	NO	
Backup	NO	

6.2.31.5 Communication type SYNC channel 3

Name	Communication type SYNC channel 3	
Index	0x1C00	
Subindex	0x04	
Data type	UNSIGNED8	
Access type	RO	
Default value	4: Process Data Output (Master ← Slave)	
Value range	4	4
PDO mapping	NO	
Backup	NO	

6.2.32 SYNC manager 2 PDO assignment

The object is only available for «IDX EtherCAT».

Used to configure a PDO assignment for Sync channel 2 (Master → Slave).

In order to change the value in object → 1st assigned RxPDO, object → Number of assigned RxPDOs must be set to zero first.

Write access is only permitted in NMT state «Pre-Operational».

Name	SYNC manager 2 PDO assignment
Index	0x1C12
Object code	ARRAY
Highest subindex supported	1

6.2.32.1 Number of assigned RxPDOs

Name	Number of assigned RxPDOs	
Index	0x1C12	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	1	
Value range	0 (PDO disabled)	1
PDO mapping	NO	
Backup	YES	

6.2.32.2 1st assigned RxPDO

Name	1st assigned RxPDO	
Index	0x1C12	
Subindex	0x01	
Data type	UNSIGNED16	
Access type	RW	
Default value	0x1600	
Value range	0x1600	0x1603
PDO mapping	NO	
Backup	YES	

6.2.33 SYNC manager 3 PDO assignment

The object is only available for «IDX EtherCAT».

Used to configure a PDO assignment for Sync channel 2 (Master ← Slave).

In order to change the value in object → 1st assigned TxPDO, object → Number of assigned TxPDOs must be set to zero first.

Write access is only permitted in NMT state «Pre-Operational».

Name	SYNC manager 3 PDO assignment
Index	0x1C13
Object code	ARRAY
Highest subindex supported	1

6.2.33.1 Number of assigned TxPDOs

Name	Number of assigned TxPDOs	
Index	0x1C13	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	1	
Value range	0 (PDO disabled)	1
PDO mapping	NO	
Backup	YES	

6.2.33.2 1st assigned TxPDO

Name	1st assigned TxPDO	
Index	0x1C13	
Subindex	0x01	
Data type	UNSIGNED16	
Access type	RW	
Default value	0x1A00	
Value range	0x1A00	0x1A03
PDO mapping	NO	
Backup	YES	

6.2.34 SYNC manager 2 parameter

The object is only available for «IDX EtherCAT».

Used to display the synchronization of the output parameters.

Name	SYNC manager 2 parameter
Index	0x1C32
Object code	RECORD
Highest subindex supported	32

6.2.34.1 Synchronization type

Displays the synchronization type of the output parameters.

Name	Synchronization type
Index	0x1C32
Subindex	0x01
Data type	UNSIGNED16
Access type	RO
Default value	Synchronous
Value range	→ Table 6-84
PDO mapping	NO
Backup	NO

Value	Description
0x0001	Synchronous: Synchronous (with SM2 event)
0x0002	Distributed clock Sync0: Synchronous with SYNC0 event

Table 6-84 SYNC mode output parameters

6.2.34.2 Cycle time

Displays the cycle time of the output parameters. In Sync Manager synchronous mode, the value is measured while in Distributed Clock synchronous mode, the value is taken from the SyncO cycle time register. The value is given in [ns].

Name	Cycle time
Index	0x1C32
Subindex	0x02
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	–
PDO mapping	NO
Backup	NO

6.2.34.3 Synchronization types supported

Displays the supported synchronization modes of the output parameters.

Name	Synchronization types supported	
Index	0x1C32	
Subindex	0x04	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

Bit	Description
15...12	reserved
11	Fixed delay time (synchronization executed by hardware)
10...7	reserved
6, 5	Shift settings 00 = No output shift supported
4...2	DC mode supported 000 = No DC 001 = DC Sync0
1	Synchronous supported
0	FreeRun supported

Table 6-85 Synchronization types supported – Output parameters

6.2.34.4 Minimum cycle time

Displays the minimum cycle time of the output parameters. The value is given in [ns].

Name	Minimum cycle time	
Index	0x1C32	
Subindex	0x05	
Data type	UNSIGNED32	
Access type	RO	
Default value	1'000'000	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.34.5 Calc and copy time

The time needed by the application controller to copy the process data from the Sync Manager to the local memory and to perform calculations, if necessary, before the data is sent to the process. The value is given in [ns].

Name	Calc and copy time	
Index	0x1C32	
Subindex	0x06	
Data type	UNSIGNED32	
Access type	RO	
Default value	1'000	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.34.6 Delay time

The hardware delay time of the slave. The time from receiving the trigger (Sync0 or Sync1 Event) to drive output values to the time until they become valid in the process. The value is given in [ns].

Name	Delay time	
Index	0x1C32	
Subindex	0x09	
Data type	UNSIGNED32	
Access type	RO	
Default value	1'000	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.34.7 SM-event missed

The SM-event missed counter.

Name	SM-event missed	
Index	0x1C32	
Subindex	0x0B	
Data type	UNSIGNED16	
Access type	RO	
Default value	0	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.34.8 *Cycle time too small*

The cycle time too small/even counter.

Name	Cycle time too small	
Index	0x1C32	
Subindex	0x0C	
Data type	UNSIGNED16	
Access type	RO	
Default value	0	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.34.9 *Sync error*

Displays the sync error information.

Name	Sync error	
Index	0x1C32	
Subindex	0x20	
Data type	BOOL	
Access type	RO	
Default value	0	
Value range	–	–
PDO mapping	YES	
Backup	NO	

Value	Description
1	Synchronization error
0	No synchronization error or Sync error not supported

Table 6-86 Sync values

6.2.35 SYNC manager 3 parameter

The object is only available for «IDX EtherCAT».

Used to display the synchronization of the input parameters.

Name	SYNC manager 3 parameter
Index	0x1C33
Object code	RECORD
Highest subindex supported	32

6.2.35.1 Synchronization type

Displays the synchronization type of the input parameters.

Name	Synchronization type
Index	0x1C33
Subindex	0x01
Data type	UNSIGNED16
Access type	RO
Default value	Synchronous with SM2
Value range	→ Table 6-87
PDO mapping	NO
Backup	NO

Value	Description
0x0002	Distributed clock Sync0: Synchronous with SYNC0 event
0x0022	Synchronous with SM2: Synchronous with SM2 event

Table 6-87 SYNC mode input parameters

6.2.35.2 Cycle time

Displays the cycle time of the input parameters. In Sync Manager synchronous mode, the value is measured while in Distributed Clock synchronous mode, the value is taken from the SyncO cycle time register. The value is given in [ns].

Name	Cycle time
Index	0x1C33
Subindex	0x02
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	–
PDO mapping	NO
Backup	NO

6.2.35.3 Synchronization types supported

Displays the supported synchronization modes of the input parameters.

Name	Synchronization types supported	
Index	0x1C33	
Subindex	0x04	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

Bit	Description
15...7	reserved
6, 5	Shift settings 00 = No output shift supported
4...2	DC mode supported 000 = No DC 001 = DC Sync0
1	Synchronous supported
0	FreeRun supported

Table 6-88 Synchronization types supported – Input parameters

6.2.35.4 Minimum cycle time

Displays the minimum cycle time of the input parameters. The value is given in [ns].

Name	Minimum cycle time	
Index	0x1C33	
Subindex	0x05	
Data type	UNSIGNED32	
Access type	RO	
Default value	1'000'000	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.35.5 Calc and copy time

The time needed by the application controller to copy the process data from the Sync Manager to the local memory and to perform calculations, if necessary, before the data is sent to the process. The value is given in [ns].

Name	Calc and copy time	
Index	0x1C33	
Subindex	0x06	
Data type	UNSIGNED32	
Access type	RO	
Default value	1'000	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.35.6 SM-event missed

The cycle time too small/even counter.

Name	SM-event missed	
Index	0x1C33	
Subindex	0x0B	
Data type	UNSIGNED16	
Access type	RO	
Default value	0	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.35.7 Cycle time too small

The cycle time too small/even counter.

Name	Cycle time too small	
Index	0x1C33	
Subindex	0x0C	
Data type	UNSIGNED16	
Access type	RO	
Default value	0	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.35.8 Sync error

Displays the sync error information.

Name	Sync error	
Index	0x1C33	
Subindex	0x20	
Data type	BOOL	
Access type	RO	
Default value	0	
Value range	–	–
PDO mapping	YES	
Backup	NO	

Value	Description
1	Synchronization error
0	No synchronization error or Sync error not supported

Table 6-89 Sync values

6.2.36 Program data

Used to download a firmware file (msdc). Download will commence only if both, a stop program command and a clear program command were immediately received by →Program control.

Related object: →“Program control” on page 6-114

Name	Program data	
Index	0x1F50	
Object code	ARRAY	
Highest subindex supported	1	

6.2.36.1 Program number 1

Name	Program number 1	
Index	0x1F50	
Subindex	0x01	
Data type	DOMAIN	
Access type	WO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.37 Program control

Initiates firmware download related commands and reads back information on the running application.

While the bootloader is active, only a subset of objects is supported and only one communication interface can be used. For example: The bootloader is activated with the stop program command. If the first command received by the bootloader is sent by USB, the communication is possible via USB only until the application is started with a start program command or a device reset is performed.

To successfully perform a firmware update, the following command sequence must be executed:

Stop program – clear program – download program with write access to → Program data

Related object: → “Program data” on page 6-113

Name	Program control
Index	0x1F51
Object code	ARRAY
Highest subindex supported	1

6.2.37.1 Program number 1

Name	Program number 1
Index	0x1F51
Subindex	0x01
Data type	UNSIGNED8
Access type	RW
Default value	–
Value range	→ Table 6-90
PDO mapping	NO
Backup	NO

Value	Write access	Read access
0x00	Stop program: Activate bootloader application	Program stopped: Bootloader application is active
0x01	Start program: Activate Program	Program started: Program is active
0x02	Reset program: Initiate device reset	Not used
0x03	Clear program: Erase the flash memory before new program data is downloaded	No program available: No valid application is available in the flash memory
0x04...0x07	reserved	reserved
0x80	Triggers an ESM state change acknowledge upon application restart. Relevant only for bootloader.	–

Table 6-90 Program control – Value range

6.2.38 Program software identification

Provides identification on the loaded program software.

If no valid flash content or program software is available, the program software identification is “0” (zero).

While the bootloader is active, the identification of the actually running bootloader version is returned. After a bootloa-der update, a device reset or start program command is required for display of the new identification number.

Name	Program software identification
Index	0x1F56
Object code	ARRAY
Highest subindex supported	1

6.2.38.1 Program number 1

Name	Program number 1
Index	0x1F56
Subindex	0x01
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	➔Table 6-91
PDO mapping	NO
Backup	NO

Bit	Description
31...16	Identification of the application
15...0	Identification of the bootloader

Table 6-91 Program software identification – Value range

6.2.39 *Flash status identification*

Displays the status of the firmware download process.

Name	Flash status identification
Index	0x1F57
Object code	ARRAY
Highest subindex supported	1

6.2.39.1 *Program number 1*

Name	Program number 1
Index	0x1F57
Subindex	0x01
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	➔Table 6-92
PDO mapping	NO
Backup	NO

Continued on next page.

Bit	Value	Description
31...16		Manufacturer-specific information
15...8		Reserved, always 0
7...1	127...93	Reserved for manufacturer-specific errors
	92	Decryption error [a]
	91	Authentication sequence error. Expected command sequence (activate bootloader – clear program – write program data) was not observed. [a]
	90	Flash clear error [a]
	89	Hardware version mismatch. Received firmware cannot be use with this hardware; manufacturer-specific error. [a]
	88	Unspecified error [a]
	87	Flash secured. Write access currently forbidden. [a]
	86	General address error [a]
	85	Flash write error [a]
	84	Flash not cleared before write [a]
	83	Data format error or data CRC error [a]
	82	Data format unknown [a]
	81	No valid program available [a]
	80...68	Reserved for manufacturer-specific errors [a]
	67	Decryption error
	66	Authentication sequence error: Expected command sequence (activate bootloader – clear program – write program data) was not observed.
	65	Flash clear error
	64	Hardware version mismatch. Received firmware cannot be use with this hardware; manufacturer-specific error.
	63	Unspecified error
	62...8	Reserved
	7	Flash secured. Write access currently forbidden.
	6	General address error
	5	Flash write error
	4	Flash not cleared before write
	3	Data format error or data CRC error
	2	Data format unknown
	1	No valid program available
	0	No error occurred, valid program available
0	1	Download in progress. Program Software Identification is not valid.
	0	No download in progress. Program Software Identification is valid.

[a] Error received from extension communication module

Table 6-92 Flash status identification – Value range

6.2.40 Node-ID

Defines the node ID of the device and is used by the communication interfaces CAN and USB.

Changes to this object only come into effect after restart. Therefore, storing all parameters after a change is required, then restart.

The default value 255 is an invalid node ID and it is expected that the user changes the value to a valid node ID via USB or CAN LSS communication interface. For detailed information on LSS see separate document →«IDX Communication Guide»; chapter “Layer Setting Services (LSS)”.

Related object: →“Active fieldbus” on page 6-120

Name	Node-ID	
Index	0x2000	
Subindex	0x00	
Data type	UNSIGNED8	
Access type	RW	
Default value	255: if the active fieldbus is CANopen 1: if the active fieldbus is EtherCAT or None	
Value range	1	127 (and 255)
PDO mapping	NO	
Backup	YES	

6.2.41 CAN bit rate

The object is only available for «IDX CANopen».

Holds the desired bit rate of the CAN interface.

Changes to this object only come into effect after restart. Therefore, storing all parameters after a change is required, then restart.

Automatic bit rate detection is activated in the following cases:

- CAN bit rate is set to “9” and saved (followed by reset/power on).

Name	CAN bit rate
Index	0x2001
Subindex	0x00
Data type	UNSIGNED8
Access type	RW
Default value	0
Value range	→ Table 6-93
PDO mapping	NO
Backup	YES

Value	Bit rate
0	1 Mbit/s
1	800 kbit/s
2	500 kbit/s
3	250 kbit/s
4	125 kbit/s
(5)	reserved
6	50 kbit/s
7	20 kbit/s
(8)	not supported (10 kbit/s)
9	Automatic bite rate detection

Table 6-93 CAN bit rate

6.2.42 USB frame timeout

Defines the timeout over a USB communication frame. It is scaled in [ms].

Name	USB frame timeout	
Index	0x2006	
Subindex	0x00	
Data type	UNSIGNED16	
Access type	RW	
Default value	500	
Value range	50	65'535
PDO mapping	NO	
Backup	YES	

6.2.43 CAN bit rate display

The object is only available for «IDX CANopen».

Represents the actually configured CAN bit rate. Its value can differ from the value of the object →“CAN bit rate” on page 6-119 if automatic bit rate detection is or was active. In all other cases, the value of these two objects are identical.

Related object: →“CAN bit rate” on page 6-119

Name	CAN bit rate display
Index	0x200A
Subindex	0x00
Data type	UNSIGNED8
Access type	RO
Default value	–
Value range	→Table 6-93
PDO mapping	NO
Backup	NO

6.2.44 Active fieldbus

Shows the actual active fieldbus.

Name	Active fieldbus
Index	0x2010
Subindex	0x00
Data type	UNSIGNED8
Access type	RO
Default value	–
Value range	→Table 6-94
PDO mapping	NO
Backup	NO

Value	Fieldbus
0	None
1	CANopen
2	EtherCAT

Table 6-94 Fieldbus type

6.2.45 Active controller type

Shows the actual active controller type.

Name	Active controller type
Index	0x2011
Subindex	0x00
Data type	UNSIGNED8
Access type	RO
Default value	–
Value range	→ Table 6-95
PDO mapping	NO
Backup	NO

Value	Type
0	Servo controller
1	Positioning controller

Table 6-95 Active controller type

6.2.46 Additional identity

Name	Additional identity
Index	0x2100
Object code	RECORD
Highest subindex supported	1

6.2.46.1 Serial number complete

Contains the full 64-bit device serial number.

Name	Serial number complete
Index	0x2100
Subindex	0x01
Data type	UNSIGNED64
Access type	RO
Default value	–
Value range	–
PDO mapping	NO
Backup	YES

6.2.47 *Extension 1 identity*

The object is only available for «IDX EtherCAT».
Shows version information of the connected extension communication.

Name	Extension 1 identity
Index	0x2101
Object code	RECORD
Highest subindex supported	6

6.2.47.1 *Extension 1 software version*

Contains the software version of the connected extension communication.

Name	Extension 1 software version
Index	0x2101
Subindex	0x01
Data type	UNSIGNED16
Access type	RO
Default value	–
Value range	–
PDO mapping	NO
Backup	NO

6.2.47.2 *Extension 1 hardware version*

Contains the software version of the connected extension communication.

Name	Extension 1 hardware version
Index	0x2101
Subindex	0x02
Data type	UNSIGNED16
Access type	RO
Default value	–
Value range	➔Table 6-96
PDO mapping	NO
Backup	NO

Hardware version	Hardware
0x5100	EtherCAT extension

Table 6-96 Extension 1 hardware – Version definition

6.2.47.3 Extension 1 application number

Contains the application number of the connected extension communication.

Name	Extension 1 application number	
Index	0x2101	
Subindex	0x03	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.47.4 Extension 1 application version

Contains the application number of the connected extension communication.

Name	Extension 1 application version	
Index	0x2101	
Subindex	0x04	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.47.5 Extension 1 serial number

Contains the full 64-bit device serial number of the connected extension communication.

Name	Extension 1 serial number	
Index	0x2101	
Subindex	0x05	
Data type	UNSIGNED64	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.47.6 Extension 1 type

Contains the type of the connected extension communication.

Name	Extension 1 type
Index	0x2101
Subindex	0x06
Data type	UNSIGNED8
Access type	RO
Default value	–
Value range	→ Table 6-97
PDO mapping	NO
Backup	NO

Value	Fieldbus
0	None
2	EtherCAT

Table 6-97 Extension communication type

6.2.48 Custom persistent memory

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Name	Custom persistent memory
Index	0x210C
Object code	ARRAY
Highest subindex supported	4

6.2.48.1 Custom persistent memory (1...4)

Can be used to store custom values (for example axis numbers, identifications, etc.) on the device. The stored values will not be evaluated by the firmware but will be cleared by setting the default parameters.

Names	Custom persistent memory 1 Custom persistent memory 2 Custom persistent memory 3 Custom persistent memory 4
Index	0x210C
Subindex	0x01...0x04
Data type	UNSIGNED32
Access type	RW
Default value	0
Value range	– –
PDO mapping	NO
Backup	YES

6.2.49 *Power supply*

Used to display the power supply parameters.

Name	Power supply
Index	0x2200
Object code	RECORD
Highest subindex supported	1

6.2.49.1 *Power supply voltage*

Represents the actual power supply voltage. The value is given in [0.1 V].

Name	Power supply voltage	
Index	0x2200	
Subindex	0x01	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.50 Power supply supervision

Used to customize power supervision.

Name	Power supply supervision
Index	0x2201
Object code	RECORD
Highest subindex supported	2

6.2.50.1 Power supply undervoltage limit

If the supply voltage falls below this undervoltage limit and device is enabled, the →Undervoltage error will be set. After a undervoltage is detected the device can only be enabled if the supply voltage is higher than the summed undervoltage limit (→Table 6-98) plus the hysteresis undervoltage (→Table 6-99). The value is given in [0.001 V].

The maximum value is →Power supply overvoltage limit (0x2201; 0x02) “Max” value minus the sum of the voltage hysteresis (→Table 6-99). If the undervoltage limit is set higher than the overvoltage limit, the overvoltage limit will be adjusted accordingly.

Name	Power supply undervoltage limit
Index	0x2201
Subindex	0x01
Data type	UNSIGNED32
Access type	RW
Default value	→Table 6-98
Value range	→Table 6-98
PDO mapping	NO
Backup	NO

Hardware	Default	Min	Max
IDX 56	8'000	8'000	60'500
IDX 70	8'000	8'000	72'800

Table 6-98 Power supply voltage – Undervoltage limit

Hardware	Hysteresis undervoltage	Hysteresis overvoltage
IDX 56	500	2'000
IDX 70	500	1'000

Table 6-99 Power supply voltage – Hysteresis

6.2.50.2 *Power supply overvoltage limit*

If the supply voltage raises above this overvoltage limit, the →Overvoltage error will be set. The error can only be cleared if the supply voltage falls below the overvoltage limit minus hysteresis overvoltage (→Table 6-100). The value is given in [0.001 V].

The overvoltage limit's "Min" value is dependent on the →Power supply undervoltage limit (0x2201; 0x01) and must be equal or larger than the summed undervoltage limit (→Table 6-98) plus the hysteresis undervoltage plus the hysteresis overvoltage (→Table 6-99).

Name	Power supply overvoltage limit
Index	0x2201
Subindex	0x02
Data type	UNSIGNED32
Access type	RW
Default value	→Table 6-100
Value range	→Table 6-100
PDO mapping	NO
Backup	NO

Hardware	Default	Min	Max
IDX 56	63'000	Dependent on the undervoltage limit (→Table 6-98)	63'000
IDX 70	74'300		74'300

Table 6-100 Power supply voltage – Overvoltage limit

6.2.51 Axis configuration

Used to setup the main components of the axis by configuring the sensors and the control structure.

Write access is only permitted in device state «Power Disable».

Related object: → “Motor type” on page 6-221

Name	Axis configuration
Index	0x3000
Object code	RECORD
Highest subindex supported	6

6.2.51.1 Sensors configuration

Displays the sensor types used for the axis.

Related object: → “SSI absolute encoder” on page 6-138

Name	Sensors configuration
Index	0x3000
Subindex	0x01
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	→ Table 6-101 and Table 6-102
PDO mapping	NO
Backup	NO

Bit 31...24	Bit 23...16	Bit 15...8	Bit 7...0
reserved (0)	Sensor 3 type	Sensor 2 type	Sensor 1 type

Table 6-101 Sensor configuration – Bits

Name	Value	Description
Sensor 1 type	0x00	None
Sensor 2 type	0x03	SSI absolute encoder
Sensor 3 type	0x00	None

Table 6-102 Supported sensor types

6.2.51.2 Control structure

Defines the control structure of the axis.

- Take into account that the position control quality depends, among other influences, on the resolution of the main sensor. For some sensor types, such as SSI, the “position refresh rate” has an additional influence on the position control quality. Increase the sensor’s “data rate” to improve position control quality.
- Upon changing this parameter, the absolute position may be corrupted. Therefore, ➔ «Position referenced to home position» (➔ «Statusword” on page 6-183) and ➔ «Position actual value” on page 6-188 will be cleared.

Name	Control structure
Index	0x3000
Subindex	0x02
Data type	UNSIGNED32
Access type	RW
Default value	Device-specific
Value range	➔ Table 6-103
PDO mapping	NO
Backup	YES

Bit	Name	Value	Description
31...28	reserved	0	–
27...26	Mounting Position Sensor 2	0	On motor (or undefined)
25...20	reserved	0	–
19...16	Main Sensor	2	Sensor 2
15...14	Process Value Reference	0	On motor (or undefined)
13	reserved	0	–
12	Gear	0	None
		1	Gear mounted to the system
11...8	Position Control Structure	0	None [a] [b]
		1	PID position controller [c]
7...4	Velocity Control Structure	1	PI velocity controller (low pass filter)
		2	PI velocity controller (observer)
3...0	Current Control Structure	1	PI current controller
[a] Not available with «IDX CANopen» [b] Not available with «IDX EtherCAT» [c] Not available with «IDX I/O»			

Table 6-103 Control structure – Bits

6.2.51.3 Commutation sensors

Displays the commutation sensors for axis drive.

Name	Commutation sensors
Index	0x3000
Subindex	0x03
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	→Table 6-104 and Table 6-105
PDO mapping	NO
Backup	NO

Bit	Name	Value	Description
31...8	reserved	0	–
7...4	Commutation Sensor Absolute	2	Sensor 2
3...0	Commutation Sensor Relative	0	None

Table 6-104 Commutation sensors – Bits

Value	Description	Motor type supported
0x00000020	Sensor 2 used for commutation	EC sinus (SSI encoder only)

Table 6-105 Commutation sensors – Value range

6.2.51.4 Axis configuration miscellaneous

Used to define various options regarding the axis configuration.

Name	Axis configuration miscellaneous
Index	0x3000
Subindex	0x04
Data type	UNSIGNED32
Access type	RW
Default value	0x00000000
Value range	→ Table 6-106
PDO mapping	NO
Backup	YES

Bit	Name	Value	Description
31...9	reserved	0	–
8	Sensor supervision	1	Main sensor supervision disabled
		0	Main sensor supervision enabled
7...1	reserved	0	–
0	Axis polarity	1	Inverse polarity – rotational direction of the axis is CW when positive demanded values are attached
		0	Normal polarity – rotational direction of the axis is CCW when positive demanded values are attached

Table 6-106 Axis configuration miscellaneous – Bits

6.2.51.5 Main sensor resolution

Displays the resolution of the main sensor given in [increments/revolution].

Name	Main sensor resolution
Index	0x3000
Subindex	0x05
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	–
PDO mapping	NO
Backup	NO

6.2.51.6 Max system speed

Displays the max system speed. The value is given in [velocity units] (→Page 2-17).

Related objects: →“Motor type” on page 6-221 / →“Max profile velocity” on page 6-196 / →“Max motor speed” on page 6-197 / →“Target velocity” on page 6-221 / →“Max gear input speed” on page 6-137

Name	Max system speed	
Index	0x3000	
Subindex	0x06	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	1	→Table 6-107 →Table 6-108
PDO mapping	NO	
Backup	NO	

Velocity limit		Max motor speed greater Max gear input speed	Max motor speed lower or equal Max gear input speed
Gear	no	Max motor speed	Max motor speed
	yes	$\frac{\text{Max gear input speed}}{\text{Absolute gear reduction}}$	$\frac{\text{Max motor speed}}{\text{Absolute gear reduction}}$

Table 6-107 Max system speed – Limits

Velocity units factor	Max system speed limited by velocity units	Limit
$10^0 / 10^{-1} / 10^{-2} / 10^{-3} / 10^{-4}$	No	—
10^{-5}	Yes	21474.83647
10^{-6}	Yes	2147.483647

Table 6-108 Max system speed – Speed limitations based on velocity units

6.2.52 Motor data

Used to configure the parameters of the motor.

Related object: →“Motor type” on page 6-221

Name	Motor data
Index	0x3001
Object code	RECORD
Highest subindex supported	5

6.2.52.1 Nominal current

Represents the nominal current of the motor [mA]. Continuous operation of the motor at this current level and at 25 °C ambient will cause the winding to ultimately reach the specified maximal winding temperature. This assumes no heat sinking.

Related object: →“Motor rated torque” on page 6-192

Name	Nominal current
Index	0x3001
Subindex	0x01
Data type	UNSIGNED32
Access type	RW
Default value	Device-specific
Value range	Device-specific
PDO mapping	RXPDO
Backup	YES

6.2.52.2 Output current limit

Represents the maximal permissible current of the motor [mA]. We recommend to set the value to double of →Nominal current. The value can be substantially increased if the motor mount is made of heat-dissipating materials.

Name	Output current limit
Index	0x3001
Subindex	0x02
Data type	UNSIGNED32
Access type	RW
Default value	Device-specific
Value range	Device-specific
PDO mapping	RXPDO
Backup	YES

6.2.52.3 Number of pole pairs

Represents the number of magnetic pole pairs (number of poles divided by 2) of the rotor of a brushless DC motor (maxon EC motor/BLDC motor).

Related object: ➔“Max motor speed” on page 6-197

Name	Number of pole pairs	
Index	0x3001	
Subindex	0x03	
Data type	UNSIGNED8	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.52.4 Thermal time constant winding

Represents the thermal time constant of motor winding. The value is given in [0.1 s]. Example: For a time constant of 4 seconds, set the value “40”.

Name	Thermal time constant winding	
Index	0x3001	
Subindex	0x04	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.52.5 Torque constant

Represents the motor's torque constant. The value is given in [$\mu\text{Nm/A}$].

Related object: ➔“Motor rated torque” on page 6-192

Name	Torque constant	
Index	0x3001	
Subindex	0x05	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.53 Electrical system parameters

The parameters are evaluated during the auto tuning identification of the electrical system. They are used during the auto tuning identification of the mechanical system to calculate the torque constant.

Name	Electrical system parameters
Index	0x3002
Object code	RECORD
Highest subindex supported	2

6.2.53.1 Electrical resistance

Represents the electrical system resistance. The value is given in [$\text{m}\Omega$].

Name	Electrical resistance
Index	0x3002
Subindex	0x01
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	–
PDO mapping	NO
Backup	NO

6.2.53.2 Electrical inductance

Represents the electrical system inductance. The value is given in [μH].

Name	Electrical inductance
Index	0x3002
Subindex	0x02
Data type	UNSIGNED16
Access type	RO
Default value	–
Value range	–
PDO mapping	NO
Backup	NO

6.2.54 Gear configuration

Used to setup configuration of a gear. A gear can only be used if the corresponding value of →Axis configuration (→Control structure) has been configured (not “none”).

Write access is only permitted in device state «Power Disable».

Related object: →“Axis configuration” on page 6-128

Name	Gear configuration
Index	0x3003
Object code	RECORD
Highest subindex supported	4

6.2.54.1 Gear reduction numerator

The absolute gear reduction is calculated by division of gear reduction numerator by gear reduction denominator. It is also the ratio of input speed/turns as well as output speed/turns of a gear.

For detailed gear specifications →maxon catalog.

Name	Gear reduction numerator	
Index	0x3003	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	Device-specific	
Value range	1	4'294'967'295
PDO mapping	NO	
Backup	YES	

6.2.54.2 Gear reduction denominator

The absolute gear reduction is calculated by division of gear reduction numerator by gear reduction denominator. It is also the ratio of input speed/turns as well as output speed/turns of a gear.

For detailed gear specifications →maxon catalog.

Name	Gear reduction denominator	
Index	0x3003	
Subindex	0x02	
Data type	UNSIGNED32	
Access type	RW	
Default value	Device-specific	
Value range	1	4'294'967'295
PDO mapping	NO	
Backup	YES	

6.2.54.3 Max gear input speed

Indicates the configured maximal allowed input speed for the gear. It serves as protection of the gear. Together with the →Max motor speed, it limits the gear's output speed. The value is given in [rpm].

For detailed gear specifications →maxon catalog.

Write access is permitted in device state «Power Enabled».

Related objects: →“Max profile velocity” on page 6-196 / →“Axis configuration” on page 6-128

Name	Max gear input speed	
Index	0x3003	
Subindex	0x03	
Data type	UNSIGNED32	
Access type	RW	
Default value	Device-specific	
Value range	1	Device-specific
PDO mapping	NO	
Backup	YES	

Velocity limit		Max motor speed greater Max gear input speed	Max motor speed lower or equal Max gear input speed
Gear	no	Max motor speed	Max motor speed
	yes	$\frac{\text{Max gear input speed}}{\text{Absolute gear reduction}}$	$\frac{\text{Max motor speed}}{\text{Absolute gear reduction}}$

Table 6-109 Gear velocity limits

6.2.54.4 Gear miscellaneous configuration

Used to define various options regarding the gear configuration.

Name	Gear miscellaneous configuration	
Index	0x3003	
Subindex	0x04	
Data type	UNSIGNED32	
Access type	RW	
Default value	Device-specific	
Value range	→Table 6-110	
PDO mapping	NO	
Backup	YES	

Bit	Name	Value	Description
31...1	reserved	0	–
0	Gear direction	0	Normal (rotational direction of input and output are the same)
		1	Inverted (rotational direction of input and output are opposite)

Table 6-110 Gear miscellaneous configuration – Bits

6.2.55 SSI absolute encoder

Represents the configuration of the SSI absolute encoder. Make sure to activate the SSI absolute encoder for the respective axis using →“Axis configuration” on page 6-128.

Write access is only permitted if the corresponding axis is in state «Power Disable».

A virtual index pulse is generated at value “0” (zero) of single turn part of the raw value. The virtual index can be used for homing or touch probe.

Name	SSI absolute encoder
Index	0x3012
Object code	RECORD
Highest subindex supported	13

6.2.55.1 SSI data rate

Represents the SSI encoder data rate (SSI clock frequency). The value is given in [kbit/s].

The maximal data rate depends on the actual cable length and the configuration of the encoder. For the correlation between cable length and data rate →Figure 6-41. Use cables with twisted pairs.




Figure 6-41 SSI encoder – Data rate vs. cable length

Name	SSI data rate
Index	0x3012
Subindex	0x01
Data type	UNSIGNED16
Access type	RO
Default value	–
Value range	– –
PDO mapping	NO
Backup	NO

6.2.55.2 SSI number of data bits

Represents the number of multi-turn, single-turn, and special bits of the SSI data frame. The maximum value combined is 62 (including special bits →Figure 6-42).

Related object: →“SSI position bits” on page 6-144

Name	SSI number of data bits
Index	0x3012
Subindex	0x02
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	→Table 6-111
PDO mapping	NO
Backup	NO

Bit	Name	Default	Min	Max
31...24	Special bits leading	0	0	16
23...16	Multi-turn bits	0	0	32
15...8	Single-turn bits	12	6	32
7...0	Special bits trailing	0	0	16

Table 6-111 SSI encoder – Number of data bits




Figure 6-42 SSI encoder – Data frame

6.2.55.3 SSI encoding type

Represents the type of SSI encoding.

Name	SSI encoding type
Index	0x3012
Subindex	0x03
Data type	UNSIGNED16
Access type	RO
Default value	—
Value range	→ Table 6-112
PDO mapping	NO
Backup	NO

Bit	Name	Value	Description	Default
15...10	reserved	0	—	0
9	Reference reset	0	No reference reset on frame error	0
		1	Reset referenced flag on frame error (→ Statusword)	
8	Check frame	0	No frame checking	0
		1	Frame start and end bit checking	
7...5	reserved	0	—	0
4	Direction	0	maxon	0
		1	Inverted (or encoder mounted on motor shaft)	
3...0	Encoding type	0	Binary coded data	0
		1	Gray coded data	
		—	reserved	

Table 6-112 SSI encoder – Protocol

6.2.55.4 SSI timeout time

Represents the minimal duration after the last clock edge of a sequence until the first clock edge of the next sequence (→ Figure 6-43). The value is given in [μs].

Name	SSI timeout time	
Index	0x3012	
Subindex	0x05	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	




Figure 6-43 SSI encoder – Timing

6.2.55.5 SSI special bits trailing data

The trailing special bits of the SSI data frame will be copied to this object if the number of special bits trailing >0 (→ Table 6-111). In the device, no additional processing of the special bits will take place, thus, subsequent processing must be handled by the superior application.

Name	SSI special bits trailing data	
Index	0x3012	
Subindex	0x06	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	YES	
Backup	NO	

6.2.55.6 SSI refresh frequency

Displays the momentarily used refresh frequency. The maximal refresh frequency is $1/T_r$. However, this can be smaller depending on the device's internal timings conditions (→ Figure 6-43). The value is given in [Hz]; typically are 25'000, 12'5000, 5'000.

Related object: → "SSI absolute encoder" on page 6-138

Name	SSI refresh frequency	
Index	0x3012	
Subindex	0x07	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.55.7 SSI power up time

Represents the duration from power-up until the SSI encoder is initialized and ready for operation. The value is given in [ms].

Name	SSI power up time	
Index	0x3012	
Subindex	0x08	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.55.8 SSI position raw value

Represents the lower 32 bit part of the actual SSI absolute position raw value derived directly by the encoder (right aligned). The value is given in [increments].

Name	SSI position raw value	
Index	0x3012	
Subindex	0x09	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.55.9 SSI commutation offset value

Represents the SSI absolute position offset value to align to the “0” (zero) angle position for commutation purposes. The SSI commutation offset [0...encoder resolution] represents [0°...360°].

For detailed information see separate document → «IDX Application Notes»; section “Adjustment of SSI Commutation Offset Value” (find a list of sources → Chapter “1.1.6 Sources for additional Information” on page 1-10). The value is given in [increments].


Name	SSI commutation offset value	
Index	0x3012	
Subindex	0x0A	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	



Encoder alignment

- If you are using a maxon absolute encoder, the alignment is factory-set and the “SSI commutation offset value” does not require to be set.
- If you are using a third party absolute encoder, you must...
 - either ensure that the alignment follows the specified pattern (→Figure 6-44)
 - or use the “SSI commutation offset value” to align the angle position.

Signal Sequence of Hall Sensors



Supplied Motor Voltage (Phase to Phase)




Figure 6-44 Block commutation of EC (BLDC) motors – Definition of phases

6.2.55.10 SSI position bits

Unlike the SSI encoder's maximal data length of 62 bit (→“SSI number of data bits” on page 6-139), the position format of the device has a maximum length of 32 bits. Hence, the number of data bits used by the SSI encoder must be reduced, if the sum exceeds 32 multi-turn/single-turn bits.

Among other instances, the number of single-turn bits is also used for calculation of the actual speed. The resolution for rotary encoders is as follows:

$$Resolution = 2^{\text{Single-turn bits}} \left[\frac{inc}{rev} \right]$$




Figure 6-45 SSI encoder – Data bits

Name	SSI position bits
Index	0x3012
Subindex	0x0B
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	→Table 6-113
PDO mapping	NO
Backup	NO

Bit	Name	Min	Max
31...16	reserved	–	–
15...8	Multi-turn bits	0	26
7...0	Single-turn bits	6	31

Table 6-113 SSI position bits

6.2.55.11 SSI special bits leading data

The leading special bits of the SSI data frame will be copied to this object if the number of special bits leading >0 (➔Table 6-111). In the device, no additional processing of special bits will take place, thus, subsequent processing must be handled by the superior application.

Name	SSI special bits leading data	
Index	0x3012	
Subindex	0x0C	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	YES	
Backup	NO	

6.2.55.12 SSI position raw value complete

Represents the actual SSI absolute position raw value [MT, ST] derived directly by the encoder. The value is given in [increments].

Name	SSI position raw value complete	
Index	0x3012	
Subindex	0x0D	
Data type	UNSIGNED64	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.56 Current control parameter set

Holds the current controller parameters. The current controller is realized with a digital PI controller.

Name	Current control parameter set
Index	0x30A0
Object code	RECORD
Highest subindex supported	2

6.2.56.1 Current controller P gain

Represents the proportional gain of the current controller. The value is given in $[\frac{\mu V}{A}]$.

Name	Current controller P gain	
Index	0x30A0	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	Device-specific	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.56.2 Current controller I gain

Represents the integral gain of the current controller. The value is given in $[-\frac{\mu V}{A \cdot ms}]$.

Name	Current controller I gain	
Index	0x30A0	
Subindex	0x02	
Data type	UNSIGNED32	
Access type	RW	
Default value	Device-specific	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.57 Position control parameter set

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Holds the position controller parameters. The position controller is realized with a digital PID controller.

Name	Position control parameter set
Index	0x30A1
Object code	RECORD
Highest subindex supported	9

6.2.57.1 Position controller P gain

Represents the proportional gain of the position controller. The value is given in $[\frac{\mu A}{rad}]$.

Name	Position controller P gain	
Index	0x30A1	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	3'600'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.57.2 Position controller I gain

Represents the integral gain of the position controller. The value is given in →SI unit position controller I gain (0x30A1; 0x09).

Reconfirm values when importing/exporting parameters

Prior to the firmware release 0x0170h, the position controller I gain has been given in $[\frac{\mu A}{rad \cdot s}]$.

Make sure to consider this fact and check for correct values when importing/exporting a parameter file from/to firmware older than 0x0170h.

Name	Position controller I gain	
Index	0x30A1	
Subindex	0x02	
Data type	UNSIGNED32	
Access type	RW	
Default value	50'000'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.57.3 Position controller D gain

Represents the differential gain of the position controller. The value is given in $[\frac{\mu A \cdot s}{rad}]$.

Name	Position controller D gain	
Index	0x30A1	
Subindex	0x03	
Data type	UNSIGNED32	
Access type	RW	
Default value	50'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.57.4 Position controller FF velocity gain

Represents the speed feedforward gain of the position controller. The value is given in $[\frac{\mu A \cdot s}{rad}]$.

Name	Position controller FF velocity gain	
Index	0x30A1	
Subindex	0x04	
Data type	UNSIGNED32	
Access type	RW	
Default value	2'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.57.5 Position controller FF acceleration gain

Represents the acceleration feedforward gain of the position controller. The value is given in $[\frac{\mu A \cdot s^2}{rad}]$.

Name	Position controller FF acceleration gain	
Index	0x30A1	
Subindex	0x05	
Data type	UNSIGNED32	
Access type	RW	
Default value	500	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.57.6 SI unit position controller I gain

Represents the SI units of the →Position controller I gain (0x30A1; 0x02). Coding of the user-defined units and prefixes follows →Chapter “2.3.1 SI Units” on page 2-17.

Name	SI unit position controller I gain		
Index	0x30A1		
Subindex	0x09		
Data type	UNSIGNED32		
Access type	RW		
Default value	0xFA040300		
Value range	–		–
PDO mapping	RXPDO		
Backup	YES		

Bit 31...24	Bit 23...16	Bit 15...8	Bit 7...0
Prefix	Numerator	Denominator	reserved (0)

Table 6-114 SI units velocity – Bits

Value	Description	Symbol
0xFA040300	micro ampere / radian second	$\frac{\mu A \cdot s}{rad}$
0xFD040300	milli ampere / radian second	$\frac{mA \cdot s}{rad}$

Table 6-115 SI units velocity – Value range

6.2.58 Velocity control parameter set

Velocity regulation is implemented with a digital PI controller. The object holds all parameters of the velocity controller.

Name	Velocity control parameter set
Index	0x30A2
Object code	RECORD
Highest subindex supported	5

6.2.58.1 Velocity controller P gain

Represents the proportional gain of the velocity controller. The value is given in $[\frac{\mu A \cdot s}{rad}]$.

Name	Velocity controller P gain	
Index	0x30A2	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	60'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.58.2 Velocity controller I gain

Represents the integral gain of the velocity controller. The value is given in $[\frac{\mu A}{rad}]$.

Name	Velocity controller I gain	
Index	0x30A2	
Subindex	0x02	
Data type	UNSIGNED32	
Access type	RW	
Default value	1'200'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.58.3 Velocity controller FF velocity gain

Represents the speed feedforward gain of the velocity controller. The value is given in $[\frac{\mu A \cdot s}{rad}]$.

Name	Velocity controller FF velocity gain	
Index	0x30A2	
Subindex	0x03	
Data type	UNSIGNED32	
Access type	RW	
Default value	2'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.58.4 Velocity controller FF acceleration gain

Represents the acceleration feedforward gain of the velocity controller. The value is given in $[\frac{\mu A \cdot s^2}{rad}]$.

Name	Velocity controller FF acceleration gain	
Index	0x30A2	
Subindex	0x04	
Data type	UNSIGNED32	
Access type	RW	
Default value	500	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.58.5 Velocity controller filter cut-off frequency

Represents the velocity low pass filter cut-off frequency of the velocity controller. The value is given in [Hz].

Name	Velocity controller filter cut-off frequency	
Index	0x30A2	
Subindex	0x05	
Data type	UNSIGNED16	
Access type	RW	
Default value	600	
Value range	1	10'000
PDO mapping	NO	
Backup	YES	

6.2.59 Velocity observer parameter set

Velocity observation is implemented with a digital disturbance observer. The object holds all parameters of the velocity observer.

Name	Velocity observer parameter set
Index	0x30A3
Object code	RECORD
Highest subindex supported	5

6.2.59.1 Velocity observer position correction gain

Represents the position correction gain of the velocity observer. The value is given in [%].

Name	Velocity observer position correction gain	
Index	0x30A3	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	868	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.59.2 Velocity observer velocity correction gain

Represents the velocity correction gain of the velocity observer. The value is given in [mHz].

Name	Velocity observer velocity correction gain	
Index	0x30A3	
Subindex	0x02	
Data type	UNSIGNED32	
Access type	RW	
Default value	500'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.59.3 Velocity observer load correction gain

Represents the load correction gain of the velocity observer. The value is given in $[\frac{\mu Nm}{rad}]$.

Name	Velocity observer load correction gain	
Index	0x30A3	
Subindex	0x03	
Data type	UNSIGNED32	
Access type	RW	
Default value	200'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.59.4 Velocity observer friction

Represents the velocity observer friction. The value is given in $[0.001 \cdot \frac{\mu Nm}{rpm}]$.

Name	Velocity observer friction	
Index	0x30A3	
Subindex	0x04	
Data type	UNSIGNED32	
Access type	RW	
Default value	3'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.59.5 Velocity observer inertia

Represents the velocity observer inertia. The value is given in $[0.001 g \cdot cm^2]$.

Name	Velocity observer inertia	
Index	0x30A3	
Subindex	0x05	
Data type	UNSIGNED32	
Access type	RW	
Default value	300'000	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.60 Home position

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Defines the position that will be set as zero position of the absolute position counter. The value is given in [position units] (→Page 2-17).

Related object: →“Home offset move distance” on page 6-154

Name	Home position	
Index	0x30B0	
Subindex	0x00	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.61 Home offset move distance

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Represents a moving distance in a homing procedure. It is useful to move away from a detected position (for example mechanical limit stop or limit switch) at the end of the homing sequence, thus preventing the axis from a border damage respectively limit switch error. The value is given in [position units] (→Page 2-17).

Name	Home offset move distance	
Index	0x30B1	
Subindex	0x00	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.62 Current threshold for homing mode

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Used for homing methods «-1», «-2», «-3», and «-4». A mechanical border will be detected when the measured motor current rises above the specified threshold [mA].

Related object: → "Homing method" on page 6-200

Name	Current threshold for homing mode	
Index	0x30B2	
Subindex	0x00	
Data type	UNSIGNED16	
Access type	RW	
Default value	500	
Value range	–	Maximal value of → Output current limit
PDO mapping	RXPDO	
Backup	YES	

6.2.63 Current demand value

The set value for the current controller. The value is given in [mA].

Name	Current demand value	
Index	0x30D0	
Subindex	0x00	
Data type	INTEGER32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.64 Current actual values

Provides the actual current values.

Name	Current actual values
Index	0x30D1
Object code	ARRAY
Highest subindex supported	2

6.2.64.1 Current actual value averaged

Represents the →“Current actual value” on page 6-156 filtered by 1st order digital low-pass filter with a cut-off frequency of 50 Hz. The value is given in [mA].

Name	Current actual value averaged	
Index	0x30D1	
Subindex	0x01	
Data type	INTEGER32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.64.2 Current actual value

Provides the actual value of the motor's current. The value is given in [mA].

Name	Current actual value	
Index	0x30D1	
Subindex	0x02	
Data type	INTEGER32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.65 Torque actual values

Provides the actual torque values.

Name	Torque actual values
Index	0x30D2
Object code	ARRAY
Highest subindex supported	1

6.2.65.1 Torque actual value averaged

Represents the →“Torque actual value” on page 6-192 filtered by 1st order digital low-pass filter with a cut-off frequency of 50 Hz. The value is given in $[\frac{MotorRatedTorque}{1000}]$.

Related object: →“Torque actual value” on page 6-192

Name	Torque actual value averaged	
Index	0x30D2	
Subindex	0x01	
Data type	INTEGER16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.66 Velocity actual values

Provides the actual velocity values.

Name	Velocity actual values
Index	0x30D3
Object code	ARRAY
Highest subindex supported	1

6.2.66.1 Velocity actual value averaged

Represents the →“Velocity actual value” on page 6-191 filtered by 1st order digital low-pass filter with a cut-off frequency of 5 Hz.

Provides the actual averaged velocity value of the axis, derived by the main sensor defined in →“Axis configuration” on page 6-128. If no main sensor is configured, the velocity actual value is “0” (zero). The value is given in [velocity units] (→Page 2-17).

Related object: →“Velocity actual value” on page 6-191

Name	Velocity actual value averaged	
Index	0x30D3	
Subindex	0x01	
Data type	INTEGER32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.67 Standstill window configuration

Configures the conditions to detect when the drive has come to a standstill. The functionality specifies the behavior of some device state machine transitions (→ “Device Control” on page 2-14).

The following transitions are not performed until standstill condition is reached:

- «Operation Enable» → «Switch on disabled»
- «Operation Enable» → «Ready to switch on»
- «Operation Enable» → «Switched on»
- «Fault reaction active» → «Fault»

The slowdown behavior can be configured using the related objects.

Related objects: → “Abort connection option code” on page 6-180 / → “Shutdown option code” on page 6-185 / → “Disable operation option code” on page 6-185 / → “Fault reaction option code” on page 6-186

Name	Standstill window configuration
Index	0x30E0
Object code	RECORD
Highest subindex supported	3

6.2.67.1 Standstill window

Defines a symmetric range of accepted velocity values relatively to zero.

Standstill is reached, if the → “Velocity actual value averaged” on page 6-158 is within the standstill window (0x01) for the duration of the standstill window time (0x02). The value is given in [velocity units] (→ Page 2-17).

The value “4'294'967'295” ($2^{32}-1$) switches off standstill detection and standstill is deemed to be reached at the end of the trajectory.




Figure 6-46 Standstill window

Continued on next page.

Name	Standstill window	
Index	0x30E0	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	30	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.67.2 Standstill window time

Standstill is reached, if the →“Velocity actual value averaged” on page 6-158 is within the standstill window (0x01) for the duration of the standstill window time (0x02). The value is given in [ms].

Name	Standstill window time	
Index	0x30E0	
Subindex	0x02	
Data type	UNSIGNED16	
Access type	RW	
Default value	2	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.67.3 Standstill window timeout

Defines the point of time standstill is supposed to be reached, even if the standstill conditions are not yet fulfilled. This timeout may be used to prevent “hangs” in the device state machine in case the standstill window configuration or the velocity controller parameters are set inauspicious. The value is given in [ms].

The value “65'535” will disable the timeout.

Name	Standstill window timeout	
Index	0x30E0	
Subindex	0x03	
Data type	UNSIGNED16	
Access type	RW	
Default value	1000	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.68 Digital input properties

Related objects: → “Configuration of digital inputs” on page 6-162 / → “Digital inputs” on page 6-219

Name	Digital input properties
Index	0x3141
Object code	ARRAY
Highest subindex supported	2

6.2.68.1 Digital inputs logic state

Displays the state of the digital input logic signal (before polarity correction). A bit is read as “1” if the signal at the corresponding pin is high.

Name	Digital inputs logic state	
Index	0x3141	
Subindex	0x01	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

Bit	Default value
3	Digital input 4
2	Digital input 3
1	Digital input 2
0	Digital input 1

Table 6-116 Digital input bits

6.2.68.2 Digital inputs polarity

Used to set the polarity of the digital input functionalities. If a bit is set to “0” (zero), the associated pin is high active. For bit description → Table 6-116.

Name	Digital inputs polarity	
Index	0x3141	
Subindex	0x02	
Data type	UNSIGNED16	
Access type	RW	
Default value	0x0000	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.69 Configuration of digital inputs

Configures the functionality that will be assigned to digital inputs.

Related objects: ➔“Digital input properties” on page 6-161 / ➔“Digital inputs” on page 6-219

Name	Configuration of digital inputs
Index	0x3142
Object code	ARRAY
Highest subindex supported	4

6.2.69.1 Digital input configuration

Maps functions to digital inputs. Each function can only be mapped once, each digital input can only hold one function.

Names	Digital input 1 configuration Digital input 2 configuration Digital input 3 configuration Digital input 4 configuration
Index	0x3142
Subindex	0x01...0x04
Data type	UNSIGNED8
Access type	RW
Default value	➔Table 6-117
Value range	➔Table 6-117
PDO mapping	NO
Backup	YES

Digital input	Default value	
	«IDX CANopen» «IDX EtherCAT»	«IDX I/O»
DgIn1	0: Negative limit switch	16: Drive enable
DgIn2	1: Positive limit switch	17: Quick stop
DgIn3	2: Home switch	18: General purpose C
DgIn4	19: General purpose D	19: General purpose D

Table 6-117 Digital inputs – Default values

Continued on next page.

Value	Functionality	Description
255	None	No functionality assigned
254...29	reserved	–
28	Quick stop	Stop movement and switch to «Quick stop active» state (→“Device Control” on page 2-14 for valid transitions)
27	Drive enable	Enable/disable the drive or clear errors in «Fault» state (→“Device Control” on page 2-14 for valid transitions)
26	Touch probe [a]	Samples actual position
25	Positive limit switch without errors [a]	Used in homing mode with corresponding methods only, does not generate limit errors
24	Negative limit switch without errors [a]	Used in homing mode with corresponding methods only, does not generate limit errors
23...20	reserved	–
19	General purpose D	State can be read
18	General purpose C	State can be read
17	General purpose B	State can be read
16	General purpose A	State can be read
15...3	reserved	–
2	Home switch [a]	Used in some homing modes
1	Positive limit switch	Generates limit error except in homing mode with corresponding methods
0	Negative limit switch	Generates limit error except in homing mode with corresponding methods
[a] Not available with «IDX I/O»		

Table 6-118 Digital inputs – Configuration

6.2.70 Digital output properties

Related objects: ➔“Configuration of digital outputs” on page 6-165 / ➔“Digital outputs” on page 6-220

Name	Digital output properties
Index	0x3150
Object code	ARRAY
Highest subindex supported	2

6.2.70.1 Digital outputs logic state

Displays the digital output logic state (after polarity correction). A bit is read as “1” if the signal at the corresponding pin is high.

Name	Digital outputs logic state	
Index	0x3150	
Subindex	0x01	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

Bit	Description
1	Digital output 2
0	Digital output 1

Table 6-119 Digital output bits

6.2.70.2 Digital outputs polarity

Used to set the polarity of the digital outputs. If a bit is set to “1”, the associated output will be inverted, thus “1” in ➔“Digital outputs” on page 6-220” will set the output pin low.

For bit description ➔Table 6-119.

Name	Digital outputs polarity	
Index	0x3150	
Subindex	0x02	
Data type	UNSIGNED16	
Access type	RW	
Default value	0x0000	
Value range	–	–
PDO mapping	NO	
Backup	YES	

6.2.71 Configuration of digital outputs

Configures the functionality that will be assigned to digital outputs 1 to 3.

Related objects: ➔ “Digital output properties” on page 6-164 / ➔ “Digital outputs” on page 6-220

Name	Configuration of digital outputs
Index	0x3151
Object code	ARRAY
Highest subindex supported	2

6.2.71.1 Digital output configuration

Names	Digital output 1 configuration Digital output 2 configuration
Index	0x3151
Subindex	0x01...0x02
Data type	UNSIGNED8
Access type	RW
Default value	➔ Table 6-120
Value range	➔ Table 6-121
PDO mapping	NO
Backup	YES

Digital output	Default value
DigOut1	16: General purpose A
DigOut2	17: General purpose B

Table 6-120 Digital outputs – Default values

Value	Functionality	Description
255	None	No functionality assigned
254...26	reserved	–
25	Ready/Fault	Active on device ready / inactive on device fault state
24	Holding brake [a]	Output functionality to drive a holding brake (for details see ➔ “Holding brake parameters” on page 6-166)
23...18	reserved	–
17	General purpose B	State can be read/written by the host
16	General purpose A	State can be read/written by the host
15...1	reserved	–
0	Set brake (GPIO)	To drive a brake operated by the host in conformance to CiA 402 specification
[a] Not available with factory-equipped internal brake		

Table 6-121 Digital outputs – Configuration

6.2.72 Holding brake parameters

The object cannot be modified with factory-equipped internal brake.

Holding brakes are designed to provide protection against unintentional drifting at standstill. They are activated when no torque is applied to the motor. If the controller applies torque to the motor, the holding break is deactivated (→Chapter “2.2 Device Control” on page 2-14).

The functionality can be mapped to any digital output (→“Configuration of digital inputs” on page 6-162). Thereby, take the output current limit into account (for details see separate document →«Hardware Reference» of respective controller).

DESIGN CHARACTERISTICS OF HOLDING BRAKE

- The holding brake is not designed to brake loads. This is done by the controller.
- The holding brake or the motor may be damaged if the holding brake will activate before the motor has reached full standstill. Thus, it is of vital importance to configure the standstill conditions (→“Standstill window configuration” on page 6-159)!
- The holding brake function will only work properly if a main sensor is configured. Otherwise, there is no available information on the motor speed and, as a consequence thereof, there is no possibility to detect standstill →“Standstill window configuration” on page 6-159 and →“Control structure” on page 6-129).
- The parameters, their characteristics and configuration are optimized for the use of a permanent magnet brake. However, other brake types may be used whereby an appropriate interpretation of the parameters and the respective settings must be carefully considered.




Figure 6-47 Holding brake activation timing (digital output polarity “High active”)

Name	Holding brake parameters
Index	0x3158
Object code	RECORD
Highest subindex supported	3

Continued on next page.

6.2.72.1 Holding brake coupling time (former Holding brake rise time)

Indicates the time required from power-off until reaching the holding brake's torque (→Figure 6-47). For permanent magnet brakes, the data sheet often uses the term «reaction time closing». The value is given in [ms].

Name	Holding brake coupling time		
Index	0x3158		
Subindex	0x01		
Data type	UNSIGNED16		
Access type	RW		
Default value	10		
Value range	0		5'000
PDO mapping	NO		
Backup	YES		

6.2.72.2 Holding brake opening time (former Holding brake fall time)

Indicates the time required from power-on until releasing the holding brake's torque (→Figure 6-47). For permanent magnet brakes, the data sheet often uses the term «reaction time opening». The value is given in [ms].

Name	Holding brake opening time		
Index	0x3158		
Subindex	0x02		
Data type	UNSIGNED16		
Access type	RW		
Default value	10		
Value range	0		5'000
PDO mapping	NO		
Backup	YES		

6.2.72.3 Holding brake state

Indicates the state of the holding brake.

Name	Holding brake state		
Index	0x3158		
Subindex	0x03		
Data type	UNSIGNED8		
Access type	RO		
Default value	–		
Value range	→Table 6-122		
PDO mapping	NO		
Backup	NO		

Value	State
0	Inactive
1	Active

Table 6-122 Holding brake states

6.2.73 *Analog input properties*

Name	Analog input properties
Index	0x3160
Object code	ARRAY
Highest subindex supported	2

6.2.73.1 *Analog input n voltage*

Represents the voltage measured at analog inputs. The value is given in [mV].

Names	Analog input 1 voltage Analog input 2 voltage	
Index	0x3160	
Subindex	0x01...0x02	
Data type	INTEGER16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.74 Configuration of analog inputs

Configures the functionality that will be assigned to analog inputs.

Related object: → “Analog input properties” on page 6-168

Name	Configuration of analog inputs
Index	0x3161
Object code	ARRAY
Highest subindex supported	2

6.2.74.1 Analog input *n* configuration

Maps functions to analog inputs. Each function can only be mapped once, each analog input can only hold one function.

In CSV and an analog input configured as “Set value velocity” (9), the value of → Velocity offset (0x60B1) will automatically be set to “0” (zero). In CST and an analog input configured as “Set value current” (8), the value of → Torque offset (0x60B2) will automatically be set to “0” (zero).

Related objects: → “Modes of operation” on page 6-187 / → “Velocity offset” on page 6-205 / → “Torque offset” on page 6-205

Names	Analog input 1 configuration Analog input 2 configuration
Index	0x3161
Subindex	0x01...0x02
Data type	UNSIGNED8
Access type	RW
Default value	→ Table 6-123
Value range	→ Table 6-124
PDO mapping	NO
Backup	YES

Analog input	Default value	
	«IDX CANopen» «IDX EtherCAT»	«IDX I/O»
AnIn1	0: General purpose A	8: Set value current
AnIn2	1: General purpose B	9: Set value velocity

Table 6-123 Analog inputs – Default values

Value	Functionality	Description
255	None	No functionality assigned
254...10	reserved	–
9	Set value velocity	
8	Set value current	
7...2	reserved	–
1	General purpose B	Value can be read
0	General purpose A	Value can be read

Table 6-124 Analog inputs – Configuration

6.2.75 *Analog input general purpose*

Displays the actual value measured at the analog inputs. The value is only displayed if the analog input is configured as general purpose. The value is given in [mV].

Related object: ➔ “Analog input properties” on page 6-168

Name	Analog input general purpose
Index	0x3162
Object code	ARRAY
Highest subindex supported	2

6.2.75.1 *Analog input general purpose n*

Names	Analog input general purpose A Analog input general purpose B	
Index	0x3162	
Subindex	0x01...0x02	
Data type	INTEGER16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.76 Analog input adjustment

Name	Analog input adjustment
Index	0x3163
Object code	RECORD
Highest subindex supported	4

6.2.76.1 Analog input n adjustment offset

Represents the adjustment offset voltage of an analog input. The value is given in [mV].

Names	Analog input 1 adjustment offset Analog input 2 adjustment offset	
Index	0x3163	
Subindex	0x01, 0x03	
Data type	INTEGER16	
Access type	RW	
Default value	0	
Value range	-1'000	1'000
PDO mapping	NO	
Backup	YES	

6.2.76.2 Analog input n adjustment gain factor

Represents the adjustment gain factor of an analog input. The value is given in [1/10000].

Names	Analog input 1 adjustment gain factor Analog input 2 adjustment gain factor	
Index	0x3163	
Subindex	0x02, 0x04	
Data type	UNSIGNED16	
Access type	RW	
Default value	10'000	
Value range	5'000	20'000
PDO mapping	NO	
Backup	YES	

6.2.77 Analog input current set value properties

A setpoint function for the analog input. It configures the current set value which is set by an analog input value. The functionality is supported in →“Cyclic Synchronous Torque Mode (CST)” on page 3-44.




Figure 6-48 Analog input current set value properties – Setpoint function

Name	Analog input current set value properties
Index	0x3170
Object code	ARRAY
Highest subindex supported	4




Figure 6-49 Analog input current set value properties – Set value

6.2.77.1 Current set value first voltage

Represents the set voltage for the first slope point. The value is given in [mV].

Name	Current set value first voltage	
Index	0x3170	
Subindex	0x01	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	-10'000	+10'000
PDO mapping	NO	
Backup	YES	

6.2.77.2 Current set value first current

Represents the output current for the first slope point. The value is given in [mA].

Name	Current set value first current	
Index	0x3170	
Subindex	0x02	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	-Max output current (→Output current limit)	+Max output current (→Output current limit)
PDO mapping	NO	
Backup	YES	

6.2.77.3 Current set value second voltage

Represents the set voltage for the second slope point. The value is given in [mV].

Name	Current set value second voltage	
Index	0x3170	
Subindex	0x03	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	-10'000	+10'000
PDO mapping	NO	
Backup	YES	

6.2.77.4 *Current set value second current*

Represents the output current for the second slope point. The value is given in [mA].

Name	Current set value second current	
Index	0x3170	
Subindex	0x04	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–Output current limit (➔Output current limit)	+Output current limit (➔Output current limit)
PDO mapping	NO	
Backup	YES	

6.2.78 *Analog input velocity set value properties*

A setpoint function for the analog input. It configures the velocity set value which is set by an analog input value. The input →Max acceleration is used to define the limitations for the target velocity. The functionality is supported in →“Cyclic Synchronous Velocity Mode (CSV)” on page 3-41.




Figure 6-50 Analog input velocity set value properties – Setpoint function

Name	Analog input velocity set value properties
Index	0x3171
Object code	ARRAY
Highest subindex supported	4




Figure 6-51 Analog input velocity set value properties – Set value

6.2.78.1 Velocity set value first voltage

Represents the set voltage for the first slope point. The value is given in [mV].

Name	Velocity set value first voltage	
Index	0x3171	
Subindex	0x01	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–10'000	+10'000
PDO mapping	NO	
Backup	YES	

6.2.78.2 Velocity set value first velocity

Represents the set velocity for the first slope point. The value is given in [velocity units].

Name	Velocity set value first velocity	
Index	0x3171	
Subindex	0x02	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–100'000 rpm	+100'000 rpm
PDO mapping	NO	
Backup	YES	

6.2.78.3 Velocity set value second voltage

Represents the set voltage for the second slope point. The value is given in [mV].

Name	Velocity set value second voltage	
Index	0x3171	
Subindex	0x03	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–10'000	+10'000
PDO mapping	NO	
Backup	YES	

6.2.78.4 Velocity set value second velocity

Represents the set velocity for the second slope point. The value is given in [velocity units].

Name	Velocity set value second velocity	
Index	0x3171	
Subindex	0x04	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–100'000 rpm	+100'000 rpm
PDO mapping	NO	
Backup	YES	

6.2.79 Power limitation

Represents the model-based I2t power limitation parameters.

Name	Power limitation	
Index	0x3200	
Object code	RECORD	
Highest subindex supported	2	

6.2.79.1 I2t level power stage

Provides the actual thermal state of the internal I2t power stage protection feature. The number is given in percent but values higher than 100% are possible.

Name	I2t level power stage	
Index	0x3200	
Subindex	0x02	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.80 Thermal overload protection

Handles the thermal overload protection.

Name	Thermal overload protection
Index	0x3201
Object code	RECORD
Highest subindex supported	4

6.2.80.1 Temperature power stage

Displays the power stage temperature. The value is given in [0.1 C°].

Name	Temperature power stage
Index	0x3201
Subindex	0x01
Data type	INTEGER16
Access type	RO
Default value	–
Value range	–
PDO mapping	NO
Backup	NO

6.2.80.2 Temperature motor

Displays the motor winding temperature. The value is given in [0.1 C°].

Name	Temperature motor
Index	0x3201
Subindex	0x02
Data type	INTEGER16
Access type	RO
Default value	–
Value range	–
PDO mapping	NO
Backup	NO

6.2.80.3 *Maximal temperature power stage*

Displays the maximal permitted power stage temperature. The value is given in [0.1 C°]. If the power stage temperature exceeds this value, the → Thermal overload error (0x4210) will be set.

Name	Maximal temperature power stage
Index	0x3201
Subindex	0x04
Data type	UNSIGNED16
Access type	RW
Default value	→ Table 6-125
Value range	→ Table 6-125
PDO mapping	NO
Backup	NO

Hardware	Default	Min	Max
IDX 56	1'000	0	1'000
IDX 70	1'000	0	1'000

Table 6-125 Maximal temperature power stage

6.2.81 Motor control

Handles the motor control.

Name	Motor control
Index	0x3203
Object code	RECORD
Highest subindex supported	1

6.2.81.1 PWM duty cycle actual value

Displays the duty cycle of a PWM signal that is applied to the motor. The value is given in thousandth part of the supply voltage.

Name	PWM duty cycle actual value
Index	0x3203
Subindex	0x01
Data type	UNSIGNED16
Access type	RO
Default value	–
Value range	–
PDO mapping	YES
Backup	NO

6.2.82 Abort connection option code

Specifies the action that will be performed when one of the errors labeled “a” (→“Device Errors” on page 7-231) will be detected. It contains all communication errors.

Some critical errors labeled “d” (→“Device Errors” on page 7-231) always lead to a Disable command even if the fault reaction was not configured to do so.

Related objects: →“Error register” on page 6-64 / →“Fault reaction option code” on page 6-186

Name	Abort connection option code
Index	0x6007
Subindex	0x00
Data type	INTEGER16
Access type	RW
Default value	3
Value range	2
PDO mapping	NO
Backup	YES

Value	Description
2	«Disable voltage» command
3	Decelerate with quick stop ramp; disabling of the drive function

Table 6-126 Abort connection option code

6.2.83 *Error code*

Provides the error code of the last error that occurred in the device. This value differs from the value in object ➔“Error register” on page 6-64. Yet, it is the value that will also appear in object ➔“Error history” on page 6-65.

Name	Error code	
Index	0x603F	
Subindex	0x00	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.84 Controlword

Comprises bits for the following items:

- → “Device Control Commands” on page 2-16 (bits 0...3, 7)
- Supervision of operating modes (bits 4...6, 8):
 - “Controlword (Profile Position Mode-specific Bits)” on page 3-23
 - “Controlword (Profile Velocity Mode-specific Bits)” on page 3-26
 - “Controlword (Homing Mode-specific Bits)” on page 3-29

For bit patterns of triggered commands → Chapter “2.2.3 Device Control Commands” on page 2-16.

Related object: → “Statusword” on page 6-183

Name	Controlword		
Index	0x6040		
Subindex	0x00		
Data type	UNSIGNED16		
Access type	RW		
Default value	–		
Value range	–		–
PDO mapping	RXPDO, TXPDO		
Backup	NO		

Bit	Description	PPM	PVM	HMM	CSP	CSV	CST
15	Operating mode-specific	Endless movement	reserved	reserved	reserved	reserved	reserved
14...11	reserved						
10, 9	reserved						
8	Operating mode-specific	Halt	Halt	Halt			
7	Fault reset						
6	Operating mode-specific	Abs / rel	reserved	reserved			
5	Operating mode-specific	Change set immediately	reserved	reserved			
4	Operating mode-specific	New setpoint	reserved	Homing operation start			
3	Enable operation						
2	Quick stop						
1	Enable voltage						
0	Switched on						

Table 6-127 Controlword bits

6.2.85 Statusword

Comprises bits for the following items:

- ➔ “State of the Drive” on page 2-15 (bits 0...6)
- Operating state of the mode (bits 10, 12 and 13):
 - ➔ “Statusword (Profile Position Mode-specific Bits)” on page 3-24
 - ➔ “Statusword (Profile Velocity Mode-specific Bits)” on page 3-27
 - ➔ “Statusword (Homing Mode-specific Bits)” on page 3-30
 - ➔ “Statusword (Cyclic Synchronous Position Mode-specific Bits)” on page 3-40
 - ➔ “Statusword (Cyclic Synchronous Velocity Mode-specific Bits)” on page 3-43
 - ➔ “Statusword (Cyclic Synchronous Torque Mode-specific Bits)” on page 3-46
- Position referenced to home position (bit 15: will be set on homing attained and will be cleared on a position counter overflow or a position sensor error)
- Internal limit active (bit 11; signals a limitation based on an internal calculation)
 - I2t: Limitation according to the I2t method
 - Current: Limitation according to ➔ Current demand value (0x30D0) and ➔ Output current limit (0x3001; 0x02)
 - Max. velocity: Limitation according to ➔ Velocity demand value (0x606B) and ➔ Max profile velocity (0x607F)
 - Max. speed: Limitation according to ➔ Velocity demand value (0x606B) and ➔ Max system speed (0x3000; 0x06)
- Remote (bit 9: indicates NMT state is «Operational»)
- Warning (bit 7: indicates the presence of a warning condition)

Related object: ➔ “Controlword” on page 6-182

Name	Statusword	
Index	0x6041	
Subindex	0x00	
Data type	UNSIGNED16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

Bit	Description	PPM	PVM	HMM	CSP	CSV	CST
15	Position referenced to home position						
14	reserved (0)						
13	Operating mode-specific	Following error	Not used	Homing error	Following error		
12	Operating mode-specific	Setpoint acknowledge	Speed	Homing attained	Drive follows command value	Drive follows command value	Drive follows command value
11	Internal limit active	I2t, Current	I2t, Current Max velocity	I2t, Current	I2t, Current Max. speed	I2t, Current Max. speed	I2t, Current Max. speed
10	Operating mode-specific	Target reached	Target reached	Target reached	reserved	reserved	reserved
9	Remote						
8	reserved (0)						
7	Warning						
6	Switch on disabled						

Continued on next page.

Bit	Description	PPM	PVM	HMM	CSP	CSV	CST
5	Quick stop						
4	Voltage enabled (power stage on)						
3	Fault						
2	Operation enabled						
1	Switched on						
0	Ready to switch on						

Table 6-128 Statusword bits

6.2.86 Quick stop option code

Indicates the action that will be performed as «Quick stop» is executed.

Name	Quick stop option code		
Index	0x605A		
Subindex	0x00		
Data type	INTEGER16		
Access type	RW		
Default value	6		
Value range	6		6
PDO mapping	NO		
Backup	YES		

Value	Description
6	Decelerate with quick stop ramp and stay in «Quick stop active», enabled

Table 6-129 Quick stop option code

6.2.87 Shutdown option code

Indicates the action that will be performed during transition from state «Operation enabled» to states «Ready to switch on» or «Switch on disabled».

Name	Shutdown option code
Index	0x605B
Subindex	0x00
Data type	INTEGER16
Access type	RW
Default value	0: without factory-installed internal brake 1: with factory-installed internal brake
Value range	0...1: without factory-installed internal brake 1: with factory-installed internal brake
PDO mapping	NO
Backup	YES

Value	Description
1	Decelerate with slowdown ramp; disabling of the drive function
0	Disable drive function (switch-off the power stage)

Table 6-130 Shutdown option code

6.2.88 Disable operation option code

Indicates the action that will be performed during transition from state «Operation enabled» to state «Switched on».

Name	Disable operation option code
Index	0x605C
Subindex	0x00
Data type	INTEGER16
Access type	RW
Default value	1
Value range	01
PDO mapping	NO
Backup	YES

Value	Description
1	Decelerate with slowdown ramp; disabling of the drive function
0	Disable drive function (switch-off the power stage)

Table 6-131 Disable operation option code

6.2.89 Halt option code

Indicates the action that will be performed when the halt function is executed. The slow down ramp is the deceleration value of the used mode of operations.

Name	Halt option code
Index	0x605D
Subindex	0x00
Data type	INTEGER16
Access type	RW
Default value	1
Value range	→ Table 6-132 «Halt option code»
PDO mapping	NO
Backup	YES

Value	Description
1	Decelerate with slowdown ramp and stay in operation enabled
2	Decelerate with quick stop ramp and stay in operation enabled

Table 6-132 Halt option code

6.2.90 Fault reaction option code

Specifies the action to be performed if one of the errors labeled “f” in the → “Device Errors” on page 7-231 will be detected. It contains most errors except communication errors (handled as to → “Abort connection option code” on page 6-180).

Some critical errors (labeled “d” (→ “Device Errors” on page 7-231) always lead to a disable command even if the fault reaction was not configured to do so.

Related objects: → “Error register” on page 6-64 / → “Abort connection option code” on page 6-180

Name	Fault reaction option code
Index	0x605E
Subindex	0x00
Data type	INTEGER16
Access type	RW
Default value	2
Value range	0 2
PDO mapping	NO
Backup	YES

Value	Description
2	Decelerate with quick stop ramp; disabling of the drive function
1	Decelerate with slowdown ramp; disabling of the drive function
0	Disable drive function

Table 6-133 Fault reaction option code

6.2.91 Modes of operation

Switches the actually chosen operating mode. We recommend to use →Modes of operation display after changing the operation mode.

Related object: →“Modes of operation display” on page 6-187

Name	Modes of operation
Index	0x6060
Subindex	0x00
Data type	INTEGER8
Access type	RW
Default value	1
Value range	→Table 6-134
PDO mapping	RXPDO
Backup	YES

Operation mode	Description
1	→Profile Position Mode (PPM) [a]
3	→Profile Velocity Mode (PVM) [a]
6	→Homing Mode (HMM) [a]
8	→Cyclic Synchronous Position Mode (CSP) [a]
9	→Cyclic Synchronous Velocity Mode (CSV)
10	→Cyclic Synchronous Torque Mode (CST)
[a] Not available with «IDX I/O»	

Table 6-134 Modes of operation

6.2.92 Modes of operation display

Displays the actual mode of operation. The meaning of the returned value corresponds to the code in →Table 6-134.

Related object: →“Modes of operation” on page 6-187

Name	Modes of operation display
Index	0x6061
Subindex	0x00
Data type	INTEGER8
Access type	RO
Default value	–
Value range	→Table 6-134
PDO mapping	TXPDO
Backup	NO

6.2.93 Position demand value

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Used as input for the position controller. For profiled motions, the value is generated by the profile generator. The value is given in [position units] (→Page 2-17).

Name	Position demand value	
Index	0x6062	
Subindex	0x00	
Data type	INTEGER32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.94 Position actual value

Provides the actual position value of the axis, derived by the main sensor defined in →“Axis configuration” on page 6-128. The value is given in [position units] (→Page 2-17).

As soon as a homing procedure is successfully performed, the value is absolute and referenced which is indicated by the «Position referenced to home position» bit →“Statusword” on page 6-183.

Name	Position actual value	
Index	0x6064	
Subindex	0x00	
Data type	INTEGER32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.95 Following error window

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Represents the maximal permitted difference between →“Position actual value” on page 6-188 and →“Position demand value” on page 6-188. If exceeded, a following error will occur. If the value is set to 4'294'967'295, following error monitoring is switched off. The value is given in [position units] (→Page 2-17).

Name	Following error window	
Index	0x6065	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	2000	
Value range	0	2'147'483'647 (and 4'294'967'295 for disable)
PDO mapping	RXPDO	
Backup	YES	

6.2.96 *Following error time out*

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Indicates the configured time for a following error condition. If exceeded, a following error will occur. The value is given in milliseconds [ms].

Name	Following error time out	
Index	0x6066	
Subindex	0x00	
Data type	UNSIGNED16	
Access type	RW	
Default value	0	
Value range	0	0
PDO mapping	RXPDO	
Backup	NO	

6.2.97 *Position window*

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Indicates the configured position window for the target reached condition. It defines a symmetrical range of accepted positions relative to the →Target position. If the actual value of the position is within the position window, the target position is regarded as reached if the →Position demand value has reached the target position. The value is given in [position units] (“System units” on page 2-17).

If the value of the position window is 4'294'967'295, the position window is switched off and the corresponding bit 10 (target reached) in the →Statusword will be set to “1” at the end of the trajectory.

Related objects: →“Statusword” on page 6-183 / →“Target position” on page 6-193




Figure 6-52 Position window

Name	Position window	
Index	0x6067	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	4'294'967'295	
Value range	0	2'147'483'647 (and 4'294'967'295 for disable)
PDO mapping	RXPDO	
Backup	YES	

6.2.98 Position window time

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Indicates the configured position window time for the target reached condition. If the actual position is within the →Position window during the set time, the corresponding bit 10 (target reached) in the →Statusword will be set to “1”. The value is given in [ms]

Related objects: →“Statusword” on page 6-183 / →“Position window” on page 6-190.

Name	Position window time	
Index	0x6068	
Subindex	0x00	
Data type	UNSIGNED16	
Access type	RW	
Default value	0	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.99 Velocity demand value

Used as input for the position controller. For profiled moves, the value is generated by the profile generator. The value is given in [velocity units] (→Page 2-17).

Name	Velocity demand value	
Index	0x606B	
Subindex	0x00	
Data type	INTEGER32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.100 Velocity actual value

Provides the actual velocity value of the axis derived by the main sensor defined in →“Axis configuration” on page 6-128. The value is given in [velocity units] (→Page 2-17).

Related object: →“Velocity actual value averaged” on page 6-158

Name	Velocity actual value	
Index	0x606C	
Subindex	0x00	
Data type	INTEGER32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.101 Target torque

Indicates the configured input value for the torque controller in Cyclic Synchronous Torque Mode. The value is given in per thousand of →“Motor rated torque” on page 6-192).

Related object: →“Motor rated torque” on page 6-192

Name	Target torque	
Index	0x6071	
Subindex	0x00	
Data type	INTEGER16	
Access type	RW	
Default value	0	
Value range	–	–
PDO mapping	RXPDO	
Backup	NO	

6.2.102 Motor rated torque

Holds the value to which all torque objects are related to. The value is defined as «Nominal current» multiplied by the «Torque constant». The value is given in [μNm].

Changing the value by write access is not permitted.

Related object: →“Motor data” on page 6-133

Name	Motor rated torque	
Index	0x6076	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	Device-specific	
Value range	–	–
PDO mapping	NO	
Backup	NO	

6.2.103 Torque actual value

Provides the actual torque and corresponds to the motor's instantaneous torque. The value is given in per thousand of →“Motor rated torque” on page 6-192).

Related object: →“Motor rated torque” on page 6-192

Name	Torque actual value	
Index	0x6077	
Subindex	0x00	
Data type	INTEGER16	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.104 Target position

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Used as input for the profile generator during profiled moves. Represents the position that the drive is supposed to move using the motion control parameters (such as velocity, acceleration, and deceleration). For non-profiled moves, the target position is directly used as input for the position controller. The value is given in [position units] (→Page 2-17).

The target position is not set until the command is given by the →“Controlword” on page 6-182. In this case, the target position will be interpreted as absolute or relative depending on the command set to the controlword. Otherwise, the target position is interpreted as absolute value.

Related objects: →“Profile velocity” on page 6-197 / →“Profile acceleration” on page 6-198

Name	Target position	
Index	0x607A	
Subindex	0x00	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–	–
PDO mapping	RXPDO	
Backup	NO	

6.2.105 Position range limit

The object is only available for «IDX CANopen» and «IDX EtherCAT».

For the time being, the value range of both objects is limited to the value of “0” (zero) meaning that the functionality of both objects →Min position range limit (0x607B; 0x01) and →Max position range limit (0x607B; 0x02) is disabled. A «Value range error» (abort code 0x0609; 0030) will be reported in case of writing a value other than “0” (zero).

If you should require a way to implement a limitation of the motion range, you might wish to configure the →Software position limit (0x607D), instead.

Name	Position range limit
Index	0x607B
Object code	ARRAY
Highest subindex supported	2

6.2.105.1 Min position range limit

Defines the minimum position range limit by limiting the →Position demand value. Upon reaching or exceeding this limit, the input value automatically skips to the other end of the range. The value is given in [position units] (→Page 2-17).

A value of “0” (zero) disables the minimum position range limit check.

Related object: →“Position demand value” on page 6-188

Name	Min position range limit	
Index	0x607B	
Subindex	0x01	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	0	0
PDO mapping	RXPDO	
Backup	NO	

6.2.105.2 Max position range limit

Defines the maximum position range limit by limiting the →Position demand value. Upon reaching or exceeding this limit, the input value automatically skips to the other end of the range. The value is given in [position units] (→Page 2-17).

A value of “0” (zero) disables the maximum position range limit check.

Related object: →“Position demand value” on page 6-188

Name	Max position range limit	
Index	0x607B	
Subindex	0x02	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	0	0
PDO mapping	RXPDO	
Backup	YES	

6.2.106 Home offset

Defines the position that will be set as zero position of the absolute position counter.
The value is given in [position units].

The value of this object is the same as the value of the object → «Home position» (0x30B0).

Name	Home offset	
Index	0x607C	
Subindex	0x00	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

6.2.107 Software position limit

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Defines the min/max position values for the actual position value and the demand position value. An error is launched if the actual position value or the demand position value exceed their limits.

In PPM, the new target position is limited to the min/max position limit.

The software position limit supervision is inactive in Homing Mode (HMM).

Name	Software position limit	
Index	0x607D	
Object code	ARRAY	
Highest subindex supported	2	

6.2.107.1 Min position limit

Defines the absolute negative position limit for the →Position demand value or the →Position actual value. The value is given in [position units] (→Page 2-17).

If the desired or the actual position is lower than the negative position limit, a software position limit error will be launched.

If the value of Min position limit and Max position limit is “0” (zero), the position limit check is disabled.

Related objects: →“Position demand value” on page 6-188 / →“Position actual value” on page 6-188

Name	Min position limit	
Index	0x607D	
Subindex	0x01	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	-2'147'483'648	2'147'483'647
PDO mapping	RXPDO	
Backup	YES	

6.2.107.2 Max position limit

Defines the absolute positive position limit for the →Position demand value or the →Position actual value. The value is given in [position units] (→Page 2-17).

If the desired or the actual position is higher than the positive position limit, a software position limit error will be launched.

If the value of Min position limit and Max position limit is "0" (zero), position limit check is disabled.

Related objects: →"Position demand value" on page 6-188 / →"Position actual value" on page 6-188

Name	Max position limit	
Index	0x607D	
Subindex	0x02	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	-2'147'483'648	2'147'483'647
PDO mapping	RXPDO	
Backup	YES	

6.2.108 Max profile velocity

Used as velocity limit in a PPM or PVM move. The value is given in [velocity units] (→Page 2-17).

Related objects: →"Profile velocity" on page 6-197 / →"Homing speeds" on page 6-201 / →"Max motor speed" on page 6-197 / →"Target velocity" on page 6-221 / →"Max gear input speed" on page 6-137 / →"Axis configuration" on page 6-128 / →"Max system speed" on page 6-132

Name	Max profile velocity	
Index	0x607F	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	Device-specific	
Value range	1	→Max system speed
PDO mapping	RXPDO	
Backup	YES	

6.2.109 Max motor speed

Indicates the configured maximal allowed speed for the motor. It serves as protection of the motor. The value is given in [rpm] (→Page 2-17).

For detailed motor specifications →maxon catalog.

Related objects: →“Motor type” on page 6-221 / →“Number of pole pairs” on page 6-134 / →“Max profile velocity” on page 6-196 / →“Target velocity” on page 6-221 / →“Max gear input speed” on page 6-137 / →“Max system speed” on page 6-132

Name	Max motor speed	
Index	0x6080	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	Device-specific	
Value range	1	Device-specific / max. 100'000 rpm per pole pair
PDO mapping	RXPDO	
Backup	YES	

6.2.110 Profile velocity

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Represents the velocity normally attained at the end of the acceleration ramp during a profiled move (PPM, PVM). The value is given in [velocity units] (→Page 2-17).

Related object: →“Max profile velocity” on page 6-196

Name	Profile velocity	
Index	0x6081	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	1000	
Value range	1	→Max profile velocity
PDO mapping	RXPDO	
Backup	YES	

6.2.111 Profile acceleration

Defines the acceleration value used during a profiled move. The value is given in [acceleration units] (→Page 2-17).

Name	Profile acceleration	
Index	0x6083	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	10'000	
Value range	1	→Max acceleration
PDO mapping	RXPDO	
Backup	YES	

6.2.112 Profile deceleration

Defines the deceleration value used during a profiled move. The value is given in [acceleration units] (→Page 2-17).

Name	Profile deceleration	
Index	0x6084	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	10'000	
Value range	1	→Max acceleration
PDO mapping	RXPDO	
Backup	YES	

6.2.113 Quick stop deceleration

Used with a «Quick stop» command to determine the deceleration of the quick stop profile. The value is given in [acceleration units] (→Page 2-17).

Related objects: →“Controlword” on page 6-182 / →“Fault reaction option code” on page 6-186 / →“Abort connection option code” on page 6-180

Name	Quick stop deceleration	
Index	0x6085	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	10'000	
Value range	1	→Max acceleration
PDO mapping	RXPDO	
Backup	YES	

6.2.114 Motion profile type

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Selects the type of motion profile trajectory used in →“Profile Position Mode (PPM)” on page 3-21, →“Homing Mode (HMM)” on page 3-28, or →“Profile Velocity Mode (PVM)” on page 3-25.

Name	Motion profile type		
Index	0x6086		
Subindex	0x00		
Data type	INTEGER16		
Access type	RW		
Default value	0		
Value range	➔Table 6-135	—	
PDO mapping	RXPDO		
Backup	YES		

Value	Description
0	linear ramp (trapezoidal profile)

Table 6-135 Motion profile types

6.2.115 Homing method

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Used to select the desired homing method.

If the homing method is changed during an ongoing homing process, it will not come into effect before the next homing process is started.

Name	Homing method	
Index	0x6098	
Subindex	0x00	
Data type	INTEGER8	
Access type	RW	
Default value	7	
Value range	–	–
PDO mapping	RXPDO	
Backup	YES	

Value	Description
37	➔Homing Method 37 (Actual Position)
34	➔Homing Method 34 (Index Positive Speed) [a]
33	➔Homing Method 33 (Index Negative Speed) [a]
27	➔Homing Method 27 (Home Switch Negative Speed)
23	➔Homing Method 23 (Home Switch Positive Speed)
18	➔Homing Method 18 (Positive Limit Switch)
17	➔Homing Method 17 (Negative Limit Switch)
11	➔Homing Method 11 (Home Switch Negative Speed & Index) [a]
7	➔Homing Method 7 (Home Switch Positive Speed & Index) [a]
2	➔Homing Method 2 (Positive Limit Switch & Index) [a]
1	➔Homing Method 1 (Negative Limit Switch & Index) [a]
-1	➔Homing Method -1 (Current Threshold Positive Speed & Index) [a]
-2	➔Homing Method -2 (Current Threshold Negative Speed & Index) [a]
-3	➔Homing Method -3 (Current Threshold Positive Speed)
-4	➔Homing Method -4 (Current Threshold Negative Speed)
[a] The virtual index (SSI sensor) is used for homing.	

Table 6-136 Homing methods

6.2.116 Homing speeds

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Used to search a limit switch in a homing sequence. The value is given in [velocity units] (→Page 2-17).

Related object: →“Max profile velocity” on page 6-196

Name	Homing speeds
Index	0x6099
Object code	ARRAY
Highest subindex supported	2

6.2.116.1 Speed for switch search

Name	Speed for switch search	
Index	0x6099	
Subindex	0x01	
Data type	UNSIGNED32	
Access type	RW	
Default value	100	
Value range	1	→Max profile velocity
PDO mapping	RXPDO	
Backup	YES	

6.2.116.2 Speed for zero search

Used to search the index in a homing sequence. The value is given in [velocity units] (→Page 2-17).

Name	Speed for zero search	
Index	0x6099	
Subindex	0x02	
Data type	UNSIGNED32	
Access type	RW	
Default value	10	
Value range	1	→Max profile velocity
PDO mapping	RXPDO	
Backup	YES	

6.2.117 Homing acceleration

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Used to define acceleration and deceleration ramps in the homing profile. The value is given in [acceleration units] (→Page 2-17).

Related object: →“Max acceleration” on page 6-210

Name	Homing acceleration		
Index	0x609A		
Subindex	0x00		
Data type	UNSIGNED32		
Access type	RW		
Default value	1000		
Value range	1	➔Max acceleration	
PDO mapping	RXPDO		
Backup	YES		

6.2.118 SI unit position

Defines the position units. Coding of the user-defined units and prefixes follows →Chapter “2.3.1 SI Units” on page 2-17.

Write access is only permitted in device state «Power Disable».

Name	SI unit position		
Index	0x60A8		
Subindex	0x00		
Data type	UNSIGNED32		
Access type	RW		
Default value	0x00B50000		
Value range	→Table 6-138		
PDO mapping	NO		
Backup	YES		

Bit 31...24	Bit 23...16	Bit 15...8	Bit 7...0
Prefix	Numerator	Denominator	reserved (0)

Table 6-137 SI units position – Bits

Value	Description	Symbol
0x00B50000	Increments	inc

Table 6-138 SI units position – Value range

6.2.119 SI unit velocity

Defines the velocity units. Coding of the user-defined units and prefixes follows →Chapter “2.3.1 SI Units” on page 2-17.

Write access is only permitted in device state «Power Disable».

Name	SI unit velocity
Index	0x60A9
Subindex	0x00
Data type	UNSIGNED32
Access type	RW
Default value	0x00B44700
Value range	→Table 6-140
PDO mapping	NO
Backup	YES

Bit 31...24	Bit 23...16	Bit 15...8	Bit 7...0
Prefix	Numerator	Denominator	reserved (0)

Table 6-139 SI units velocity – Bits

Value	Description	Symbol
0x00B44700	Revolutions/minute	rev/min (rpm)
0xFFB44700	0.1 revolutions/minute	deci rev/min (drpm)
0xFEB44700	0.01 revolutions/minute	centi rev/min (crpm)
0xFDB44700	0.001 revolutions/minute	milli rev/min (mrpm)
0xFCB44700	0.0001 revolutions/minute	10 ⁻⁴ rev/min (10 ⁻⁴ rpm)
0xFBB44700	0.00001 revolutions/minute	10 ⁻⁵ rev/min (10 ⁻⁵ rpm)
0xFAB44700	0.000001 revolutions/minute	micro rev/min (μrpm)

Table 6-140 SI units velocity – Value range

6.2.120 SI unit acceleration

Defines the acceleration units. Coding of the user-defined units and prefixes follows → Chapter “2.3.1 SI Units” on page 2-17.

Write access is only permitted in device state «Power Disable».

Name	SI unit acceleration
Index	0x60AA
Subindex	0x00
Data type	UNSIGNED32
Access type	RW
Default value	0x00C00300
Value range	→ Table 6-142
PDO mapping	NO
Backup	YES

Bit 31...24	Bit 23...16	Bit 15...8	Bit 7...0
Prefix	Numerator	Denominator	reserved (0)

Table 6-141 SI units acceleration – Bits

Value	Description	Symbol
0x00C00300	(Revolutions/minute)/second	rpm/s

Table 6-142 SI units acceleration – Value range

6.2.121 Position offset

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Provides the offset of the position. The value is given in [position units].

- In CSP, the object contains the commanded additive position of the drive which is then added to the → Target position.

Related object: → “Target position” on page 6-193

Name	Position offset
Index	0x60B0
Subindex	0x00
Data type	INTEGER32
Access type	RW
Default value	0
Value range	–
PDO mapping	RXPDO
Backup	NO

6.2.122 Velocity offset

In CSV, the object provides the offset towards the →Target velocity. The value itself is absolute but, since it represents an additive velocity value, it also can be used to control the drive with relative values in respect to the →Target velocity. The value is given in [velocity units] (→Page 2-17).

Name	Velocity offset	
Index	0x60B1	
Subindex	0x00	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–	–
PDO mapping	RXPDO	
Backup	NO	

6.2.123 Torque offset

Provides the offset of the torque. The value is given in per thousand of →“Motor rated torque” on page 6-192.

- In CSP and CSV, the object contains the input value for torque feed forward.
- In CST, the object contains the commanded additive torque of the drive which is then added to the →Target torque.

Related object: →“Target torque” on page 6-192

Name	Torque offset	
Index	0x60B2	
Subindex	0x00	
Data type	INTEGER16	
Access type	RW	
Default value	0	
Value range	–	–
PDO mapping	RXPDO	
Backup	NO	

6.2.124 Touch probe function

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Configures the touch probe function. Consider →“Digital Input Timing Behavior” on page 4-53 and take note that the touch probe function and Homing Mode cannot be used at the same time. After homing, all touch probe states and latched positions are cleared.

Related object: →“Configuration of digital inputs” on page 6-162

Name	Touch probe function
Index	0x60B8
Subindex	0x00
Data type	UNSIGNED16
Access type	RW
Default value	0
Value range	→Table 6-143
PDO mapping	RXPDO
Backup	NO

Bit	Value	Description
15...6	–	reserved
5 [a]	1	Enable sampling a negative edge touch probe 1
	0	Switch off sampling a negative edge touch probe 1
4 [a]	1	Enable sampling a positive edge touch probe 1
	0	Switch off sampling a positive edge touch probe 1
3; 2 [b]	11	reserved
	10	Touch probe source defined by object 0x60D0-01
	01	Trigger on main encoder index signal [c]
	00	Trigger on touch probe (input mapped to touch probe 1)
1	1	Continuous
	0	Trigger first event
0	1	Enable touch probe 1
	0	Switch off touch probe 1
[a] If main encoder index signal is selected, it is not possible to configure both edges at the same time. [b] Configuring bits 3 or 2 with either values 00 or 10 results in the same behavior. [c] It is the virtual index of the SSI sensor.		

Table 6-143 Touch probe function

6.2.125 Touch probe status

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Provides the status of the touch probe. Status information of the touch probe shall first be evaluated by the control device to check whether the stored touch probe values (➔Touch probe 1 positive edge and ➔Touch probe 1 negative edge) are valid.

Related objects: ➔“Touch probe 1 positive edge” on page 6-207 / ➔“Touch probe 1 negative edge” on page 6-208

Name	Touch probe status
Index	0x60B9
Subindex	0x00
Data type	UNSIGNED16
Access type	RO
Default value	0
Value range	➔Table 6-144
PDO mapping	TXPDO
Backup	NO

Bit	Value	Description
15...3	–	reserved
2	1	Touch probe 1, negative edge position stored
	0	Touch probe 1, no negative edge position stored
1	1	Touch probe 1, positive edge position stored
	0	Touch probe 1, no positive edge position stored
0	1	Touch probe 1 enabled
	0	Touch probe 1 switched off

Table 6-144 Touch probe status

6.2.126 Touch probe 1 positive edge

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Provides the position value of the touch probe 1 at positive edge detection. The object is only valid if the position is stored (➔Touch probe status; bit 1). The value is given in [position units] (➔“System Units” on page 2-17)

Related object: ➔“Touch probe status” on page 6-207

Name	Touch probe 1 positive edge	
Index	0x60BA	
Subindex	0x00	
Data type	INTEGER32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.127 Touch probe 1 negative edge

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Provides the position value of the touch probe 1 at negative edge detection. The object is only valid if the position is stored (→Touch probe status; bit 1). The value is given in [position units] (→“System Units” on page 2-17)

Related object:→“Touch probe status” on page 6-207

Name	Touch probe 1 negative edge	
Index	0x60BB	
Subindex	0x00	
Data type	INTEGER32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

6.2.128 Interpolation time period

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Name	Interpolation time period
Index	0x60C2
Object code	RECORD
Highest subindex supported	2

6.2.128.1 Interpolation time period value

Indicates the time between two PDOs. Values > “0” (zero) enable the demand value interpolation in CSP and CSV. It is of importance that the setpoint (→Target position, →Position offset, →Target velocity, →Velocity offset) is written cyclically with the interpolation time period.

The value is given in $[s \cdot 10^{\text{interpolation time index}}]$. An →Interpolation time index of value –3 indicates that the interpolation time period value is given in milliseconds.

The value “0” (zero) disables the demand value interpolation.



Best Practice

The «Interpolation time period value» must be configured to correspond with the master's synchronized PDO command cycle that updates the CSP set value, respectively the CSV set value.
If a value of “0” (zero) is configured, the device immediately takes the new set value and adapts the position (in case of CSP mode), respectively the velocity (in case of CSV mode) to it within the next control cycle (i.e. 0.4 ms). Afterwards it holds this set value until the next set value of the master is received. This results in an interrupted and noisy motion if the master just provides new set values at cycle rates of 1 ms, 2 ms, or even lower.
If the «Interpolation time period value» is configured properly based on the master's PDO cycle time, the device interpolates the new set value in between the period. This results in a smooth motion and less noisy control result.

Name	Interpolation time period value
Index	0x60C2
Subindex	0x01
Data type	UNSIGNED8
Access type	RW
Default value	0
Value range	0100
PDO mapping	RXPDO
Backup	YES

6.2.128.2 Interpolation time index

Defines the unit of the →Interpolation time period value. The value -3 corresponds to the unit [ms].

Name	Interpolation time index	
Index	0x60C2	
Subindex	0x02	
Data type	INTEGER8	
Access type	RW	
Default value	-3	
Value range	-3	-3
PDO mapping	RXPDO	
Backup	YES	

6.2.129 Max acceleration

Used to limit the maximal allowed acceleration to prevent mechanical damage. It represents the limit of all other acceleration/deceleration objects of the axis. The value is given in [acceleration units] (→Page 2-17). In cyclic modes (CSP, CSV, CST), the object is not taken into account.

Related objects: →“Profile acceleration” on page 6-198 / →“Profile deceleration” on page 6-198 / →“Quick stop deceleration” on page 6-198 / →“Homing acceleration” on page 6-202

Name	Max acceleration	
Index	0x60C5	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RW	
Default value	4'294'967'295	
Value range	1	4'294'967'295
PDO mapping	RXPDO	
Backup	YES	

6.2.130 *Touch probe source*

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Defines the source of the touch probe functions.

Name	Touch probe source
Index	0x60D0
Object code	ARRAY
Highest subindex supported	1

6.2.130.1 *Touch probe 1 source*

Defines the source of the touch probe 1 functions.

Name	Touch probe 1 source
Index	0x60D0
Subindex	0x01
Data type	INTEGER16
Access type	RO
Default value	–
Value range	➔Table 6-145
PDO mapping	NO
Backup	NO

Value	Description
5	Index impulse signal of main sensor [a]
4	Digital input 4
3	Digital input 3
2	Digital input 2
1	Digital input 1
0	reserved
[a] It is the virtual index of the SSI sensor.	

Table 6-145 Touch probe 1 source

6.2.131 Touch probe 1 positive edge counter

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Provides a continuous counter being incremented with each positive edge at touch probe 1. The counter is only valid if the sampling of the positive edge is enabled (→Touch probe status; bit 0 and bit 4) and cleared when the touch probe is disabled.

Related object: →“Touch probe status” on page 6-207

Name	Touch probe 1 positive edge counter
Index	0x60D5
Subindex	0x00
Data type	UNSIGNED16
Access type	RO
Default value	–
Value range	→Table 6-146
PDO mapping	TXPDO
Backup	NO

Probe mode	Value range
Single event	0...1
Continuous	0...65'535 (with overflow)

Table 6-146 Touch probe 1 positive edge counter

6.2.132 Touch probe 1 negative edge counter

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Provides a continuous counter being incremented with each negative edge at touch probe 1. The counter is only valid if the sampling of the negative edge is enabled (→Touch probe status; bit 0 and bit 4) and cleared when the touch probe is disabled.

Related object: →“Touch probe status” on page 6-207

Name	Touch probe 1 negative edge counter
Index	0x60D6
Subindex	0x00
Data type	UNSIGNED16
Access type	RO
Default value	–
Value range	→Table 6-147
PDO mapping	TXPDO
Backup	NO

Probe mode	Value range
Single event	0...1
Continuous	0...65'535 (with overflow)

Table 6-147 Touch probe 1 negative edge counter

6.2.133 Supported homing methods

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Provides the supported homing methods of the drive.

Related object: ➔ “Homing method” on page 6-200

Name	Supported homing methods
Index	0x60E3
Object code	ARRAY
Highest subindex supported	15

6.2.133.1 1st supported homing method

Provides the 1st supported homing method of the drive.

Name	1st supported homing method
Index	0x60E3
Subindex	0x01
Data type	INTEGER8
Access type	CONST
Default value	37
Value range	➔ Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.2 2nd supported homing method

Provides the 2nd supported homing method of the drive.

Name	2nd supported homing method
Index	0x60E3
Subindex	0x02
Data type	INTEGER8
Access type	CONST
Default value	34
Value range	➔ Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.3 3rd supported homing method

Provides the 3rd supported homing method of the drive.

Name	3rd supported homing method
Index	0x60E3
Subindex	0x03
Data type	INTEGER8
Access type	CONST
Default value	33
Value range	→Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.4 4th supported homing method

Provides the 4th supported homing method of the drive.

Name	4th supported homing method
Index	0x60E3
Subindex	0x04
Data type	INTEGER8
Access type	CONST
Default value	27
Value range	→Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.5 5th supported homing method

Provides the 5th supported homing method of the drive.

Name	5th supported homing method
Index	0x60E3
Subindex	0x05
Data type	INTEGER8
Access type	CONST
Default value	23
Value range	→Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.6 6th supported homing method

Provides the 6th supported homing method of the drive.

Name	6th supported homing method
Index	0x60E3
Subindex	0x06
Data type	INTEGER8
Access type	CONST
Default value	18
Value range	→ Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.7 7th supported homing method

Provides the 7th supported homing method of the drive.

Name	7th supported homing method
Index	0x60E3
Subindex	0x07
Data type	INTEGER8
Access type	CONST
Default value	17
Value range	→ Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.8 8th supported homing method

Provides the 8th supported homing method of the drive.

Name	8th supported homing method
Index	0x60E3
Subindex	0x08
Data type	INTEGER8
Access type	CONST
Default value	11
Value range	→ Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.9 9th supported homing method

Provides the 9th supported homing method of the drive.

Name	9th supported homing method
Index	0x60E3
Subindex	0x09
Data type	INTEGER8
Access type	CONST
Default value	7
Value range	→ Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.10 10th supported homing method

Provides the 10th supported homing method of the drive.

Name	10th supported homing method
Index	0x60E3
Subindex	0x0A
Data type	INTEGER8
Access type	CONST
Default value	2
Value range	→ Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.11 11th supported homing method

Provides the 11th supported homing method of the drive.

Name	11th supported homing method
Index	0x60E3
Subindex	0x0B
Data type	INTEGER8
Access type	CONST
Default value	1
Value range	→ Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.12 12th supported homing method

Provides the 12th supported homing method of the drive.

Name	12th supported homing method
Index	0x60E3
Subindex	0x0C
Data type	INTEGER8
Access type	CONST
Default value	-1
Value range	➔Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.13 13th supported homing method

Provides the 13th supported homing method of the drive.

Name	13th supported homing method
Index	0x60E3
Subindex	0x0D
Data type	INTEGER8
Access type	CONST
Default value	-2
Value range	➔Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.14 14th supported homing method

Provides the 14th supported homing method of the drive.

Name	14th supported homing method
Index	0x60E3
Subindex	0x0E
Data type	INTEGER8
Access type	CONST
Default value	-3
Value range	➔Table 6-136
PDO mapping	NO
Backup	NO

6.2.133.15 15th supported homing method

Provides the 15th supported homing method of the drive.

Name	15th supported homing method
Index	0x60E3
Subindex	0x0F
Data type	INTEGER8
Access type	CONST
Default value	-4
Value range	→Table 6-136
PDO mapping	NO
Backup	NO

6.2.134 Following error actual value

The object is only available for «IDX CANopen» and «IDX EtherCAT».

Represents the actual value of the following error. The value is given in [position units] (→Page 2-17).

Name	Following error actual value
Index	0x60F4
Subindex	0x00
Data type	INTEGER32
Access type	RO
Default value	–
Value range	–
PDO mapping	TXPDO
Backup	NO

6.2.135 Digital inputs

Displays the state of the digital input functionalities (after polarity correction by →“Digital input properties” on page 6-161; Polarity). A bit is read as “1” if the signal at the corresponding pin is high.

Related objects: →“Digital input properties” on page 6-161 / →“Configuration of digital inputs” on page 6-162

Name	Digital inputs	
Index	0x60FD	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

Value	Functionality	Description
255	None	No functionality assigned
254...29	reserved	–
28	Quick stop	Stop movement and switch to «Quick stop active» state (→“Device Control” on page 2-14 for valid transitions)
27	Drive enable	Enable/disable the drive or clear errors in «Fault» state (→“Device Control” on page 2-14 for valid transitions)
26	Touch probe [a]	Samples actual position
25	Positive limit switch without errors [a]	Used in homing mode with corresponding methods only, does not generate limit errors
24	Negative limit switch without errors [a]	Used in homing mode with corresponding methods only, does not generate limit errors
23...20	reserved	–
19	General purpose D	State can be read
18	General purpose C	State can be read
17	General purpose B	State can be read
16	General purpose A	State can be read
15...3	reserved	–
2	Home switch [a]	Used in some homing modes
1	Positive limit switch	Generates limit error except in homing mode with corresponding methods
0	Negative limit switch	Generates limit error except in homing mode with corresponding methods

[a] Not available with «IDX I/O»

Table 6-148 Digital inputs

6.2.136 Digital outputs

Configures the state of the digital output functionalities (before polarity correction by →“Digital output properties” on page 6-164; Polarity). If a bit is set to “1” and the polarity bit is set to “0” (zero), the signal at the corresponding pin is high.

Related objects: →“Digital output properties” on page 6-164 / →“Configuration of digital outputs” on page 6-165

Name	Digital outputs
Index	0x60FE
Object code	ARRAY
Highest subindex supported	1

6.2.136.1 Physical outputs

Name	Physical outputs
Index	0x60FE
Subindex	0x01
Data type	UNSIGNED32
Access type	Bit 0...23: RW / Bit 24...31: RO
Default value	0
Value range	– –
PDO mapping	RXPDO
Backup	NO

Bit	Functionality	Description
31...26	reserved	–
25	Ready/Fault	Active on device ready / inactive on device fault state
24	Holding brake [a]	Output functionality to drive a holding brake (for details see →“Holding brake parameters” on page 6-166)
23...18	reserved	–
17	General purpose B	State can be read/written by the host
16	General purpose A	State can be read/written by the host
15...1	reserved	–
0	Set brake (GPIO)	–
[a] Not available with factory-equipped internal brake		

Table 6-149 Digital outputs

6.2.137 Target velocity

In Profile Velocity Mode (PVM), the object indicates the configured target velocity and is used as input for the trajectory generator. The value is given in [velocity units] (→Page 2-17).

Related objects: →“Max profile velocity” on page 6-196 / →“Max motor speed” on page 6-197 / →“Profile acceleration” on page 6-198 / →“Profile deceleration” on page 6-198

Name	Target velocity	
Index	0x60FF	
Subindex	0x00	
Data type	INTEGER32	
Access type	RW	
Default value	0	
Value range	–	–
PDO mapping	RXPDO	
Backup	NO	

6.2.138 Motor type

Defines the motor type of the axis.

Related objects: →“Axis configuration” on page 6-128 / →“Motor data” on page 6-133

Name	Motor type	
Index	0x6402	
Subindex	0x00	
Data type	UNSIGNED16	
Access type	RW	
Default value	10	
Value range	→Table 6-150	
PDO mapping	NO	
Backup	YES	

Value	DS-402 Name	Description
10	Sinusoidal PM BL motor	Brushless DC motor BLDC sinus commutated (maxon EC motor)

Table 6-150 Motor types

6.2.139 Supported drive modes

Provides an overview of the implemented operating modes in the device. Supported are the following modes whereby marked “[a]” are not available with «IDX I/O»:

- ➔Profile Position Mode (PPM) [a]
- ➔Profile Velocity Mode (PVM) [a]
- ➔Homing Mode (HMM) [a]
- ➔Cyclic Synchronous Position Mode (CSP) [a]
- ➔Cyclic Synchronous Velocity Mode (CSV)
- ➔Cyclic Synchronous Torque Mode (CST)

Name	Supported drive modes	
Index	0x6502	
Subindex	0x00	
Data type	UNSIGNED32	
Access type	RO	
Default value	–	
Value range	–	–
PDO mapping	TXPDO	
Backup	NO	

Bit		Description
31...11	0	reserved
10	0	Cyclic Synchronous Torque Mode With Commutation Angle
9	1	Cyclic Synchronous Torque Mode (CST)
8	1	Cyclic Synchronous Velocity Mode (CSV)
7	1	Cyclic Synchronous Position Mode (CSP)
6	0	Interpolated Position Mode (IPM)
5	1	Homing Mode (HMM)
4	0	reserved
3	0	Torque Mode
2	1	Profile Velocity Mode (PVM)
1	0	Velocity Mode
0	1	Profile Position Mode (PPM)

Table 6-151 Supported drive modes – Bits

6.2.140 Modular device profile

The object is only available for «IDX EtherCAT».

Contains the information to interpret the objects in function areas of the modules.

Name	Modular device profile		
Index	0xF000		
Object code	RECORD		
Highest subindex supported	2		

6.2.140.1 Index distance

Name	Index distance		
Index	0xF000		
Subindex	0x01		
Data type	UNSIGNED16		
Access type	RO		
Default value	–		
Value range	0x0010		0x0010
PDO mapping	NO		
Backup	NO		

6.2.140.2 Maximum number of modules

Name	Maximum number of modules		
Index	0xF000		
Subindex	0x02		
Data type	UNSIGNED16		
Access type	RO		
Default value	–		
Value range	1		1
PDO mapping	NO		
Backup	NO		

6.2.141 Configured module ident list

The object is only available for «IDX EtherCAT».

Contains the identification numbers of the configured modules.

The device supports only one module. If the number of configured modules is set to “0” (zero), no module is active.

Write access is only permitted in ESM state «Pre-Operational».

Name	Configured module ident list
Index	0xF030
Object code	ARRAY
Highest subindex supported	1

6.2.141.1 Nbr of configured modules

Name	Nbr of configured modules		
Index	0xF030		
Subindex	0x00		
Data type	UNSIGNED8		
Access type	RW		
Default value	0		
Value range	0		1
PDO mapping	NO		
Backup	NO		

6.2.141.2 Module 1

For details and their definitions on objects specified for the MDP modules see →Chapter “6.3 Modular Device Profile Module” on page 6-226.

Name	Module 1		
Index	0xF030		
Subindex	0x01		
Data type	UNSIGNED32		
Access type	RW		
Default value	–		
Value range	→Table 6-153		
PDO mapping	NO		
Backup	NO		

Bit 31...28 (Nibble)	Bit 27...24 (Nibble)	Bit 23...8 (Word)	Bit 7...0 (Byte)
(0x7) IDX	Op mode	Application number	Version

Table 6-152 Configured module identification – Bits

Continued on next page.

Value	Description (MDP Profile 742)
0x71xxxxxx	PPM module ident
0x73xxxxxx	PVM module ident
0x78xxxxxx	CSP module ident
0x79xxxxxx	CSV module ident
0x7Axxxxxx	CST module ident

Table 6-153 Configured module identification types

6.2.142 Detected module ident list

The object is only available for «IDX EtherCAT».

Contains the module identification during power-up or after executing the «Detect Modules Command».

Name	Detected module ident list
Index	0xF050
Object code	ARRAY
Highest subindex supported	1

6.2.142.1 Nbr of detected modules

Name	Nbr of detected modules
Index	0xF050
Subindex	0x00
Data type	UNSIGNED8
Access type	RO
Default value	0
Value range	0 1
PDO mapping	NO
Backup	NO

6.2.142.2 Module 1

Name	Module 1
Index	0xF050
Subindex	0x01
Data type	UNSIGNED32
Access type	RO
Default value	–
Value range	→ Table 6-153
PDO mapping	NO
Backup	NO

6.3 Modular Device Profile Module

In the EtherCAT Slave Information (ESI) file, the default PDO mapping for the different operation modes is defined as Modular Device Profile (MDP) module. The module can be used by the EtherCAT master to remap the PDO for the selected mode.

The module outputs are assigned to the Receive PDO1 mapping (1600-xx), the module inputs are assigned to the Transmit PDO1 mapping (1A00-xx).

Related objects: → “Modular device profile” on page 6-223 / → “Configured module ident list” on page 6-224 / → “Detected module ident list” on page 6-225

6.3.1 MDP Module PPM

Mapped object	Object (index-subindex)	Object name
1 st	0x6040-00	→ Controlword
2 nd	0x607A-00	→ Target position
3 rd	0x6083-00	→ Profile acceleration
4 th	0x6084-00	→ Profile deceleration
5 th	0x6081-00	→ Profile velocity
6 th	0x6060-00	→ Modes of operation
7 th	0x60FE-01	→ Digital outputs

Table 6-154 MDP module PPM mapping – Default values for RxPDO

Mapped object	Object (index-subindex)	Object name
1 st	0x6041-00	→ Statusword
2 nd	0x6064-00	→ Position actual value
3 rd	0x606C-00	→ Velocity actual value
4 th	0x60F4-00	→ Following error actual value
5 th	0x6061-00	→ Modes of operation display
6 th	0x60FD-00	→ Digital inputs

Table 6-155 MDP module PPM mapping – Default values for TxPDO

6.3.2 MDP Module PVM

Mapped object	Object (index-subindex)	Object name
1 st	0x6040-00	→ Controlword
2 nd	0x60FF-00	→ Target velocity
3 rd	0x6083-00	→ Profile acceleration
4 th	0x6084-00	→ Profile deceleration
5 th	0x6060-00	→ Modes of operation
6 th	0x60FE-01	→ Digital outputs

Table 6-156 MDP module PVM mapping – Default values for RxPDO

Mapped object	Object (index-subindex)	Object name
1 st	0x6041-00	→ Statusword
2 nd	0x6064-00	→ Position actual value
3 rd	0x606C-00	→ Velocity actual value
4 th	0x6061-00	→ Modes of operation display
5 th	0x60FD-00	→ Digital inputs

Table 6-157 MDP module PVM mapping – Default values for TxPDO

6.3.3 MDP Module CSP

Mapped object	Object (index-subindex)	Object name
1 st	0x6040-00	➔Controlword
2 nd	0x607A-00	➔Target position
3 rd	0x60B0-00	➔Position offset
4 th	0x60B2-00	➔Torque offset
5 th	0x6060-00	➔Modes of operation
6 th	0x60FE-01	➔Digital outputs

Table 6-158 MDP module CSP mapping – Default values for RxPDO

Mapped object	Object (index-subindex)	Object name
1 st	0x6041-00	➔Statusword
2 nd	0x6064-00	➔Position actual value
3 rd	0x606C-00	➔Velocity actual value
4 th	0x6077-00	➔Torque actual value
5 th	0x6061-00	➔Modes of operation display
6 th	0x60FD-00	➔Digital inputs

Table 6-159 MDP module CSP mapping – Default values for TxPDO

6.3.4 MDP Module CSV

Mapped object	Object (index-subindex)	Object name
1 st	0x6040-00	→ Controlword
2 nd	0x60FF-00	→ Target velocity
3 rd	0x60B1-00	→ Velocity offset
4 th	0x6060-00	→ Modes of operation
5 th	0x60FE-01	→ Digital outputs

Table 6-160 MDP module CSV mapping – Default values for RxPDO

Mapped object	Object (index-subindex)	Object name
1 st	0x6041-00	→ Statusword
2 nd	0x6064-00	→ Position actual value
3 rd	0x606C-00	→ Velocity actual value
4 th	0x6077-00	→ Torque actual value
5 th	0x6061-00	→ Modes of operation display
6 th	0x60FD-00	→ Digital inputs

Table 6-161 MDP module CSV mapping – Default values for TxPDO

6.3.5 MDP Module CST

Mapped object	Object (index-subindex)	Object name
1 st	0x6040-00	➔Controlword
2 nd	0x6071-00	➔Target torque
3 rd	0x60B2-00	➔Torque offset
4 th	0x6060-00	➔Modes of operation
5 th	0x60FE-01	➔Digital outputs

Table 6-162 MDP module CST mapping – Default values for RxPDO

Mapped object	Object (index-subindex)	Object name
1 st	0x6041-00	➔Statusword
2 nd	0x6064-00	➔Position actual value
3 rd	0x606C-00	➔Velocity actual value
4 th	0x6077-00	➔Torque actual value
5 th	0x6061-00	➔Modes of operation display
6 th	0x60FD-00	➔Digital inputs

Table 6-163 MDP module CST mapping – Default values for TxPDO

7 ERROR HANDLING

7.1 Emergency Message Frame

Upon detection of device-internal errors, the device will transmit emergency message frames over the CANopen network using →“COB-ID EMCY” on page 6-68. An emergency message frame will be transmitted only once per error event and consists of the error code and the actual state of the →“Error register” on page 6-64.

Byte	0	1	2	3	4	5	6	7
Description	Error code		Error register	Not used (always “0”)				

Table 7-164 Emergency message frame

7.2 Device Errors

The device can detect a variety of device errors. The reaction to an error depends on error type and option code. After execution of the fault reaction, the device changes to fault state and the drive will be disabled.

The →“Error history” on page 6-65 holds the error codes that occurred and will be signaled via an emergency message frames. The →“Error register” on page 6-64 holds all set error flags and provides a summary on possible errors.

For fault reaction codes, the following notations will be used:

- a: Use →“Abort connection option code” on page 6-180.
- f: Use →“Fault reaction option code” on page 6-186.
- d: A secure movement is no longer possible.
- w: No effect on device status (warning).

“Position Clear” points out that the position will be clearing upon executing the error reset.

Error code	Error register	Name	Fault reaction code	Position clear
0x0000	0000 0000b	No Error	—	
0x1000	0000 0001b	→Generic error	d	
0x1080 ... 0x1088	0000 0001b	→Generic initialization error	d	
0x1090	0000 0001b	→Firmware incompatibility error	d	
0x2310	0000 0010b	→Overcurrent error	d	
0x2320	0000 0010b	→Power stage protection error	d	
0x3210	0000 0100b	→Overvoltage error	d	
0x3220	0000 0100b	→Undervoltage error	d	
0x4210	0000 1000b	→Thermal overload error	d	
0x4380	0000 1000b	→Thermal motor overload error	d	
0x5113	0000 0100b	→Logic supply voltage too low error	d	
0x5280	0000 0001b	→Hardware defect error	d	
0x5281	0000 0001b	→Hardware incompatibility error	d	
0x5480 ... 0x5483	0000 0001b	→Hardware error	d	
0x6080	0000 0001b	→Sign of life error	d	

Continued on next page.

Error code	Error register	Name	Fault reaction code	Position clear
0x6081	0000 0001b	→Extension 1 watchdog error	a	
0x6180 ... 0x61F0	0000 0001b	→Internal software error	d	
0x6320	0000 0001b	→Software parameter error	f	
0x6380	0000 0001b	→Persistent parameter corrupt error	d	
0x7320	0010 0000b	→Position sensor error	d	
0x7380	0010 0000b	→Position sensor breach error	d	X
0x738C	0010 0000b	→SSI sensor error	d	
0x738D	0010 0000b	→SSI sensor frame error	d	
0x7390	0010 0000b	→Missing main sensor error	d	
0x7391	0010 0000b	→Missing commutation sensor error	d	
0x7392	0010 0000b	→Main sensor direction error	d	X
0x8110	0001 0000b	→CAN overrun error (object lost)	a	
0x8111	0001 0000b	→CAN overrun error	a	
0x8120	0001 0000b	→CAN passive mode error	a	
0x8130	0001 0000b	→CAN heartbeat error	a	
0x8150	0001 0000b	→CAN PDO COB-ID collision	a	
0x8180	0001 0000b	→EtherCAT communication error	a	
0x8181	0001 0000b	→EtherCAT initialization error	d	
0x8182	0001 0000b	→EtherCAT Rx queue overflow	a	
0x8183	0001 0000b	→EtherCAT communication error (internal)	a	
0x8184	0001 0000b	→EtherCAT communication cycle time error	a	
0x81FD	0001 0000b	→CAN bus turned off	a	
0x81FE	0001 0000b	→CAN Rx queue overflow	a	
0x81FF	0001 0000b	→CAN Tx queue overflow	a	
0x8210	0001 0000b	→CAN PDO length error	a	
0x8250	0001 0000b	→RPDO timeout	a	
0x8280	0001 0000b	→EtherCAT PDO communication error	a	
0x8281	0001 0000b	→EtherCAT SDO communication error	a	
0x8611	1000 0000b	→Following error	f	
0x8A80	1000 0000b	→Negative limit switch error	f	
0x8A81	1000 0000b	→Positive limit switch error	f	
0x8A82	1000 0000b	→Software position limit error	f	
0xFF01	0000 0000b	→System overloaded error	w	
0xFF02	0000 0001b	→Watchdog error	d	X
0xFF0B	0000 0001b	→System peak overloaded error	d	
0xFF10	0010 0000b	→Controller gain error	f	
0xFF11	0010 0000b	→Auto tuning identification error	d	
0xFF12	0010 0000b	→Auto tuning current limit error	d	
0xFF13	0010 0000b	→Auto tuning identification current error	d	
0xFF14	0010 0000b	→Auto tuning data sampling error	d	

Continued on next page.

Error code	Error register	Name	Fault reaction code	Position clear
0xFF15	0010 0000b	➔Auto tuning sample mismatch error	d	
0xFF16	0010 0000b	➔Auto tuning parameter error	d	
0xFF17	0010 0000b	➔Auto tuning amplitude mismatch error	d	
0xFF19	0010 0000b	➔Auto tuning timeout error	d	
0xFF20	0010 0000b	➔Auto tuning standstill error	d	
0xFF21	0010 0000b	➔Auto tuning torque invalid error	d	
0xFF22	0010 0000b	➔Auto tuning max system speed error	d	
0xFF23	0010 0000b	➔Auto tuning motor connection error	d	
0xFF24	0010 0000b	➔Auto tuning sensor signal error	d	

Table 7-165 Device error codes

7.2.1 Generic error

Error code	0x1000
Error register	0000 0001b
Cause	Unspecific error occurred
Effect	Device disabled Red LED "ON" Error flag set in ➔Statusword
Error recovery	Reset fault with ➔Controlword

7.2.2 Generic initialization error

Error code	0x1080 through 0x1088
Error register	0000 0001b
Cause	Critical error occurred during boot-up
Effect	Device disabled Red LED "ON" Error flag set in ➔Statusword
Error recovery	Reset device. If the problem persists, contact your supplier.

7.2.3 Firmware incompatibility error

Error code	0x1090
Error register	0000 0001b
Cause	Incompatible extension firmware version detected
Effect	Device disabled Red LED "ON" Error flag set in ➔Statusword
Error recovery	First, try to resolve by resetting the device. If reset fails, update the firmware. If the problem persists, contact your supplier.

7.2.4 Overcurrent error

Error code	0x2310
Error register	0000 0010b
Cause	• Short circuit in motor winding • Controller gains too high and/or deceleration too high • Damaged power stage
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.5 Power stage protection error

Error code	0x2320
Error register	0000 0010b
Cause	• Short circuit of motor winding against ground • Short circuit of motor winding against operating voltage Vcc • Damaged power stage • Strong motor ripple (on top of a high peak current draw) • High deceleration or acceleration demands (which push the control to its limits) • Max. peak current configured which is close to the power stage current protection level • Poor current control parameter set
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.6 Overvoltage error

Error code	0x3210
Error register	0000 0100b
Cause	Power supply voltage too high
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	In most cases this error occurs at deceleration where the motor works as a generator and the energy flows from motor to power supply (resulting in an increased voltage). Usually, a capacitor (for example 2200 µF) close to the device will solve the problem. If not, a shunt regulator will be necessary to dissipate brake energy. Reset fault with → Controlword (only possible if supply voltage is in valid range).

7.2.7 Undervoltage error

Error code	0x3220
Error register	0000 0100b
Cause	• Supply voltage is too low for operation • Power supply cannot supply required acceleration current
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.8 Thermal overload error

Error code	0x4210
Error register	0000 1000b
Cause	Temperature at device's power stage too high
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword (only possible if temperature is in valid range)

7.2.9 Thermal motor overload error

Error code	0x4380
Error register	0000 1000b
Cause	Temperature at motor too high or sensor not connected
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword (only possible if temperature is in valid range)

7.2.10 Logic supply voltage too low error

Error code	0x5113
Error register	0000 0100b
Cause	Logic supply voltage is too low for operation
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword (only possible if supply voltage is in valid range)

7.2.11 Hardware defect error

Error code	0x5280
Error register	0000 0001b
Cause	Hardware problem detected
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset device. If the problem persists, contact your supplier.

7.2.12 Hardware incompatibility error

Error code	0x5281
Error register	0000 0001b
Cause	An incompatible hardware combination was detected
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset device. If the problem persists, contact your supplier.

7.2.13 Hardware error

Error code	0x5480 through 0x5483
Error register	0000 0001b
Cause	A hardware problem was detected
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset device. If the problem persists, contact your supplier.

7.2.14 Sign of life error

Error code	0x6080
Error register	0000 0001b
Cause	Problem with connection to extension 1: • Overload situation • Extension hardware failure
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset fault with →Controlword Check that extension 1 is firmly connected If problem reoccurs frequently: • Update firmware • Contact your supplier

7.2.15 Extension 1 watchdog error

Error code	0x6081
Error register	0000 0001b
Cause	Connection loss to extension 1: • Overload situation • Extension hardware failure
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword Check that extension 1 is firmly connected If problem reoccurs frequently: • Update firmware • Contact your supplier

7.2.16 Internal software error

Error code	0x6180 through 0x61F0
Error register	0010 0000b
Cause	An internal software error occurred
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.17 Software parameter error

Error code	0x6320
Error register	0000 0001b
Cause	Corrupt parameter detected: The constant velocity phase is too long due to high → Target position and low → Profile velocity
Effect	Fault reaction defined in → Fault reaction option code
Error recovery	Reset fault with → Controlword

7.2.18 Persistent parameter corrupt error

Error code	0x6380
Error register	0000 0001b
Cause	Persistent parameters are corrupt or inconsistent (wrong CRC)
Effect	Default parameters are set Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword Set or load device parameters again

7.2.19 Position sensor error

Error code	0x7320
Error register	0010 0000b
Cause	Detected position of position sensor is no longer valid due to... • changed/wrong position sensor parameters • other errors that influence the absolute position detection
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.20 Position sensor breach error

Error code	0x7380
Error register	0010 0000b
Cause	Position sensor supervision has detected a bad working condition due to... • wrong/broken wiring of encoder • defective encoder • regulation parameter are not well tuned (→ Current control parameter set)
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.21 SSI sensor error

Error code	0x738C
Error register	0010 0000b
Cause	SSI sensor driver could not sample position data
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.22 SSI sensor frame error

Error code	0x738D
Error register	0010 0000b
Cause	Invalid SSI sensor data frame. Start and/or stop bits have invalid state: • wrong wiring of SSI sensor • defective SSI sensor • wrong setting of encoder data bits
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.23 Missing main sensor error

Error code	0x7390
Error register	0010 0000b
Cause	No main sensor available. Adapt settings in →Axis configuration.
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset fault with →Controlword

7.2.24 Missing commutation sensor error

Error code	0x7391
Error register	0010 0000b
Cause	No commutation sensor available. Adapt settings in →Axis configuration.
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset fault with →Controlword

7.2.25 Main sensor direction error

Error code	0x7392
Error register	0010 0000b
Cause	Position sensor supervision has detected a turn-away of the motor in the opposite direction due to... • wrong setting of sensor polarity • wrong position sensor wiring • wrong motor wiring
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset fault with →Controlword

7.2.26 CAN overrun error (object lost)

Error code	0x8110
Error register	0001 0000b
Cause	One of the CAN mail boxes experienced an overflow caused by too high communication rate
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.27 CAN overrun error

Error code	0x8111
Error register	0001 0000b
Cause	Execution of CAN communication had an overrun caused by too high communication rate
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.28 CAN passive mode error

Error code	0x8120
Error register	0001 0000b
Cause	Device changed to CAN passive mode due to... • CAN bit rate of one CAN node in network wrong • CAN network not connected • hardware wiring of CAN bus not correct
Effect	Fault reaction defined in →Abort connection option code State transition defined in →Communication error
Error recovery	Send NMT command reset communication, then reset fault with →Controlword

7.2.29 CAN heartbeat error

Error code	0x8130
Error register	0001 0000b
Cause	CANopen Heartbeat Consumer Procedure or Life Guarding have detected a timeout. Probably, the procedure has failed due to wrong configuration. Heartbeat Consumers will be disabled if →Consumer heartbeat time = 0.
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Send NMT command reset communication, then reset fault with →Controlword

7.2.30 CAN PDO COB-ID collision

Error code	0x8150
Error register	0001 0000b
Cause	Possibly, another CAN node has configured the same transmit PDO COB-ID. Device has received a bad transmit PDO request (valid COB-ID without RTR bit set).
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.31 EtherCAT communication error

Error code	0x8180
Error register	0001 0000b
Cause	EtherCAT communication error during operation enable (link lost)
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.32 EtherCAT initialization error

Error code	0x8181
Error register	0001 0000b
Cause	Initialization of the Ethernet module has failed
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset device. If the problem persists, perform firmware update or contact your supplier.

7.2.33 EtherCAT Rx queue overflow

Error code	0x8182
Error register	0001 0000b
Cause	The EtherCAT receive queue had an overrun caused by... • Too high communication rate • Timing violation (eg. non-Real-time system)
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.34 EtherCAT communication error (internal)

Error code	0x8183
Error register	0001 0000b
Cause	Internal communication of the EtherCAT module has failed
Effect	Fault reaction defined in Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.35 EtherCAT communication cycle time error

Error code	0x8184
Error register	0001 0000b
Cause	EtherCAT communication error because of invalid cycle time
Effect	Fault reaction defined in Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.36 CAN bus turned off

Error code	0x81FD
Error register	0001 0000b
Cause	CAN controller has entered CAN bus off state
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.37 CAN Rx queue overflow

Error code	0x81FE
Error register	0001 0000b
Cause	One of the CAN receive queues had an overrun caused by too high communication rate
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.38 CAN Tx queue overflow

Error code	0x81FF
Error register	0001 0000b
Cause	One of the CAN transmit queues had an overrun caused by too high communication rate due to... • load on CAN bus too high • event-triggered PDOs defined with too small inhibit time • PDO communication configured too high (synchronous) for actual cycle time • CAN bus inactive but heartbeat producer enabled (→Producer heartbeat time)
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.39 CAN PDO length error

Error code	0x8210
Error register	0001 0000b
Cause	Received PDO was not processed due to length error (too short)
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.40 RPDO timeout

Error code	0x8250
Error register	0001 0000b
Cause	• Interpolation aborted in cyclic mode due to no PDO received after elapsed interpolation time period • The error also occurs if the master aborts communication, e.g. due to timing violations of the synchronous PDO transfer
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.41 EtherCAT PDO communication error

Error code	0x8280
Error register	0001 0000b
Cause	EtherCAT module detected an error at Process Data (PDO) communication
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.42 EtherCAT SDO communication error

Error code	0x8281
Error register	0001 0000b
Cause	EtherCAT module detected an error at Service Data (SDO) communication
Effect	Fault reaction defined in →Abort connection option code
Error recovery	Reset fault with →Controlword

7.2.43 Following error

Error code	0x8611
Error register	1000 0000b
Cause	Difference between →Position demand value and →Position actual value higher than →Following error window
Effect	Fault reaction defined in →Fault reaction option code
Error recovery	Reset fault with →Controlword

7.2.44 Negative limit switch error

Error code	0x8A80
Error register	1000 0000b
Cause	- Negative limit switch was/is active - Wrong configuration of limit switch function in →Digital inputs
Effect	Fault reaction defined in →Fault reaction option code
Error recovery	Reset fault with →Controlword

7.2.45 Positive limit switch error

Error code	0x8A81
Error register	1000 0000b
Cause	- Positive limit switch was/is active - Wrong configuration of limit switch function in →Digital inputs
Effect	Fault reaction defined in →Fault reaction option code
Error recovery	Reset fault with →Controlword

7.2.46 Software position limit error

Error code	0x8A82
Error register	1000 0000b
Cause	Movement commanded or actual position runs out of software position limit
Effect	Fault reaction defined in →Fault reaction option code
Error recovery	Reset fault with →Controlword

7.2.47 System overloaded error

Error code	0xFF01
Error register	0000 0000b
Cause	Device has not enough free resources to process new commands
Effect	Warning bit set in →Statusword
Error recovery	Reset fault by clearing →Diagnosis History / →Error history

7.2.48 Watchdog error

Error code	0xFF02
Error register	0000 0001b
Cause	Device reset by watchdog occurred due to fatal system overload or system fault
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset fault with →Controlword

7.2.49 System peak overloaded error

Error code	0xFF0B
Error register	0000 0001b
Cause	The device has not enough free resources to provide proper regulation
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset fault with →Controlword

7.2.50 Controller gain error

Error code	0xFF10
Error register	0010 0000b
Cause	Control function not possible due to bad controller gains
Effect	Device disabled Red LED "ON" Error flag set in →Statusword Fault reaction defined in →Fault reaction option code
Error recovery	Reset fault with →Controlword

7.2.51 Auto tuning identification error

Error code	0xFF11
Error register	0010 0000b
Cause	An error occurred during auto tuning identification
Effect	Device disabled Red LED "ON" Error flag set in →Statusword
Error recovery	Reset fault with →Controlword

7.2.52 Auto tuning current limit error

Error code	0xFF12
Error register	0010 0000b
Cause	Current limit occurred during auto tuning identification
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.53 Auto tuning identification current error

Error code	0xFF13
Error register	0010 0000b
Cause	Identification current could not be reached during auto tuning identification
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.54 Auto tuning data sampling error

Error code	0xFF14
Error register	0010 0000b
Cause	Data sampling initialization has failed
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.55 Auto tuning sample mismatch error

Error code	0xFF15
Error register	0010 0000b
Cause	Sample data mismatched during auto tuning identification
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.56 Auto tuning parameter error

Error code	0xFF16
Error register	0010 0000b
Cause	Wrong parameter for auto tuning identification. Error during identification auto tuning process
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.57 Auto tuning amplitude mismatch error

Error code	0xFF17
Error register	0010 0000b
Cause	Nominal actual amplitude mismatch during auto tuning identification
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.58 Auto tuning timeout error

Error code	0xFF19
Error register	0010 0000b
Cause	Auto tuning identification timeout. Termination requirements not met
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.59 Auto tuning standstill error

Error code	0xFF20
Error register	0010 0000b
Cause	Motor did not reach standstill during auto tuning. Make sure that the motor is not moving when starting the tuning process.
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.60 Auto tuning torque invalid error

Error code	0xFF21
Error register	0010 0000b
Cause	Motor movement has been obstructed during tuning process. This might be caused by e.g. the motor being connected to a rigid gear. Ensure that the motor movement is not obstructed.
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.61 Auto tuning max system speed error

Error code	0xFF22
Error register	0010 0000b
Cause	Max system speed exceeded during auto tuning identification. Reduce step amplitude to reduce max speed.
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.62 Auto tuning motor connection error

Error code	0xFF23
Error register	0010 0000b
Cause	Identification current is very small. Check the motor connection.
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.2.63 Auto tuning sensor signal error

Error code	0xFF24
Error register	0010 0000b
Cause	Sensor signal was not found during tuning identification. Check the sensor and motor connections.
Effect	Device disabled Red LED "ON" Error flag set in → Statusword
Error recovery	Reset fault with → Controlword

7.3 CANopen Communication Errors (Abort Codes)

An abort object will be sent over the network instead of a response to a SDO request if the request has failed. The same abort code will be sent as part of the response to other transfer request (such as USB).

The following abort codes are defined by CANopen Communication Profile CiA 301. Codes greater 0x0F00 0000 are maxon-specific.

Abort code	Name	Cause
0x0000 0000	No abort	Communication successful
0x0503 0000	Toggle error	Toggle bit not alternated
0x0504 0000	SDO timeout	SDO protocol timed out
0x0504 0001	Command unknown	Command specifier unknown
0x0504 0004	CRC error	CRC check failed
0x0601 0000	Access error	Unsupported access to an object
0x0601 0001	Write only error	Read command to a write only object
0x0601 0002	Read only error	Write command to a read only object
0x0601 0003	Subindex cannot be written	Subindex cannot be written, subindex 0 must be "0" (zero) for write access
0x0601 0004	SDO complete access not supported	The object can not be accessed via complete access
0x0602 0000	Object does not exist error	Last read or write command had wrong object index or subindex
0x0604 0041	PDO mapping error	Object is not mappable to the PDO
0x0604 0042	PDO length error	Number and length of objects to be mapped would exceed PDO length
0x0604 0043	General parameter error	General parameter incompatibility
0x0604 0047	General internal incompatibility error	General internal incompatibility in device
0x0606 0000	Hardware error	Access failed due to hardware error
0x0607 0010	Service parameter error	Data type does not match, length or service parameter do not match
0x0607 0013	Service parameter too short error	Data type does not match, length of service parameter too low
0x0609 0011	Subindex error	Last read or write command had wrong object subindex
0x0609 0030	Value range error	Value range of parameter exceeded
0x0800 0000	General error	General error
0x0800 0020	Transfer or store error	Data cannot be transferred or stored
0x0800 0022	Wrong device state error	Data cannot be transferred or stored to application because of present device state
0x0F00 FFBE	Password error	Password is incorrect
0x0F00 FFBF	Illegal command error	Command code is illegal (does not exist)
0x0F00 FFC0	Wrong NMT state error	Device is in wrong NMT state

Table 7-166 CANopen communication errors

7.4 EtherCAT FoE Error Codes

In the event of a communication error during a File over EtherCAT (FoE) transfer, the following error codes as defined in the ETG.1020 V1.2.0 EtherCAT Protocol Enhancements Specification (➔[13]) will be used.

Error code	Name	Cause
0x8002	Access denied	Unsupported access to an object
0x8004	Illegal	Data cannot be transferred or stored to application due to present device state
0x8008	Bootstrap only	FoE download is supported in bootstrap state only
0x8009	Not bootstrap	The downloaded file is not accepted for firmware updates
0x800B	Program error	Firmware programming was aborted due to a general internal error
0x800C	Checksum wrong	The checksum of the downloaded file was wrong
0x800D	Firmware does not fit for hardware	The firmware file is incompatible to the device hardware
0x8011	Flash problem	The flash memory of the device could not be erased or programmed
0x8012	File incompatible	The firmware format is incompatible to the device

Table 7-167 EtherCAT FoE communication error codes

••page intentionally left blank••

8 FIRMWARE VERSION HISTORY

8.1 Version Overview

Date [yyyy-mm]	Version		Application		Description
	Software	Hardware	#	Version	
2025-05	0180h	6650h, 6751h	0000h	0000h	New features, bug fixing
2021-04	0170h	6650h, 6751h	0000h	0000h	New hardware, new features, bug fixing
2020-04	0161h	6751h	0000h	0000h	Bug fixing
2019-11	0160h	6751h	0000h	0000h	Initial release

Table 8-168 Version overview

8.2 Version History

IDX_0180h_xxxxh_0000h_0000h (Release 2025-05)		
Binary Files	IDX 56	IDX_0180h_6751h_0000h_0000h.bin
	IDX 70	IDX_0180h_6650h_0000h_0000h.bin
Features	Homing	New objects 0x605D "Halt option code" and 0x607C "Home offset" for SPS homing function-block compatibility
	CSV mode	Torque offset functionality added
Changes	EtherCAT communication	The error detection mechanism related to RX queue overflow (Error 0x8182) has been modified.
	CAN auto bitrate detection	Startup, reset behavior improved
	Bugfix	Limit switch handling with EtherCAT communication fixed
	Bugfix	Halt state behavior in homing mode corrected
	Bugfix	Target position and target velocity handling in disabled state corrected
	Bugfix	General minor bug fixing and improvements

IDX_0170h_xxxxh_0000h_0000h (Release 2021-04)		
Binary Files	IDX 56	IDX_0170h_6751h_0000h_0000h.bin
	IDX 70	IDX_0170h_6650h_0000h_0000h.bin
Features	Introduction	«IDX 70»
	Position window	Position window functionality for PPM and HMM added
	Controller identification	Optical node identification by blinking LED added
	System monitoring	Actual PWM duty cycle object added
	Drive protection	Objects to configure the undervoltage, overvoltage, and thermal overload error limits added
	Error behavior	NMT state in case of CAN heartbeat error is new configurable
	SSI encoder	Homing methods with (virtual) index added
Changes	CAN communication	Support of Node-ID 255 (undefined) added (used as default value if no valid preset)
	EtherCAT communication	Check of minimal cycle time added. Process data latency improved.
	Regulation tuning	Improvements and corrections in regulation tuning system identification
	Velocity controller	Velocity controller filter cut off frequency object (0x30A2; 0x05) added
	Position controller	Position controller I gain scaling object (0x30A1; 0x09) added
	System monitoring	System overload signalization changed to warning (instead of error)
	Bugfix	Touch probe: occasionally wrong sensor index detection corrected
	Bugfix	CAN PDO: unexpected "CAN Rx queue overflow error" at overlapping PDO and SYNC frames fixed
	Bugfix	PPM with dual loop configuration: sporadic trajectory discontinuity corrected
	Bugfix	General minor bug fixing and improvements

IDX_0161h_xxxxh_0000h_0000h (Release 2020-04)		
Binary Files	IDX 56	IDX_0161h_6751h_0000h_0000h.bin
Changes	Bugfix	Transfer of occasionally incorrect actual position values via EtherCAT resolved

IDX_0160h_xxxxh_0000h_0000h (Release 2019-11)		
Binary Files	IDX 56	IDX_0160h_6751h_0000h_0000h.bin
Features	Full range	Initial release

LIST OF FIGURES

Figure 1-1	Documentation structure	7
Figure 2-2	Communication architecture	13
Figure 2-3	Device State Machine	14
Figure 3-4	Functional architecture	19
Figure 3-5	Profile Position Mode – Block diagram	21
Figure 3-6	Profile position trajectory – Linear ramp (trapezoidal profile)	22
Figure 3-7	Profile Position Mode – Setpoint (example)	24
Figure 3-8	Profile Velocity Mode – Block diagram	25
Figure 3-9	Profile velocity trajectory – Linear ramp (trapezoidal profile)	25
Figure 3-10	Profile velocity trajectory – Setpoint and acceleration behavior (example)	27
Figure 3-11	Homing Mode – Block diagram	28
Figure 3-12	Homing trajectory – Linear ramp (trapezoidal profile)	28
Figure 3-13	Homing method 1	31
Figure 3-14	Homing method 2	31
Figure 3-15	Homing method 7	32
Figure 3-16	Homing method 11	32
Figure 3-17	Homing method 17	33
Figure 3-18	Homing method 18	33
Figure 3-19	Homing method 23	33
Figure 3-20	Homing method 27	34
Figure 3-21	Homing method 33	34
Figure 3-22	Homing method 34	34
Figure 3-23	Homing method 37 (disabled)	35
Figure 3-24	Homing method 37 (enabled)	35
Figure 3-25	Homing method -1	35
Figure 3-26	Homing method -2	36
Figure 3-27	Homing method -3	36
Figure 3-28	Homing method -4	36
Figure 3-29	Cyclic Synchronous Position Mode – Overview	37
Figure 3-30	Cyclic Synchronous Position Mode – Block diagram	38
Figure 3-31	Cyclic Synchronous Velocity Mode – Overview	41
Figure 3-32	Cyclic Synchronous Velocity Mode – Block diagram	41
Figure 3-33	Cyclic Synchronous Torque Mode – Overview	44
Figure 3-34	Cyclic Synchronous Torque Mode – Block diagram	44
Figure 3-35	Position Control Function – Block diagram	47
Figure 3-36	Velocity Control Function – Block diagram	49
Figure 3-37	Current Control Function – Block diagram	51
Figure 4-38	Digital input functionality	53
Figure 4-39	Digital output functionality	54
Figure 4-40	Analog input functionality	55
Figure 6-41	SSI encoder – Data rate vs. cable length	138

Figure 6-42 SSI encoder – Data frame 139

Figure 6-43 SSI encoder – Timing 141

Figure 6-44 Block commutation of EC (BLDC) motors – Definition of phases..... 143

Figure 6-45 SSI encoder – Data bits 144

Figure 6-46 Standstill window 159

Figure 6-47 Holding brake activation timing (digital output polarity “High active”)..... 166

Figure 6-48 Analog input current set value properties – Setpoint function 172

Figure 6-49 Analog input current set value properties – Set value 172

Figure 6-50 Analog input velocity set value properties – Setpoint function 175

Figure 6-51 Analog input velocity set value properties – Set value 175

Figure 6-52 Position window 190

LIST OF TABLES

Table 1-1	Notations used	8
Table 1-2	Abbreviations & acronyms used	8
Table 1-3	Brand names and trademark owners	9
Table 1-4	Sources for additional information.	10
Table 2-5	Device state bits	15
Table 2-6	Device state transitions	16
Table 2-7	Axis control commands	16
Table 2-8	User-defined units – Parameter structure	17
Table 2-9	SI units – Notation index	17
Table 2-10	CiA 402 Application profile-specific units – Notation index	17
Table 2-11	Unit prefixes – Notation index	18
Table 3-12	Profile Position Mode – Configuration parameters	22
Table 3-13	Profile Position Mode – Commanding parameters	23
Table 3-14	Profile Position Mode – Controlword.	23
Table 3-15	Profile Position Mode – Controlword bits	23
Table 3-16	Profile Position Mode – Output parameters	23
Table 3-17	Profile Position Mode – Statusword	24
Table 3-18	Profile Position Mode – Statusword bits	24
Table 3-19	Profile Velocity Mode – Configuration parameters	26
Table 3-20	Profile Velocity Mode – Commanding parameters	26
Table 3-21	Profile Velocity Mode – Controlword	26
Table 3-22	Profile Velocity Mode – Controlword bits.	26
Table 3-23	Profile Velocity Mode – Output parameters.	26
Table 3-24	Profile Velocity Mode – Statusword.	27
Table 3-25	Profile Velocity Mode – Statusword bits	27
Table 3-26	Homing Mode – Configuration parameters	29
Table 3-27	Homing Mode – Commanding parameters	29
Table 3-28	Homing Mode – Controlword.	29
Table 3-29	Homing Mode – Controlword bits	29
Table 3-30	Homing Mode – Output parameters	30
Table 3-31	Homing Mode – Statusword	30
Table 3-32	Homing Mode – Statusword bit 15	30
Table 3-33	Homing Mode – Statusword bits 10, 12, and 13	30
Table 3-34	Cyclic Synchronous Position Mode – Configuration parameters	39
Table 3-35	Cyclic Synchronous Position Mode – Commanding parameters	39
Table 3-36	Cyclic Synchronous Position Mode – Output parameters.	40
Table 3-37	Cyclic Synchronous Position Mode – Statusword.	40
Table 3-38	Cyclic Synchronous Position Mode – Statusword bits	40
Table 3-39	Cyclic Synchronous Velocity Mode – Configuration parameters.	42
Table 3-40	Cyclic Synchronous Velocity Mode – Commanding parameters.	42
Table 3-41	Cyclic Synchronous Velocity Mode – Output parameters	42

Table 3-42	Cyclic Synchronous Velocity Mode – Statusword	43
Table 3-43	Cyclic Synchronous Velocity Mode – Statusword bits	43
Table 3-44	Cyclic Synchronous Torque Mode – Configuration parameters	45
Table 3-45	Cyclic Synchronous Torque Mode – Commanding parameters	45
Table 3-46	Cyclic Synchronous Torque Mode – Output parameters	45
Table 3-47	Cyclic Synchronous Torque Mode – Statusword	46
Table 3-48	Cyclic Synchronous Torque Mode – Statusword bits	46
Table 3-49	Position Control Function – Configuration parameters	47
Table 3-50	Position Control Function – Output parameters	48
Table 3-51	Velocity Control Function – Configuration parameters	49
Table 3-52	Velocity Control Function – Output Parameters	50
Table 3-53	Current Control Function – Configuration parameters	51
Table 3-54	Current Control Function – Output parameters	52
Table 6-55	Object data types	59
Table 6-56	Object codes	59
Table 6-57	Object access types	59
Table 6-58	Object flags	60
Table 6-59	Object Dictionary (overview)	63
Table 6-60	Error register bits	64
Table 6-61	Error history structure	66
Table 6-62	Store parameters signature	67
Table 6-63	Restore default parameters signature	68
Table 6-64	Consumer heartbeat time – Structure	69
Table 6-65	Definition of hardware version	71
Table 6-66	Error behavior in case of CAN heartbeat error	72
Table 6-67	Newest acknowledged message – Read/Write bits	74
Table 6-68	Flags – Read/Write bits	75
Table 6-69	Diagnosis messages	76
Table 6-70	COB-ID used by RxPDO – Structure	78
Table 6-71	COB-ID used by RxPDO – Description	78
Table 6-72	Receive PDO mapping – Structure of mapped object	83
Table 6-73	Receive PDO 1 mapping	84
Table 6-74	Receive PDO 2 mapping	86
Table 6-75	Receive PDO 3 mapping	87
Table 6-76	Receive PDO 4 mapping	89
Table 6-77	COB-ID used by TxPDO – Structure	90
Table 6-78	COB-ID used by TxPDO – Description	90
Table 6-79	Transmit PDO mapping – Structure of mapped object	96
Table 6-80	Transmit PDO 1 mapping	97
Table 6-81	Transmit PDO 2 mapping	99
Table 6-82	Transmit PDO 3 mapping	100
Table 6-83	Transmit PDO 4 mapping	102
Table 6-84	SYNC mode output parameters	106
Table 6-85	Synchronization types supported – Output parameters	107

Table 6-86	Sync values	109
Table 6-87	SYNC mode input parameters	110
Table 6-88	Synchronization types supported – Input parameters	111
Table 6-89	Sync values	113
Table 6-90	Program control – Value range	114
Table 6-91	Program software identification – Value range	115
Table 6-92	Flash status identification – Value range	117
Table 6-93	CAN bit rate	119
Table 6-94	Fieldbus type	120
Table 6-95	Active controller type	121
Table 6-96	Extension 1 hardware – Version definition	122
Table 6-97	Extension communication type	124
Table 6-98	Power supply voltage – Undervoltage limit	126
Table 6-99	Power supply voltage – Hysteresis	126
Table 6-100	Power supply voltage – Overvoltage limit	127
Table 6-101	Sensor configuration – Bits	128
Table 6-102	Supported sensor types	128
Table 6-103	Control structure – Bits	129
Table 6-104	Commutation sensors – Bits	130
Table 6-105	Commutation sensors – Value range	130
Table 6-106	Axis configuration miscellaneous – Bits	131
Table 6-107	Max system speed – Limits	132
Table 6-108	Max system speed – Speed limitations based on velocity units	132
Table 6-109	Gear velocity limits	137
Table 6-110	Gear miscellaneous configuration – Bits	137
Table 6-111	SSI encoder – Number of data bits	139
Table 6-112	SSI encoder – Protocol	140
Table 6-113	SSI position bits	144
Table 6-114	SI units velocity – Bits	149
Table 6-115	SI units velocity – Value range	149
Table 6-116	Digital input bits	161
Table 6-117	Digital inputs – Default values	162
Table 6-118	Digital inputs – Configuration	163
Table 6-119	Digital output bits	164
Table 6-120	Digital outputs – Default values	165
Table 6-121	Digital outputs – Configuration	165
Table 6-122	Holding brake states	167
Table 6-123	Analog inputs – Default values	169
Table 6-124	Analog inputs – Configuration	169
Table 6-125	Maximal temperature power stage	179
Table 6-126	Abort connection option code	180
Table 6-127	Controlword bits	182
Table 6-128	Statusword bits	184
Table 6-129	Quick stop option code	184

Table 6-130	Shutdown option code	185
Table 6-131	Disable operation option code	185
Table 6-132	Halt option code	186
Table 6-133	Fault reaction option code	186
Table 6-134	Modes of operation	187
Table 6-135	Motion profile types	199
Table 6-136	Homing methods	200
Table 6-137	SI units position – Bits	202
Table 6-138	SI units position – Value range	202
Table 6-139	SI units velocity – Bits	203
Table 6-140	SI units velocity – Value range	203
Table 6-141	SI units acceleration – Bits	204
Table 6-142	SI units acceleration – Value range	204
Table 6-143	Touch probe function	206
Table 6-144	Touch probe status	207
Table 6-145	Touch probe 1 source	211
Table 6-146	Touch probe 1 positive edge counter	212
Table 6-147	Touch probe 1 negative edge counter	212
Table 6-148	Digital inputs	219
Table 6-149	Digital outputs	220
Table 6-150	Motor types	221
Table 6-151	Supported drive modes – Bits	222
Table 6-152	Configured module identification – Bits	224
Table 6-153	Configured module identification types	225
Table 6-154	MDP module PPM mapping – Default values for RxPDO	226
Table 6-155	MDP module PPM mapping – Default values for TxPDO	226
Table 6-156	MDP module PVM mapping – Default values for RxPDO	227
Table 6-157	MDP module PVM mapping – Default values for TxPDO	227
Table 6-158	MDP module CSP mapping – Default values for RxPDO	228
Table 6-159	MDP module CSP mapping – Default values for TxPDO	228
Table 6-160	MDP module CSV mapping – Default values for RxPDO	229
Table 6-161	MDP module CSV mapping – Default values for TxPDO	229
Table 6-162	MDP module CST mapping – Default values for RxPDO	230
Table 6-163	MDP module CST mapping – Default values for TxPDO	230
Table 7-164	Emergency message frame	231
Table 7-165	Device error codes	233
Table 7-166	CANopen communication errors	248
Table 7-167	EtherCAT FoE communication error codes	249
Table 8-168	Version overview	251

INDEX

Numerics

10th supported homing method (object) 216
 11th supported homing method (object) 216
 12th supported homing method (object) 217
 13th supported homing method (object) 217
 14th supported homing method (object) 217
 15th supported homing method (object) 218
 1st assigned RxPDO (object) 104
 1st assigned TxPDO (object) 105
 1st mapped object in RxPDO 1 (object) 84
 1st mapped object in RxPDO 2 (object) 85
 1st mapped object in RxPDO 3 (object) 87
 1st mapped object in RxPDO 4 (object) 88
 1st mapped object in TxPDO 1 (object) 97
 1st mapped object in TxPDO 2 (object) 98
 1st mapped object in TxPDO 3 (object) 100
 1st mapped object in TxPDO 4 (object) 101
 1st supported homing method (object) 213
 2nd supported homing method (object) 213
 3rd supported homing method (object) 214
 4th supported homing method (object) 214
 5th supported homing method (object) 214
 6th supported homing method (object) 215
 7th supported homing method (object) 215
 8th supported homing method (object) 215
 9th supported homing method (object) 216

A

abbreviations & acronyms 8
 abort codes 248
 Abort connection option code (object) 180
 Access denied (error code) 249
 Access error (abort code) 248
 access types 59
 Active controller type (object) 121
 Active fieldbus (object) 120
 Additional identity (object) 121
 Analog input 1...2 adjustment offset (object) 171
 Analog input 1...2 configuration (object) 169
 Analog input 1...2 voltage (object) 168
 Analog input adjustment (object) 171
 Analog input current set value properties (object) 172
 analog input functionality 55
 Analog input general purpose (object) 170
 Analog input general purpose A...B (object) 170
 Analog input properties (object) 168
 Analog input velocity set value properties (object) 175
 applicable EU directive 11
 Auto tuning amplitude mismatch error (error message) 246

Auto tuning current limit error (error message) 245
 Auto tuning data sampling error (error message) 245
 Auto tuning identification current error (error message) 245
 Auto tuning identification error (error message) 244
 Auto tuning max system speed error (error message) 247
 Auto tuning motor connection error (error message) 247
 Auto tuning parameter error (error message) 245
 Auto tuning sample mismatch error (error message) 245
 Auto tuning sensor signal error (error message) 247
 Auto tuning standstill error (error message) 246
 Auto tuning timeout error (error message) 246
 Auto tuning torque invalid error (error message) 246
 Axis configuration (object) 128
 Axis configuration miscellaneous (object) 131

B

binary files 251
 bit rate
 CAN 119
 Bootstrap only (error code) 249

C

Calc and copy time (object) 108, 112
 CAN bit rate (object) 119
 CAN bit rate display (object) 120
 CAN bus turned off (error message) 241
 CAN heartbeat error (error message) 240
 CAN overrun error (error message) 240
 CAN overrun error (object lost) (error message) 239
 CAN passive mode error (error message) 240
 CAN PDO COB-ID collision (error message) 240
 CAN PDO length error (error message) 242
 CAN Rx queue overflow (error message) 242
 CAN Tx queue overflow (error message) 242
 CANopen communication errors 248
 Checksum wrong (error code) 249
 COB-ID EMCY (object) 68
 COB-ID SDO client to server (object) 77
 COB-ID SDO server to client (object) 77
 COB-ID SYNC (object) 66
 COB-ID used by RxPDO 1 (object) 78
 COB-ID used by RxPDO 2 (object) 80
 COB-ID used by RxPDO 3 (object) 81
 COB-ID used by RxPDO 4 (object) 82
 COB-ID used by TxPDO 1 (object) 89
 COB-ID used by TxPDO 2 (object) 91
 COB-ID used by TxPDO 3 (object) 93
 COB-ID used by TxPDO 4 (object) 94
 Command unknown (abort code) 248
 communication 57
 Communication error (object) 72

Communication type SYNC channel 0 (object) 103
 Communication type SYNC channel 1 (object) 103
 Communication type SYNC channel 2 (object) 103
 Communication type SYNC channel 3 (object) 103
 Commutation sensors (object) 130
 Configuration of analog inputs (object) 169
 Configuration of digital inputs (object) 162
 Configuration of digital outputs (object) 165
 Configured module ident list (object) 224
 Consumer 1...2 heartbeat time (object) 69
 Consumer heartbeat time (object) 69
 Control structure (object) 129
 Controller gain error (error message) 244
 Controlword (object) 182
 CRC error (abort code) 248
 CST (Cyclic Synchronous Torque Mode) 44
 CSV (Cyclic Synchronous Velocity Mode) 41
 current (units) 17
 Current actual value (object) 156
 Current actual value averaged (object) 156
 Current actual values (object) 156
 Current control parameter set (object) 146
 Current controller I gain (object) 146
 Current controller P gain (object) 146
 Current demand value (object) 155
 Current set value first current (object) 173
 Current set value first voltage (object) 173
 Current set value second current (object) 174
 Current set value second voltage (object) 173
 Current threshold for homing mode (object) 155
 Custom persistent memory (object) 124
 Custom persistent memory 1...4 (object) 124
 Cycle time (object) 106, 110
 Cycle time too small (object) 109, 112
 Cyclic Synchronous Position Mode (brief description) 20
 Cyclic Synchronous Torque Mode (brief description) 20
 Cyclic Synchronous Velocity Mode (brief description) 20

D

Delay time (object) 108
 Detected module ident list (object) 225
 Device type (object) 64
 Diagnosis History (object) 73
 Diagnosis message 1...5 (object) 76
 Digital input 1...4 configuration (object) 162
 digital input functionality 53
 Digital input properties (object) 161
 Digital inputs (object) 219
 Digital inputs logic state (object) 161
 Digital inputs polarity (object) 161
 Digital output 1...2 configuration (object) 165
 digital output functionality 54
 Digital output properties (object) 164
 Digital outputs (object) 220
 Digital outputs logic state (object) 164

Digital outputs polarity (object) 164
 dimensionless (units) 17
 Disable operation option code (object) 185

E

electric current (units) 17
 Electrical inductance (object) 135
 Electrical resistance (object) 135
 Electrical system parameters (object) 135
 Error behavior (object) 72
 Error code (object) 181
 Error history (object) 65
 Error history 1...5 (object) 66
 Error register (object) 64
 errors
 communication 248
 device 231
 EtherCAT communication error (internal) (error message) 241
 EtherCAT communication cycle time error (error message) 241
 EtherCAT communication error (error message) 240
 EtherCAT error codes 249
 EtherCAT initialization error (error message) 241
 EtherCAT PDO communication error (error message) 242
 EtherCAT Rx queue overflow (error message) 241
 EtherCAT SDO communication error (error message) 243
 EU directive, applicable 11
 Extension 1 application number (object) 123
 Extension 1 application version (object) 123
 Extension 1 hardware version (object) 122
 Extension 1 identity (object) 122
 Extension 1 serial number (object) 123
 Extension 1 software version (object) 122
 Extension 1 type (object) 124
 Extension 1 watchdog error (error message) 237

F

Fault reaction option code (object) 186
 File incompatible (error code) 249
 Firmware does not fit for hardware (error code) 249
 Firmware incompatibility error (error message) 233
 firmware versions 251
 flags 60
 Flags (object) 75
 Flash problem (error code) 249
 Flash status identification (object) 116
 Following error (error message) 243
 Following error actual value (object) 218
 Following error time out (object) 189
 Following error window (object) 188

G

gateway communication 57
 Gear configuration (object) 136
 Gear miscellaneous configuration (object) 137
 Gear reduction denominator (object) 136
 Gear reduction numerator (object) 136
 General error (abort code) 248
 General internal incompatibility error (abort code) 248
 General parameter error (abort code) 248
 Generic error (error message) 233
 Generic initialization error (error message) 233

H

Halt option code (object) 186
 hardware binary files 251
 Hardware defect error (error message) 236
 Hardware error (abort code) 248
 Hardware error (error message) 236
 Hardware incompatibility error (error message) 236
 hardware versions 71
 HMM (Homing Mode) 28
 Holding brake coupling time (object) 167
 Holding brake opening time (object) 167
 Holding brake parameters (object) 166
 Holding brake state (object) 167
 Home offset (object) 195
 Home offset move distance (object) 154
 Home position (object) 154
 Homing 28
 Homing acceleration (object) 202
 Homing method (object) 200
 Homing Mode (brief description) 20
 Homing speeds (object) 201
 how to
 decode abbreviations and acronyms 8
 interpret icons and signs used in the document 9
 use Current Control Function 51
 use Cyclic Synchronous Torque Mode 39, 45
 use Cyclic Synchronous Velocity Mode 42
 use Homing Mode 29
 use Position Control Function 47
 use Profile Position Mode 22
 use Profile Velocity Mode 26
 use Velocity Control Function 49

I

I2t level power stage (object) 177
 Identity object (object) 70
 Illegal (error code) 249
 Illegal command error (abort code) 248
 increments (units) 17
 Index distance (object) 223
 Inhibit time TxPDO 1 (object) 91
 Inhibit time TxPDO 2 (object) 92

Inhibit time TxPDO 3 (object) 94
 Inhibit time TxPDO 4 (object) 95
 input functionality 53, 55
 Internal software error (error message) 237
 Interpolation time index (object) 210
 Interpolation time period (object) 209
 Interpolation time period value (object) 209

L

length (units) 17
 Logic supply voltage too low error (error message) 235

M

Main sensor direction error (error message) 239
 Main sensor resolution (object) 131
 Manufacturer device name (object) 67
 mass (units) 17
 Max acceleration (object) 210
 Max gear input speed (object) 137
 Max motor speed (object) 197
 Max position limit (object) 196
 Max position range limit (object) 194
 Max profile velocity (object) 196
 Max system speed (object) 132
 Maximal temperature power stage (object) 179
 Maximum messages (object) 73
 Maximum number of modules (object) 223
 Min position limit (object) 195
 Min position range limit (object) 194
 Minimum cycle time (object) 107, 111
 Missing commutation sensor error (error message) 239
 Missing main sensor error (error message) 239
 Modes of operation (object) 187
 Modes of operation display (object) 187
 modes, supported 20
 Modular device profile (object) 223
 Module 1, configured (object) 224
 Module 1, detected (object) 225
 Motion profile type (object) 199
 Motor control (object) 180
 Motor data (object) 133
 Motor rated torque (object) 192
 Motor type (object) 221

N

Nbr of configured modules (object) 224
 Nbr of detected modules (object) 225
 Negative limit switch error (error message) 243
 New messages available (object) 74
 Newest acknowledged message (object) 74
 Newest message (object) 73
 No abort (abort code) 248
 Node-ID (object) 118
 Nominal current (object) 133
 Not bootstrap (error code) 249

Number of assigned RxPDOs (object) 104
Number of assigned TxPDOs (object) 105
Number of errors (object) 65
Number of mapped objects in RxPDO 1 (object) 83
Number of mapped objects in RxPDO 2 (object) 85
Number of mapped objects in RxPDO 3 (object) 86
Number of mapped objects in RxPDO 4 (object) 88
Number of mapped objects in TxPDO 1 (object) 96
Number of mapped objects in TxPDO 2 (object) 98
Number of mapped objects in TxPDO 3 (object) 99
Number of mapped objects in TxPDO 4 (object) 101
Number of pole pairs (object) 134
Number of used SYNC manager channels (object) 102

O

object codes 59
Object does not exist error (abort code) 248
object lost (see “CAN overrun error”)
object overview 60
operating license 11
Output current limit (object) 133
output functionality 54
Overcurrent error (error message) 234
overview (objects) 60
Overvoltage error (error message) 234

P

Password error (abort code) 248
PDO length error (abort code) 248
PDO mapping error (abort code) 248
Persistent parameter corrupt error (error message) 237
Physical outputs (object) 220
Position actual value (object) 188
Position control parameter set (object) 147
Position controller D gain (object) 148
Position controller FF acceleration gain (object) 148
Position controller FF velocity gain (object) 148
Position controller I gain (object) 147
Position controller P gain (object) 147
Position demand value (object) 188
Position offset (object) 204
Position range limit (object) 194
Position sensor breach error (error message) 238
Position sensor error (error message) 238
Position window (object) 190
Position window time (object) 191
Positive limit switch error (error message) 243
Power limitation (object) 177
Power stage protection error (error message) 234
Power supply (object) 125
Power supply overvoltage limit (object) 127
Power supply supervision (object) 126
Power supply undervoltage limit (object) 126
Power supply voltage (object) 125
PPM (Profile Position Mode) 21

prerequisites prior installation 11
Producer heartbeat time (object) 70
Product code (object) 71
Profile acceleration (object) 198
Profile deceleration (object) 198
Profile Position Mode (brief description) 20
Profile velocity (object) 197
Profile Velocity Mode (brief description) 20
Program control (object) 114
Program data (object) 113
Program error (error code) 249
Program number 1 (object)
 Flash status identification 116
 Program control 114
 Program data 113
 Program software identification 115
Program software identification (object) 115
purpose of this document 7
PVM (Profile Velocity Mode) 25
PWM duty cycle actual value (object) 180

Q

Quick stop deceleration (object) 198
Quick stop option code (object) 184

R

Read only error (abort code) 248
Receive PDO 1 mapping (object) 83
Receive PDO 1 parameter (object) 78
Receive PDO 2 mapping (object) 85
Receive PDO 2 parameter (object) 80
Receive PDO 3 mapping (object) 86
Receive PDO 3 parameter (object) 81
Receive PDO 4 mapping (object) 88
Receive PDO 4 parameter (object) 82
reference point (see “Homing”)
Restore all default parameters (object) 68
Restore default parameters (object) 68
Revision number (object) 71
revolutions (units) 17
RPDO timeout (error message) 242

S

Save all parameters (object) 67
SDO complete access not supported (abort code) 248
SDO server parameter (object) 77
SDO timeout (abort code) 248
sensor types 128
Sensors configuration (object) 128
Serial number (object) 71
Serial number complete (object) 121
Service parameter error (abort code) 248
Service parameter too short error (abort code) 248
Shutdown option code (object) 185
SI unit acceleration (object) 204

SI unit position (object) 202
SI unit position controller I gain (object) 149
SI unit velocity (object) 203
Sign of life error (error message) 236
signs used 9
SM-event missed (object) 108, 112
Software parameter error (error message) 237
Software position limit (object) 195
Software position limit error (error message) 243
Speed for switch search (object) 201
Speed for zero search (object) 201
SSI absolute encoder (object) 138
SSI commutation offset value (object) 143
SSI data rate (object) 138
SSI encoding type (object) 140
SSI number of data bits (object) 139
SSI position bits (object) 144
SSI position raw value (object) 142
SSI position raw value complete (object) 145
SSI power up time (object) 142
SSI refresh frequency (object) 142
SSI sensor error (error message) 238
SSI sensor frame error (error message) 238
SSI special bits leading data (object) 145
SSI special bits trailing data (object) 141
SSI timeout time (object) 141
Standstill window (object) 160
Standstill window configuration (object) 159
Standstill window time (object) 160
Standstill window timeout (object) 160
Statusword (object) 183
steps (units) 17
Store parameters (object) 67
Subindex cannot be written (abort code) 248
Subindex error (abort code) 248
Supported drive modes (object) 222
Supported homing methods (object) 213
supported modes 20
symbols used 9
Sync error (object) 109, 113
SYNC manager 2 parameter (object) 106
SYNC manager 2 PDO assignment (object) 104
SYNC manager 3 parameter (object) 110
SYNC manager 3 PDO assignment (object) 105
SYNC manager communication type (object) 102
Synchronization type (object) 106, 110
Synchronization types supported, input (object) 111
Synchronization types supported, output (object) 107
System overloaded error (error message) 244
System peak overloaded error (error message) 244

T

Target position (object) 193
Target torque (object) 192
Target velocity (object) 221

Temperature motor (object) 178
Temperature power stage (object) 178
Thermal motor overload error (error message) 235
Thermal overload error (error message) 235
Thermal overload protection (object) 178
Thermal time constant winding (object) 134
time (units) 17
Toggle error (abort code) 248
Torque actual value (object) 192
Torque actual value averaged (object) 157
Torque actual values (object) 157
Torque constant (object) 134
Torque offset (object) 205
Touch probe 1 negative edge (object) 208
Touch probe 1 negative edge counter (object) 212
Touch probe 1 positive edge (object) 207
Touch probe 1 positive edge counter (object) 212
Touch probe 1 source (object) 211
Touch probe function (object) 206
Touch probe source (object) 211
Touch probe status (object) 207
trajectory generator
 Homing 28
 Profile Position 22
 Profile Velocity 25

Transfer or store error (abort code) 248
Transmission type RxPDO 1 (object) 79
Transmission type RxPDO 2 (object) 80
Transmission type RxPDO 3 (object) 81
Transmission type RxPDO 4 (object) 82
Transmission type TxPDO 1 (object) 90
Transmission type TxPDO 2 (object) 92
Transmission type TxPDO 3 (object) 93
Transmission type TxPDO 4 (object) 95
Transmit PDO 1 mapping (object) 96
Transmit PDO 1 parameter (object) 89
Transmit PDO 2 mapping (object) 98
Transmit PDO 2 parameter (object) 91
Transmit PDO 3 mapping (object) 99
Transmit PDO 3 parameter (object) 93
Transmit PDO 4 mapping (object) 101
Transmit PDO 4 parameter (object) 94

U

Undervoltage error (error message) 235
units (definition of) 17
USB frame timeout (object) 119
USB-to-CAN gateway 57

V

Value range error (abort code) 248
velocity (units) 17
Velocity actual value (object) 191
Velocity actual value averaged (object) 158
Velocity actual values (object) 158

Velocity control parameter set (object) 150
Velocity controller FF acceleration gain (object) 151
Velocity controller FF velocity gain (object) 151
Velocity controller filter cut-off frequency (object) 151
Velocity controller I gain (object) 150
Velocity controller P gain (object) 150
Velocity demand value (object) 191
Velocity observer friction (object) 153
Velocity observer inertia (object) 153
Velocity observer load correction gain (object) 153
Velocity observer parameter set (object) 152
Velocity observer position correction gain (object) 152
Velocity observer velocity correction gain (object) 152
Velocity offset (object) 205
Velocity set value first velocity (object) 176
Velocity set value first voltage (object) 176
Velocity set value second velocity (object) 177
Velocity set value second voltage (object) 176
Vendor ID (object) 70
version history 251

W

Watchdog error (error message) 244
Write only error (abort code) 248
Wrong device state error (abort code) 248
Wrong NMT state error (abort code) 248

Z

zero point (see “Homing”)



EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany

© 2021 maxon. All rights reserved. Any use, in particular reproduction, editing, translation, and copying, without prior written approval is not permitted (contact: maxon international ltd., Brünigstrasse 220, CH-6072 Sachseln, +41 41 666 15 00, www.maxongroup.com). Infringements will be prosecuted under civil and criminal law. The mentioned trademarks belong to their respective owners and are protected under trademark laws. Subject to change without prior notice.